1.2 vla - Module

Module for VLA specific data processing
include "vla.g"

Description

This module contains functions and tools that are targeted at processing data from the Very Large Array (VLA). AIPS++ includes many other functions and tools for processing VLA data. These functions are generic enough to process data from other telescopes and hence are not described here. The functions and tools described below are specific to the VLA.

Tools

vlafiller	A tool for converting VLA archive format data to a measurement set

Functions

vlafillerdemo	Demonstrate the vlafiller tool
vlafillerfromdisk	Convert VLA archive data from a disk file to a measurement set
vlafillerfromtape	Convert VLA archive data from a tape to a measurement set
vlafilleroldweights	Use an older weighting scheme
vlafillertest	Test the vlafiller tool

1.2.1 vlafiller - Tool

Package nrao
Module vla

A tool for converting VLA archive format data to a measurement set
include "vlafiller.g"

Description

A vlafiller is a tool that contains functions that allow you to convert data that has been stored in the VLA archive format to a measurement set. Note that VLA archive format versions earlier than version 23 (earlier than 1990) are not supported by the vlafiller.

The VLA archive format is radically different from FITS and is the native data format written by the online computers at the VLA. The VLA data that is archived at the AOC is stored, on tape, in this format. It is described more fully in the VLA Computer Memorandum 188.

Running the vlafiller tool is a multi-step process. These steps can be grouped into the following sequence.

1. Create a vlafiller tool
2. Specify the data source and sink
3. Select some data filters (optional)
4. Start the copying process
5. Remove the tool

The advantage of a multi-step approach is that it gives the user fine grained, flexible control of the filling process. For many users this is unnecessary and the global functions vlafillerfromtape, vlafillerfromdisk bundle the vlafiller functions into a simpler one step approach.

Creating a vlafiller tool
The only way to create a vlafiller tool is to use the vlafiller constructor. Calling this function will start a precompiled executable, called vlafiller, usually running on your machine. This executable executes all the vlafiller functions. See the documentation for the vlafiller constructor for a more complete description of this function.

Specifying the data source and sink
The data source can either be a tape drive, disk file or the online computers. If it is a tape drive then it is assumed that a VLA archive format tape is already in the drive. The vlafiller knows about the layout and blocking structure of files on a VLA archive format tape and is able to rewind and skip to the any file on the tape. The files on a tape are numbered beginning at one. Users of tapes from the VLA archive need to be aware that the first file on these tapes is a tape label and hence the first file containing astronomical data will be the file numbered two.
An alternative to using the tapeinput function the VLA archive data may be copied from tape to disk using commands like:

```
dd if=/dev/tape bs=26624 of=file1.vla
```

and you can use commands like

```
mt -f /dev/tape fsf 2
```

to manually skip, in this example, over two tape files.
Then the diskinput function can be used to read this file. The advantage of this is that reading from disk is *much* faster and a lot less troublesome than reading from tape. It is also advantageous to do this if you need to read the data multiple times as shown in the examples below. The disadvantage is that

you need about 160MBytes of spare disk space, as this is typically the size of a VLA archive file.
The vlafiller can also read data directly from the online computers at the VLA. This option is only available when the filler is run on a computer at the array operations center in Socorro. See the final example below for an illustration of how to do this.
The data sink is a measurement set. The vlafiller can append data to an existing measurement set[1] or create a new one. Only one measurement set can be written for each pass through the input data. If you need to write multiple measurement sets each containing a different subset of the input archive you should consider copying the data to disk as described above. See the documentation for the output function for a more complete description of how to specify the data sink.

Selecting data filters
One measurement set is able to contain all the data in any number of VLA archive format files. Such a measurement set will usually be quite large, potentially affecting data access times, and may contain unwanted data. The vlafiller has a number of functions that allow you to discard data prior to it being copied into the output measurement set. These functions all have names that begin with the word select, a typical one being selectproject.
It is possible to use any combination of select functions as each one filters the data on a different parameter[2]. For example using the selectproject and selectfrequency functions will then only copy data from the specified project *and* in the specified frequency range. Other data in the same project or other projects that use the same frequency will not have their data copied to the measurement set.
Using a specific select function more than once will overwrite the previous selection. For example using the selectsource function with sourceA and then sourceB as arguments will discard any selection of sourceA (assuming you have not run the fill function between the two function calls).
Currently it is only possible to select data based on a limited number of parameters. Other selections must be done after the data is converted to a measurement set.

Starting the copying process
Once a vlafiller tool has been setup with input and output files the fill function is used to copy the data.
This function, unlike all the other ones in the vlafiller tool, can take some time. Because of this it can be run in the background ie., asynchronously. If run synchronously and from the command line you will not be able to type any further commands to glish until the command completes. If run asynchronously from the command line the function will return with a small

[1] Currently, it is only possible to append to a measurement set that was created with the vlafiller tool.

[2] The exception is the selectfrequency and selectband functions which are mutually exclusive.

positive integer that indicates the job number. This number can be used to query whether the function is still running and a message will appear in the logger when the function has finished. In either case the vlafiller tool will not execute any other functions until the fill function has completed. You need to start a new vlafiller server process, by calling the constructor with the forcenewserver argument set to true, to run two fill functions simultaneously. You can signal for the filler to stop filling as soon as possible using the stop function. This function will shut the filling function down after it has completed processing the current record.
When the fill function terminates it closes the input source, but leaves the output measurement set open. This way you can open another input source and append data to the existing measurement set.

Removing the tool
When you have finished with the vlafiller you should shut down the process, using the done function, even though it is not consuming much processor time. This is to conserve virtual memory. Once a tool is shut down it can no longer be used. It also closes the output measurement set.

Example
The following example shows the minimum necessary to run the vlafiller. The first line makes all the definitions for this tool available to the user. The second line calls the constructor. The third tells the filler that the input is to come from a file, in the current directory, called file1.vla. The fourth states that the output is to go to a measurement set called file1.ms. The fifth line does all the copying and the sixth shuts down the tool.

```
include 'vlafiller.g'     #1
v := vlafiller()          #2
v.diskinput('file1.vla')  #3
v.output('file1.ms')      #4
v.fill()                  #5
v.done()                  #5
```

This example could also be done much more simply using the vlafillerfromdisk global function as shown below.

```
vlafillerfromdisk('file1.ms', 'file1.vla')
```

All the other examples in this section are too complicated to be done using the vlafillerfromdisk or vlafillerfromtape global functions.

Example
This example illustrates the way the vlafiller can be used to read all the calibrators from three files.

The first three lines are identical to the first example. The fourth line sets the output measurement set to file1.ms. As this file may already exist, if you have just done example shown above the overwrite flag is set to force deletion of any existing file prior to copying any data. The fifth line selects all the calibrators, irrespective of their calibration code. The sixth line copies all the calibrators from the file to the measurement set.
At this point the input VLA archive file is closed but the output measurement set is still open. Line seven opens a new VLA archive file, called file2.vla, and line eight copies all the calibrators from that file to the measurement set. Note that the selection done in line five is still current and that the second fill command appends to the existing measurement set rather than overwriting it. This process continues for the third file before the process is shut down.

```
include 'vlafiller.g'               #1
v := vlafiller()                    #2
v.diskinput('file1.vla')            #3
v.output('file1.ms', overwrite=T)   #4
v.selectcalibrator('*')             #5
v.fill()                            #6
v.diskinput('file2.vla')            #7
v.fill()                            #8
v.diskinput('file3.vla')            #9
v.fill()                            #10
v.done()                            #11
```

Example
This example illustrates how to make multiple passes through a file to do more complex selections. The selectsource function can only select one source. If you want to create a measurement set with exactly two sources you need to read the file twice as shown in the example below.
The first four lines are identical to the above example. The fifth line selects the first source 'ngc1234' and the sixth line copies this to the measurement set. As described above after calling the fill function the input data source is closed. So we need to re-specify it as shown in line seven. Line eight then sets the selection to read the other source and line nine appends it to the measurement set.

```
include 'vlafiller.g'               #1
v := vlafiller()                    #2
v.diskinput('file1.vla')            #3
v.output('file1.ms', overwrite=T)   #4
v.selectsource('ngc1234')           #5
v.fill()                            #6
v.diskinput('file1.vla')            #7
```

```
v.selectsource('cen-a')            #8
v.fill()                           #9
v.done()                           #10
```

Example
This example illustrates how to use the vlafiller to read from a tape on a remote machine and fill the data asynchronously (as tapes take a long time). The first line is identical to previous examples. The second line starts up the vlafiller process on the computer called 'tapehost' (thats the one with the tape drive). The third line tells the vlafiller it is to read the first three files from the tape in the drive with a Unix device name of '/dev/nst0'. The fourth line tells the vlafiller to create the measurement set in the /tmp directory. This is the /tmp directory on the tapehost machine which is usually not the same as the /tmp directory on your local machine. To see the measurement set on your local machine you need to write to a disk that shares files (usually via NFS). The fifth line selects only the data from the specified project. The sixth line tells the filler to start copying the data asynchronously.
At this point glish returns before all the data has been copied. When all the data has been copied a message appears in the logger window. This may be missed if you are doing other things so in this example I set up a whenever that detects the event signalling that the job has finished and pops up a window to attract the users attention. Finally the tool is shut down.

```
include 'vlafiller.g'                      #1
v := vlafiller(host='tapehost')            #2
v.tapeinput('/dev/nst0', files=[1,2,3])    #3
v.output('/tmp/file1.ms')                  #4
v.selectproject('ab123')                   #5
jobid := v.fill(async=T, verbose=F)        #6
whenever defaultservers.alerter() -> [as_string(jobid)] do {
  deactivate
  messagebox("VLA filler has finished")
}
....
v.done()
```

Example
The final example illustrates how to use the vlafiller to read data from the online computers.
The first two lines are identical to previous examples. The third line tells the vlafiller it is to read data from the online computers. The fourth line tells the vlafiller to create the measurement set in the current directory. The fifth line

selects only the data from the specified project. The sixth line tells the filler to start copying the data. Records are processed as they are made available by the online computers. To stop the filling process the stop function is used. This cleanly terminates the filling function and the tool is shutdown using the done function.

```
include 'vlafiller.g'                    #1
v := vlafiller()                         #2
v.onlineinput()                          #3
v.output('realtime.ms')                  #4
v.selectproject('ab123')                 #5
v.fill(async=T)                          #6
....
v.stop()                                 #7
v.done()                                 #8
```

Scaling & weighting of VLA data

The vlafiller scales both the visibility data and computes the weights in a manner that is compatible with the `31DEC01` version of the AIPS task FILLM. The details of both the scaling and weight computation are described below.
The visibility data that is stored in the VLA archive is related to the the raw correlator coefficients by a scaling factor. This factor, which is different for each correlator, can be decomposed into antenna based terms called the nominal sensitivity (s_i). The raw correlation coeffecient (ρ_{ij}) is then related to the value stored in the VLA archive (v_{ij}) by the formula:

$$v_{ij} = \rho_{ij} \cdot \sqrt{s_i \cdot s_j}$$

The nominal sensitivity is derived during the course of an observation from calibrated noise diodes on each antenna.
The visibility data in VLA archive format is represented using a 16-bit signed integer for each of the real and imaginary components. To increase the dynamic range that can be represented each group of visibilities is scaled by a signed exponent (e). A group of visibilities is, in continuum mode, all four-correlations ie., RR, LL, RL, LR, for one baseline. In spectral line mode it's all channels corresponding to one correlation.
In order to convert these integers to a complex number (d_r, d_i) the vlafiller uses the formula (the subscripts r & i denote the real and imaginary components):

$$(d_r, d_i) = (v_r, v_i)/2^{-(e+8)}$$

All floating point operations are done in single precision. The factor of 8 added to the exponent results in scaling the complex data by 256. It is probably used to further scale the data so that it has nominal units of deka-Jansky's ie., 1.0 means 10 Jy.

The vlafiller assigns weights to the data that are directly proportional to both the integration time and the observed bandwidth and indirectly related to the system temperature at each of the antennas. The mathematical description and justification of this is described in AIPS memo 103, "Weighting data in AIPS" by Ketan Desai. In essence it states that the weights should be given by:

$$w_{ij} = \frac{\Delta t \Delta \nu}{s_i s_j}$$

where: Δt is the integration time (typically 10 seconds)
$\Delta \nu$ is the bandwidth (often 50MHz)
s_i is the nominal sensitivity of antenna i (typically around .2)

AIPS modifies these weights by scaling them by a factor that has been empirically determined so that the rms determined from the weights ($\sigma_{ij} = \frac{1}{\sqrt{w_{ij}}}$) corresponds to the measured rms in the visiblities when a calibrator is being observed. This factor is $.12/10000$[3]. In order to maintain consistency with AIPS, AIPS++ also scales the weights by this factor. Prior to version 1.5 of AIPS++ the vlafiller used a simpler algorithm for calculating weights that matched what was the default in older versions of AIPS. The old weights were simply the integration time, in seconds, divided by 10. The vlafiller contains a global function called vlafilleroldweights that allows you to change the weights in a measurement set so that the older scheme is used. You cannot change the weights in a measurement from the old scheme to the new scheme. Instead you need to reload the data.

Constructors

vlafiller	Construct an vlafiller tool.

Functions

diskinput	Specify the input data file.
done	Delete the vlafiller tool
fill	Copy the data
onlineinput	Read input data from the online computers.
output	Specify the output measurement set
selectband	Select which frequency-band to convert
selectcalibrator	Select which calibrators to convert
selectfrequency	Select which frequency-range to convert
selectproject	Select which project to convert
selectsource	Select which source to convert
selectsubarray	Select which sub-array to convert
selecttime	Select which time-range to convert

[3]It is interesting to note that $.12/10000$ is very close to $1/256^2$ which is the adjustment that would be made in the weights that corresponded to the scaling the data 256.

state	Show the state of the tool
stop	Stop the filling process
tapeinput	Specify the input tape device.

vlafiller - Constructor

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Construct an vlafiller tool.

Synopsis
vlafiller(host, forcenewserver)

Description

Use this constructor to create a vlafiller tool. This is the only way to construct such a tool. As described above newly created tools cannot convert data until the the input data source is defined, using the tapeinput, diskinput or onlineinput functions, and output measurement set is defined using the output function.
The host argument specifies which machine the precompiled vlafiller process should be started on. The default value of unset starts it on the same machine as the one that glish is running on. Starting a vlafillller process on a remote machine gives you access to the tape drives and disks on that machine. Use this option if you do not have a tape drive on your local machine.
In order to run the vlafiller on a remote machine you need to satisfy all the following conditions.

- It must be possible to start AIPS++ on the remote machine
- You must be able to log onto the remote machine without having to type a password
- The AIPSPATH environment variable must be defined on the remote machine. You may want to set this up in the relevant "dot" file eg., adding a line like `source /usr/local/aips++/aipsinit.csh` in your .cshrc file (for csh).

One quick way to check if all three conditions are met is to type, on your local machine:

```
rsh host 'echo \$AIPSPATH'
```

where host is replaced by the name of the remote machine. If the value of the AIPSPATH variabl that is printed does not contain something like `aips-root architecture site host` and that all the values are correct for the remote machine you can be certain that starting the vlafiller, or any AIPS++ server, on the remote host will not work
Each vlafiller server process can only run one function at a time. Hence it is not possible, for example, to simultaneously read data from two tape drives to two measurement sets using one server. To solve this you start two servers. The forcenewserver argument allows you to do this by overriding the default behaviour of having each vlafiller tool share the same server.

Arguments

host	The host on which the vlafiller should be run Allowed:string Default: unset
forcenewserver	Always start a new server Allowed:Boolean Default: F

Returns
A vlafiller tool

Example

```
include 'vlafiller.g'
v := vlafiller()
v.diskinput('file1.vla')
v.output('file1.ms')
v.selectproject(project='ab123')
v.state()
v.fill(async=T)
v.stop()
v.done()
```

This example creates a vlafiller tool, sets the data source as a disk file called file1.vla, and the data sink as the measurement set called file1.ms. The selectproject function filters the data so that only records that correspond to the case insensitive project-id 'ab123' will be copied. The state function prints the current state of the filler in the logger, in case you forget.
No data is actually copied until the fill function is called. If a large amount of data is involved then the fill function may take some time so it may make

sense to let the filler work in the background by setting the async flag. After copying some data the user stopped the filling function using the stop function. The vlafiller tool was then shut down, memory associated with it released and the output measurement set closed using the done function.

---

vlafiller.diskinput - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Specify the input data file.

Synopsis
diskinput(filename)

Description

The diskinput functions specifies that the input data is the specified file on disk.
Normally VLA archive data is stored on tape but if you need to read one or more files repeatedly it may be faster to copy the file to disk and then convert this disk file to a measurement set. Data can be read from tapes to disk in a variety of ways including:

```
dd if=/dev/tape bs=26624 of=file1.vla
```

This functions returns F if the specified file is not readable.

Arguments

filename	The input file name. Allowed:string Default: no default

Returns
T or F

Example
See the example for the vlafiller constructor.

---

vlafiller.onlineinput - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Read input data from the online computers.

Synopsis
onlineinput()

Description

The onlineinput functions specifies that the input data is to come from the online computers at the VLA. This allows you to read data shortly after it has been observed. The data is sent from the VLA computers to a predefined machine called `vis-server` at the Array Operations Center (AOC) in Socorro NM. The vlafiller will make a connection, via the Internet to this machine. Online filling is only available on the computers at the AOC.

Returns
T or fail

Example
See the final example in the tool overview documentation.

---

vlafiller.tapeinput - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Specify the input tape device.

Synopsis
tapeinput(device, files)

Description

The tapeinput function specifies that the input data source is the specified files on the specified tape device.

VLA archive data is normally stored on tape. Each tape may contain numerous files with the data from different projects mixed within one file and/or spread across numerous tape files. The tape archive log will contain a summary of what data is on what tape file.

This function tells the vlafiller tool which tape device and which files to read from the specified tape device. The tape device is the standard Unix name. Typical examples are `/dev/rmt/0ln` for Solaris 2.x and `/dev/nst0` for Linux.

The files are numbered beginning at one. The files that are to be read are specified with positive integers that are in ascending order. For example specifying `files=[1,2,10]` will read the first, second and tenth files from tape. [4]

Users of AIPS should note that the AIPS++ convention of explicitly specifying which files to read is different, and more flexible, than than using the `NFILES` adverb in the `FILLM` task. In `FILLM` the `NFILES` adverb specifies how many tape files to skip prior to reading to reading any data.

The vlafiller tool always rewinds the tape in order to know where the the tape is currently positioned when the files are specified using integers greater than zero. If you have manually positioned the tape to the start of the file you want to read you can specify that the filler should "read the next file" using `files=0`. The number zero in this case meaning "read the next file". In this case the filler will not rewind the tape prior to reading the data. It is also possible to specify `files=[0,0,0]` which means "read the next three files" and to mix zeros with absolute file numbers. For example `files=[1,0,10]` will read the first, second and tenth files, but `files=[1,0,2]` will produce an error message as the filler will not read file two twice.

This functions returns F if the specified tape is not readable.

Arguments

device	The tape device. Allowed:string Default: no default
files	The files to read. Allowed:vector of integers Default: [1]

Returns

T or F

[4] Users should be aware that, for tapes in the VLA archive, this numbering scheme differs by one from that used in versions of aips++ prior to 1.7. The numbering scheme now corresponds to that listed in the logs kept in the archive room.

Example

```
include 'vlafiller.g'
v := vlafiller()
v.tapeinput('/dev/nst0', files=1)
v.output('file1.ms')
v.selectsource(source='ngc1234', qualifier=1)
v.fill()
v.done()
```

This example is identical to that for the vlafiller constructor except that the input data is the first file on the specified tape and all the data of ngc1234 with qualifier will be copied.

---

vlafiller.output - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Specify the output measurement set

Synopsis
output(msname, overwrite)

Description

The output function specifies that the name of the output measurement set. A measurement set stores the data on disk in files & directories within a directory with the specified name.
If the specified measurementment set already exists, and contains exclusively data that has been created by the vlafiller tool, it is possible to append new data to the existing measurement set. The overwrite argument needs to be set to F to append data.
Otherwise the measurement set, or a file/directory with the same name, will not be replaced unless the overwrite argument is set to T.
This functions returns F if the specified measurement set cannot be created.

Arguments

msname	The measurement set name. Allowed:string Default: no default
overwrite	Overwrite an existing file. Allowed:Boolean Default: F

Returns
T or F

Example
See the example for the vlafiller constructor.

---

vlafiller.selectproject - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which project to convert

Synopsis
selectproject(project)

Description

The selectproject function filters the data so that only some of it is copied to the output measurement set.
The observing project identifier is a string of six or less characters. Only records that contain the same, case in-sensitive, string are copied to the output measurement set. The 'unset' value matches all projects. This is the default.
This functions returns F if the selection could not be done.

Arguments

project	The observing project name. Allowed:string Default: unset

Returns
T or F

Example
See the example for the vlafiller constructor.

---

vlafiller.selecttime - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Select which time-range to convert

Synopsis
selecttime(start, stop)

Description

The selecttime function filters the data so that only some of it is copied to the output measurement set.
Only data that have been observed[5] between the specified start and stop times will be copied to the output measurement set. The times are specified using any of the string formats that can be interpreted by the quanta module (see the section on time formatting).
If the start input parameter is unset then it defaults to 'a long time in the past'. Similarly if the stop input parameter is unset it defaults to 'along time in the future'. Hence using this function with no input parameters disables any time selection.
It is important to specify both the day and time portions for the start and stop time. Otherwise the day will default to the day with the modified Julian day of zero ie. the 17-Nov-1858. If you want to fill in the current date for the day number you can preceed the time with a slash. eg., `start='/6:45'`.
This functions returns F if the selection could not be done.

Arguments

[5] The observation time of a single integration is the time at the midpoint of the integration

start	The beginning of the time range. Allowed:string Default: unset
stop	The end of the time range. Allowed:string Default: unset

Returns
T or F

Example

```
include 'vlafiller.g'
v := vlafiller()
v.diskinput('file1.vla')
v.output('file1.ms')
v.selecttime(start='31Dec00/00:00:00.123',
     stop='31-Dec-2000/23:59:59.876')
v.selectfrequency(centerfrequency='1.4GHz', bandwidth='200MHz')
v.fill()
v.done()
```

This example selects all the data that was observed on the last day of the millennium where any part of the observation was between 1.3GHz and 1.5GHz. See the example for the vlafiller constructor for a more complete discreption of other parts of this example.

---

vlafiller.selectfrequency - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which frequency-range to convert

Synopsis
selectfrequency(centerfrequency, bandwidth)

Description

The selectfrequency function filters the data so that only some of it is copied to the output measurement set.
The frequency band is specified using a center frequency and a bandwidth around that frequency. These frequencies are specified using strings to include the necessary units ie., kHz, MHz etc.
This function rejects input records were all the correlations are entirely outside the specified frequency band. It cannot be used to select channels, this must be done after the measurement set has been created. For example if a spectral line observation has data in ten channels between 100MHz and 200MHz then calling this function with a center frequency of 200MHz and a bandwidth of 40MHz will include *all* of the data between 100MHz and 200MHz and not just the last two channels.
If any of the input parameters is unset then no frequency selection is done. This is the default.
This functions returns F if the selection could not be done.

Arguments

centerfrequency	The center frequency. Allowed:string Default: unset
bandwidth	The range of frequencies around the center frequency. Allowed:string Default: unset

Returns
T or F

Example
See the example for the selecttime function.

---

vlafiller.selectband - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which frequency-band to convert

Synopsis
selectband(bandname)

Description

The selectband function filters the data so that only some of it is copied to the output measurement set.
This function selects input records where any of the correlations are within one of the eight standard VLA observing bands. These bands are:

Band	Frequencies
4	48 – 96 MHz
P	298 – 345 MHz
L	1.15 – 1.75 GHz
C	4.2 – 5.1 GHz
X	6.8 – 9.6 GHz
U	13.5 – 16.3 GHz
K	20.8 – 25.8 GHz
Q	38.0 – 51.0 GHz

The input argument to this function is a single character, case insensitive, string containing one of the band codes shown above. This is then translated to the relevant frequencies and passed to the selectfrequency function described above. Like the selectfrequency function this function may also copy data that is outside the band if some of the data in an input record is inside the specified band.
If the input parameter is unset then no frequency selection is done. This is the default.
This functions returns F if the selection could not be done.

Arguments

bandname	The frequency band to select. Allowed:string Default: unset

Returns
T or F

Example
See the example for the selecttime function.

---

vlafiller.selectsource - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which source to convert

Synopsis
selectsource(source, qualifier)

Description

The selectsource function filters the data so that only some of it is copied to the output measurement set.
The source name is a string with up to 16 characters. Only records that contain the same, case in-sensitive, string are copied to the output measurement set. The 'unset' value matches all projects. This is the default.
The source qualifier is an additional parameter that can be used to distinguish different observing configurations of the same source. It is an integer and is usually zero. The unset value can be used to select data with any source qualifier and this is the default.
This functions returns F if the selection could not be done.

Arguments

source	The source name. Allowed:string Default: unset
qualifier	The qualifier. Allowed:integer Default: unset

Returns
T or F

Example
See the example for the tapeinput function.

---

vlafiller.selectsubarray - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which sub-array to convert

Synopsis
selectsubarray(subarray)

Description

The selectsubarray function filters the data so that only some of it is copied to the output measurement set.
The input argument to this function is an integer between one and five (inclusive) which indicates which subarray to select the data from.
If the input parameter is unset then no subarray selection is done. This is the default.
This functions returns F if the selection could not be done.

Arguments

subarray	The subarray id. Allowed:integer Default: unset

Returns
T or F

Example
See the selectcalibrator function.

---

vlafiller.selectcalibrator - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Select which calibrators to convert

Synopsis
selectcalibrator(calcode)

Description

The selectcalibrator function filters the data so that only some of it is copied to the output measurement set.
The calibrator code can be any uppercase letter or a single numeric character. Often it is assigned by the scheduling software and may have a specific meaning. The character '*' can be used to select all the calibrators regardless of the calibration code. This does not select any of the target sources which have a calibrator code of ' ' (the space character).
This function can be used to filter out all the calibrators so that only target sources are filled. This is done using a argument of ' ' (the space character).
To revert to the default behaviour of selecting all the target sources and all the calibrators this function should called with the unset argument.
This function returns F if the selection could not be done.

Arguments

calcode	The calibrator code to select. Allowed:string Default: unset

Returns
T or F

Example

```
include 'vlafiller.g'
v := vlafiller()
v.diskinput('file1.vla')
v.output('file1.ms')
v.selectband('L')
v.selectsubarray(1)
v.selectcalibrator('C')
v.fill()
v.done()
```

This example selects all the calibrator data with positions known to better than 50mas (as thats what calcode 'C' usually means), that was observed using in 'L' band (near 1.4GHz) in using sub-array 1. See the example for the vlafiller constructor for a more complete description of other parts of this example.

---

vlafiller.fill - Function

Package **nrao**
Module **vla**
Tool **vlafiller**

Copy the data

Synopsis
fill(verbose, async)

Description

The fill function copies the data from the previously specified input VLA archive to the previously specified output measurement set, applying any previously specified data filtering criteria.
All cross-correlation and auto-correlation data are copied to the measurement set. Data is copied and flagged if the online system indicates that any of the IF's involved in the correlation had a status greater than three.
Unlike most of the other functions in this tool the fill data may take a long time to execute. As a result it sends to the logger messages indicating whenever it has come across, a change in the array configuration, field center, spectral window or polarization setup. More extensive messages that log the processing of each record may be enabled by setting the verbose argument to T.
The fill function may also be run asynchronously by setting the async argument to T. When run asynchronously the function returns quickly and runs in the background. A message is sent to the logger window when the function has finished executing.
When the fill function has successfully completed the input source is reset to a null value. This means you *must* call setinput at least once once prior to every invocation of the fill function.
This functions returns T or the job id (if run asynchronously).

Arguments

verbose	Send messages when copying each record. Allowed:Boolean Default: F
async	Run this function asynchronously. Allowed:Boolean Default: F

Returns
T or a small integer

Example
See the example for the vlafiller constructor or the examples in the vlafiller tool description.

---

vlafiller.state - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Show the state of the tool

Synopsis
state()

Description

The state function displays to the logger the current state of the filler. This lets you know what the input and output files are and what selections have been made.

Returns
T or fail

Example
See the example for the vlafiller constructor.

---

vlafiller.stop - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Stop the filling process

Synopsis
stop()

Description

The stop function will signal the filler process to stop immediately after reading the next record. This is the earliest point at which the filling process can sensibly be halted and it is quite likely that the filling process will be stopped midway through a scan. Using this function, and then shutting down the filler process, using the done function, should result in a perfectly valid but truncated measurement set.

Returns
T or fail

Example
See the example for the vlafiller constructor.

---

vlafiller.done - Function

Package	**nrao**
Module	**vla**
Tool	**vlafiller**

Delete the vlafiller tool

Synopsis
done()

Description

The done function frees up all the memory associated with a vlafiller tool. This function also closes all the disk files and tape devices that it used so that other tools can use them. It will also shut down the server process if there are no other vlafiller tools being used.

Returns
T

Example
See the example for the vlafiller constructor.

1.2.2 vlafillerfromtape - Function

Package nrao
Module vla

Convert VLA archive data from a tape to a measurement set

Synopsis
vlafillerfromtape(msname, device, files, project, start, stop, bandname, source, overwrite, verbose, async, host)

Description

This global function prevents users from having to explicitly use the vlafiller tool by packaging its functions so they perform a common task ie., copying VLA archive data from tape to a measurement set.
There are only two arguments which the user must supply in order to successfully use this function, these are the device and msname arguments. These arguments specify the name of the tape device and the output measurement set. All other arguments are optional. See the tapeinput & output functions for more details.
A number of arguments control what data is copied to the output measurement set. These are:

project See the selectproject function.

start & stop See the selecttime function.

bandname See the selectband function.

source See the selectsource function[6].

The remaining arguments control details of the filling process. The overwrite argument specifies whether the output measurement set is deleted prior to copying the data. See the output function for more details.
The files argument controls which files on tape are to be read. The first file containing astronomical data is numbered file one and a number of files can be

[6] You cannot select which qualifier to use, you always get all of them

specified using a vector of increasing integers eg., `files=[1,2,10]`. See the tapeinput function for more details.

The verbose argument controls how much status information is sent to the logger and the async argument controls whether the function should run in the background. See the fill function for more details.

The host argument controls which machine this filler process is run on. This allows remote tape drives to be used. Unless you have done this before it is recommended you read the full description of this mechanism described in the vlafiller constructor.

This function returns T is everything went well and F otherwise.

Arguments

msname	The measurement set name. Allowed:string Default: no default
device	The tape device. Allowed:string Default: no default
files	The files to read. Allowed:vector of integers Default: [1]
project	The observing project name. Allowed:string Default: unset
start	The beginning of the time range. Allowed:string Default: unset
stop	The end of the time range. Allowed:string Default: unset
bandname	The frequency band to select. Allowed:string Default: unset
source	The source name. Allowed:string Default: unset
overwrite	Overwrite an existing file. Allowed:Boolean Default: F
verbose	Send messages when copying each record. Allowed:Boolean Default: F
async	Run this function asynchronously. Allowed:Boolean Default: T
host	The host on which the vlafiller should be run Allowed:string Default: unset

Returns
T or F

Example

```
include 'vlafiller.g'
```

```
vlafillerfromtape('ab123.ms', '/dev/rmt/0ln', files=[1,2], project='ab123');
```

This example creates the measurement set called 'ab123.ms' from all the records in the first two files of the tape that come from the observing project called 'AB123'.

1.2.3 vlafillerfromdisk - Function
Package nrao
Module vla

Convert VLA archive data from a disk file to a measurement set

Synopsis
vlafillerfromdisk(msname, filename, project, start, stop, bandname, source, overwrite, verbose, async, freqTolerance)

Description

This global function prevents users from having to explicitly use the vlafiller tool by packaging its functions so they perform a common task ie., copying data from a disk file containing VLA archive data into a measurement set. In the best case, there are only two arguments which the user must supply in order to successfully use this function, these are the filename and msname arguments. These arguments specify the names of the input vla archive file and the output measurement set. All other arguments are optional. See the diskinput & output functions for more details. Due to the variety of the dataset quality, however, some dataset requires a larger tolerance for frequeny in order to recognize the same spectral window. So the user may need to pass in a proper tolerance according to the specific dataset. As a rule of thumb, executing the filling script first with the default tolerance and examing the generated SPECTRAL_WINDOW subtable of MS will give you a good hint about what is the right tolerance for the frequency to use. For instance, for dataset G192, the proper tolerance for frequency is about 6 times of its channel width(see the glish test script g192_testTolerance.g), while for dataset NGC7538, a much larger tolerance, 60 times of its channel width, (see the glish test scripts ngc7538_testTolerance.g) is required in order to recognize the two related frequencies as the same spectral window. The freqTolerance should be in the unit of Hz.
A number of arguments control what data is copied to the output measurement set. These are:

project See the selectproject function.

start & stop See the selecttime function.

bandname See the selectband function.

source See the selectsource function[7].

The remaining arguments control details of the filling process. The overwrite argument specifies whether the output measurement set is deleted prior to copying the data. See the output function for more details.

The verbose argument controls how much status information is sent to the logger and the async argument controls whether the function should run in the background. See the fill function for more details.

This function returns T is everything went well and F otherwise.

Arguments

[7] You cannot select which qualifier to use, you always get all of them

msname	The measurement set name. Allowed:string Default: no default
filename	The input file name. Allowed:string Default: no default
project	The observing project name. Allowed:string Default: unset
start	The beginning of the time range. Allowed:string Default: unset
stop	The end of the time range. Allowed:string Default: unset
bandname	The frequency band to select. Allowed:string Default: unset
source	The source name. Allowed:string Default: unset
overwrite	Overwrite an existing file. Allowed:Boolean Default: F
verbose	Send messages when copying each record. Allowed:Boolean Default: F
async	Run this function asynchronously. Allowed:Boolean Default: F
freqTolerance	The tolerance for frequency. Allowed:Double Default: The channel width of the current spectral window in Hz

Returns
T or F

Example

```
include 'vlafiller.g'
vlafillerfromdisk('ab123.ms', 'file1.vla', project='ab123');
```

This example creates the measurement set called 'ab123.ms' from all the records in the file called 'file1.vla' that come from the observing project called 'AB123'.

Example

```
include 'vlafiller.g'
vlafillerfromdisk(filename='data/G192/AS758\_C030425.xp1',
                  msname='g192\_a.ms', overwrite=T,bandname='K',
                  async=F, freqTolerance=150000.0);
```

This example shows how a user can pass in a tolerance for the frequency matching. It creates the measurement set called 'g192_a.ms' from all the records in the file called 'data/G192/AS758_C030425.xp1'.

1.2.4 vlafilleroldweights - Function

Package nrao
Module vla

Use an older weighting scheme

Synopsis
vlafilleroldweights(msname)

Description

This global function will change the weights of the supplied measurement set to a value that only depends on the integration time. The values in the WEIGHT column will be changed to one tenth of the value in the EXPOSURE column and the values in the SIGMA column will be changed to the inverse square-root of the new value in the WEIGHT column. This was the original behaviour of the vlafiller tool.
From release 1.5 the vlafiller tool sets the weights to a value that depends on the integration time, bandwidth and system temperature of the relevant antennas. This is believed to be more representative of the errors in the observation.
This function returns T is everything went well and F otherwise.

Arguments

msname	The measurement set name. Allowed:string Default: no default

Returns
T or F

Example

```
include 'vlafiller.g'
vlafilleroldweights('ab123.ms');
```

This example resets the weights in the measurement set 'ab123.ms'. There is no way to back out of this change so if you need to compare both weighting schemes you should copy your data to a separate measurement set prior to running this function.

1.2.5 vlafillerdemo - Function
Package nrao
Module vla

Demonstrate the vlafiller tool

Synopsis
vlafillerdemo()

Description

Returns
T or fail

Example

```
include 'vlafiller.g'
vlafillerdemo()
```

1.2.6 vlafillertest - Function
Package nrao
Module vla

Test the vlafiller tool

Synopsis
vlafillertest()

Description

Returns
T or fail

Example

```
include 'vlafiller.g'
vlafillertest()
```