



**Atacama  
Large  
Millimeter  
Array**

# SDM Tables Short Description

COMP-70.75.00.00-00?-A-DSN

March 19, 2018

*Design Document*

F.Viallefond, R. Lucas



# SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 2

## Contents

<b>1</b>	<b>List of ASDM Tables</b>	<b>6</b>
1.1	Versioning information for the ASDM.	7
1.2	Main Table	8
1.3	AlmaRadiometer Table	10
1.4	Annotation Table	11
1.5	Antenna Table	13
1.6	CalAmpli Table	15
1.7	CalAntennaSolutions Table	17
1.8	CalAppPhase Table	19
1.9	CalAtmosphere Table	23
1.10	CalBandpass Table	26
1.11	CalCurve Table	29
1.12	CalData Table	31
1.13	CalDelay Table	33
1.14	CalDevice Table	35
1.15	CalFlux Table	37
1.16	CalFocus Table	39
1.17	CalFocusModel Table	42
1.18	CalGain Table	44
1.19	CalHolography Table	45
1.20	CalPhase Table	48
1.21	CalPointing Table	51
1.22	CalPointingModel Table	54
1.23	CalPosition Table	56
1.24	CalPrimaryBeam Table	58
1.25	CalReduction Table	60
1.26	CalSeeing Table	62
1.27	CalWVR Table	64
1.28	ConfigDescription Table	67
1.29	CorrelatorMode Table	69
1.30	DataDescription Table	70
1.31	DelayModel Table	71
1.32	DelayModelFixedParameters Table	73
1.33	DelayModelVariableParameters Table	75
1.34	Doppler Table	77
1.35	Ephemeris Table	78
1.36	ExecBlock Table	81
1.37	Feed Table	84
1.38	Field Table	87
1.39	Flag Table	89
1.40	Focus Table	92
1.41	FocusModel Table	93
1.42	FreqOffset Table	94



# SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 3

1.43	GainTracking Table . . . . .	95
1.44	Holography Table . . . . .	96
1.45	Pointing Table . . . . .	97
1.46	PointingModel Table . . . . .	100
1.47	Polarization Table . . . . .	101
1.48	Processor Table . . . . .	102
1.49	Pulsar Table . . . . .	103
1.50	Receiver Table . . . . .	104
1.51	SBSummary Table . . . . .	105
1.52	Scale Table . . . . .	107
1.53	Scan Table . . . . .	108
1.54	Source Table . . . . .	110
1.55	SpectralWindow Table . . . . .	113
1.56	SquareLawDetector Table . . . . .	116
1.57	State Table . . . . .	117
1.58	Station Table . . . . .	118
1.59	Subscan Table . . . . .	119
1.60	SwitchCycle Table . . . . .	120
1.61	SysCal Table . . . . .	121
1.62	SysPower Table . . . . .	123
1.63	TotalPower Table . . . . .	124
1.64	WVMCal Table . . . . .	126
1.65	Weather Table . . . . .	128

## 2 List of Enumerations 130

2.1	Versioning information for the enumerations. . . . .	131
2.2	ACAPolarization . . . . .	132
2.3	AccumMode . . . . .	132
2.4	AntennaMake . . . . .	132
2.5	AntennaMotionPattern . . . . .	132
2.6	AntennaType . . . . .	133
2.7	AssociatedCalNature . . . . .	133
2.8	AssociatedFieldNature . . . . .	133
2.9	AtmPhaseCorrection . . . . .	133
2.10	AxisName . . . . .	133
2.11	BasebandName . . . . .	134
2.12	BaselineReferenceCode . . . . .	134
2.13	BinaryDataFlags . . . . .	135
2.14	CalCurveType . . . . .	137
2.15	CalDataOrigin . . . . .	137
2.16	CalType . . . . .	138
2.17	CalibrationDevice . . . . .	138
2.18	CalibrationFunction . . . . .	139
2.19	CalibrationMode . . . . .	139
2.20	CalibrationSet . . . . .	139



# SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 4

2.21	CorrelationBit . . . . .	139
2.22	CorrelationMode . . . . .	140
2.23	CorrelatorCalibration . . . . .	140
2.24	CorrelatorName . . . . .	140
2.25	CorrelatorType . . . . .	140
2.26	DataContent . . . . .	141
2.27	DataScale . . . . .	141
2.28	DetectorBandType . . . . .	141
2.29	DifferenceType . . . . .	141
2.30	DirectionReferenceCode . . . . .	142
2.31	DopplerReferenceCode . . . . .	143
2.32	DopplerTrackingMode . . . . .	143
2.33	FieldCode . . . . .	143
2.34	FilterMode . . . . .	143
2.35	FluxCalibrationMethod . . . . .	143
2.36	FocusMethod . . . . .	144
2.37	FrequencyReferenceCode . . . . .	144
2.38	HolographyChannelType . . . . .	144
2.39	InvalidatingCondition . . . . .	144
2.40	NetSideband . . . . .	145
2.41	PointingMethod . . . . .	145
2.42	PointingModelMode . . . . .	145
2.43	PolarizationType . . . . .	145
2.44	PositionMethod . . . . .	145
2.45	PositionReferenceCode . . . . .	146
2.46	PrimaryBeamDescription . . . . .	146
2.47	PrimitiveDataType . . . . .	146
2.48	ProcessorSubType . . . . .	146
2.49	ProcessorType . . . . .	146
2.50	RadialVelocityReferenceCode . . . . .	147
2.51	ReceiverBand . . . . .	147
2.52	ReceiverSideband . . . . .	148
2.53	SBType . . . . .	148
2.54	ScanIntent . . . . .	148
2.55	SchedulerMode . . . . .	149
2.56	SidebandProcessingMode . . . . .	149
2.57	SourceModel . . . . .	150
2.58	SpectralResolutionType . . . . .	150
2.59	StationType . . . . .	150
2.60	StokesParameter . . . . .	150
2.61	SubscanIntent . . . . .	151
2.62	SwitchingMode . . . . .	152
2.63	SynthProf . . . . .	152
2.64	SyscalMethod . . . . .	152
2.65	TimeSampling . . . . .	152



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 5

2.66	TimeScale . . . . .	152
2.67	WVRMethod . . . . .	153
2.68	WeightType . . . . .	153
2.69	WindowFunction . . . . .	153



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 6

### 1 List of ASDM Tables

This document is just a container for the list of ASDM Tables. More documentation is envisaged in the final document which will include a general introduction.

Note: The order of keys in this document is NOT alphabetical; the hierarchical order matters and is actually different. In particular it has been changed in the CalDM Tables.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 7

### 1.1 Versioning information for the ASDM.

- Version : 3
- CVS revision : -1
- CVS branch :



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 8

### 1.2 Main Table

Contains links to all data subsets. Each data subset is contained in a separate entity, usually a BLOB.

Main		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>time</b>	<b>ArrayTime</b>	mid point of scheduled period.
<b>configDescriptionId</b>	<b>Tag</b>	Configuration description identifier.
<b>fieldId</b>	<b>Tag</b>	Field identifier.
<i>Required Data</i>		
<b>numAntenna</b> ( $N_{Ante}$ )	<b>int</b>	Number of antennas.
<b>timeSampling</b>	<b>TimeSampling</b>	time sampling mode.
<b>interval</b>	<b>Interval</b>	data sampling interval.
<b>numIntegration</b> ( $N_{Inte}$ )	<b>int</b>	number of integrations.
<b>scanNumber</b>	<b>int</b>	scan number.
<b>subscanNumber</b>	<b>int</b>	subscan number.
<b>dataSize</b>	<b>int64_t</b>	size of the binary data , as a number of bytes.
<b>dataUID</b>	<b>EntityRef</b>	reference to the binary data.
<b>stateId</b>	<b>Tag [numAntenna]</b>	State identifier.
<b>execBlockId</b>	<b>Tag</b>	ExecBlock identifier.

#### Column Descriptions:

**time** : The mid-point of the scheduled period for the row, thus not taking into account the effects of data blanking and any overhead.

**configDescriptionId** : The Configuration Description Table identifier. Note that two or more sub-arrays cannot refer to the same Configuration Description row. The Configuration Description thus makes possible to identify the various subarrays if more than one have been used in the same data set.

**fieldId** : The Field Identifier used in the Field Table.

**numAntenna** : The number of antennas. Provides the size of **stateId**.

**timeSampling** : This specifies whether the sampling interval is divided into simple integrations, or into integrations further divided into sub-integrations (for channel averaged correlator data).

**interval** : This is the nominal data interval, as scheduled, for the whole row. This means that data taking was scheduled to start a **time-interval/2** and end at **time+interval/2**. **Interval** corresponds to the sum of all integrations and does not include the effects of blanking (bad data) or partial integrations. In ALMA this is the scheduled duration of the subscan. For the actual subscan start and end times see the Subscan Table.

**numIntegration** : The number of integrations in **interval**. For Alma this is either true integrations (for full spectral resolution data), or the total number of subintegrations in **interval** (for channel -averaged spectral data).





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 9

**scanNumber** : In Alma a scan is an amount of data taken to reach a single result (e.g. a simple calibration). The scan numbers increment from 1 inside an Execution Block.

**subscanNumber** : In Alma a Subscan is the minimum amount of data taken by executing a single Control Command Language (CCL) command. There can be several data cells for each subscan corresponding to different backends (correlator, total power detectors) or different results of the same backend (channel averaged or full-resolution data from a Correlator). In each scan there is at least one subscan.

**dataSize** : Total size, in bytes, of the binary data file.

**dataUID** : This is a string that specifies the data object.

**stateId** : The State identifier used in the State Table.

**execBlockId** : The ExecBlock identifier used in the ExecBlock Table. For ALMA the ExecBlocks represent each execution of a Scheduling Block.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 10

### 1.3 AlmaRadiometer Table

Properties of the Radiometer receiver/backend (used to monitor water vapour content and correct phases). Note that standard properties (like spectral coverage) are in the generic tables (like SpectralWindow).

AlmaRadiometer		
Name	Type (Shape)	Comment
<i>Key</i>		
almaRadiometerId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
<i>Optional Data</i>		
numAntenna ( $N_{Ante}$ )	int	the number of antennas.
spectralWindowId	Tag [numAntenna]	the references to the actual spectral windows (one spectral window per antenna).

#### Column Descriptions:

almaRadiometerId : Alma Radiometer Table identifier.

numAntenna : The number of antennas to which the data refer.

spectralWindowId : enter tag descr. here



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 11

### 1.4 Annotation Table

The Annotation Table is intended to offer space for unexpected data to be added in the software development process at short notice, without redefining the data model.

Annotation		
Name	Type (Shape)	Comment
<i>Key</i>		
annotationId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
time	ArrayTime	mid point of the interval of time on which the recorded information is pertinent.
issue	string	name of this annotation.
details	string	details of this annotation.
<i>Optional Data</i>		
numAntenna ( $N_{Ante}$ )	int	number of antennas.
basebandName	BasebandName [numBaseband]	an array of numBaseband baseband names.
numBaseband ( $N_{Base}$ )	int	number of basebands.
interval	Interval	time interval
dValue	double	scalar data.
vdValue	double []	useful to store an array of double values.
vvdValues	double [] []	useful to store an array of array(s) of double values.
llValue	int64_t	useful to record a long long data.
vllValue	int64_t []	useful to store an array of array(s) of long long values.
vvllValue	int64_t [] []	useful to store an array of array(s) long long values.
antennaId	Tag [numAntenna]	refers to a collection of rows in the AntennaTable.

#### Column Descriptions:

annotationId : Annotation Table identifier.

time : The midpoint of the time interval the data in this row are referring to. This is for documentation purposes only.

issue : A short (preferably 1-word) string that identifies the type of annotation.

details : Details of this entry: this should explain the motivation, the dimensionality and contents of the generic columns: dValue, llValue, vdValue, vllValue, vvdValues, vvllValue.

numAntenna : The number of antennas to which the data refer.

basebandName : The basebands that the baseband-based data in this table refer to.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 12

**numBaseband** : The number of basebands to which the data refer.

**interval** : Time interval during which the recorded information is pertinent.

**dValue** : space for a scalar floating-point number.

**vdValue** : space for a 1-dimensional array of floating-point data; shape must be made explicit in **details**.

**vvdValues** : space for a 2-dimensional array of floating-point data; shape must be made explicit in **details**.

**llValue** : space for a scalar integer.

**vllValue** : space for a 1-dimensional array of integer data; shape must be made explicit in **details**.

**vvllValue** : space for a 2-dimensional array of integer data; shape must be made explicit in **details**.

**antennaId** : Antenna Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 13

### 1.5 Antenna Table

Antenna characteristics.

Antenna		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>antennaId</b>	Tag	identifies a unique row in the table.
<i>Required Data</i>		
<b>name</b>	string	the antenna's name.
<b>antennaMake</b>	AntennaMake	the antenna's make.
<b>antennaType</b>	AntennaType	the antenna's type.
<b>dishDiameter</b>	Length	the diameter of the main reflector.
<b>position</b>	Length [3]	the antenna's position.
<b>offset</b>	Length [3]	the position's offset.
<b>time</b>	ArrayTime	the time of position's measurement.
<b>stationId</b>	Tag	refers to the station where this antenna is located (i.e. one row in the Station table).
<i>Optional Data</i>		
<b>assocAntennaId</b>	Tag	refers to an associate antenna (i.e. one row in the Antenna table).

#### Column Descriptions:

**antennaId** : Identifies the row in the Antenna Table.

**name** : Provides a unique string identification for the antenna hardware. *Examples:* DV01 or DA41 for ALMA antenna prototypes

**antennaMake** : Identifies the antenna manufacturer. Antennas with same optical design may have subtle differences if built according to different designs.

**antennaType** : Generic antenna type; e.g. radio antennas are either for ground use or space use.

**dishDiameter** : The diameter of the main reflector (or the largest dimension for non-circular apertures).

**position** : The position of the antenna pedestal reference point, relative to the station reference point, measured in the horizon system at the station position. The antenna pedestal reference point is on the elevation axis, nominally at the same height as the station reference point (ground level), so that the antenna position should be always close to zero if the antenna is well positioned on the station. This is the quantity that has to be re-measured whenever the antenna is moved to a new station.

**offset** : The position of the antenna phase reference point in the Yoke, relative to the antenna pedestal reference point. This is an antenna characteristic that should be unchanged when the antenna is moved to a new station.

- The X component is horizontal along the elevation axis and has no effect of the interferometer phase; it can be set arbitrarily to zero.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 14

- The  $Y$  component is horizontal and perpendicular to the elevation axis; it produces an elevation dependent interferometer phase term and has to be accurately calibrated.
- The  $Z$  component is vertical and can be kept equal to the nominal height of the elevation axis above ground for the antenna's mount. Small variations from the nominal value have the same phase effect as the  $Z$  component of `position`, so they can be ignored.

`YOKEAntenna.position` - The YOKE reference system is defined in ALMA-80.05.00.00-009-B-SPE document; not known in Measures (CASA)

- Note - The relevant distance between axes is in the  $y$  coordinate, not  $x$ ...

`time` : Gives the time at which the positions were measured.

`stationId` : enter tag descr. here

`assocAntennaId` : Identifies an associated antenna in the Table. This can refer to the same antenna with a position measured at a different time.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 15

### 1.6 CalAmpli Table

Amplitude Calibration Result from Telescope Calibration. This calibration checks that observing amplitude calibrators provide reasonable results: From the antenna-based fringe amplitudes rough aperture efficiencies are determined.

CalAmpli		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the antenna's name.
atmPhaseCorrection	AtmPhaseCorrection	qualifies how the atmospheric phase correction has been applied.
receiverBand	ReceiverBand	the name of the receiver band.
basebandName	BasebandName	The name of the 'baseband pair' which is measured. For ALMA a baseband pair is the signal path identified by a second local oscillator and has two polarizations. BB ALL may be used if all basebands are fitted together.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
polarizationTypes	PolarizationType [numReceptor]	the polarizations of the receptors (an array containing one value per receptor).
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
frequencyRange	Frequency [2]	the frequency range over which the result is valid.
apertureEfficiency	float [numReceptor]	the aperture efficiency without correction.
apertureEfficiencyError	float [numReceptor]	the aperture efficiency error.
<i>Optional Data</i>		
correctionValidity	bool	the correction validity.

#### Column Descriptions:

antennaName : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

atmPhaseCorrection : the atmospheric phase corrections states for which result is given.

receiverBand : The name of the front-end frequency band being used.

basebandName : **long doc missing**

calDataId : CalData Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 16

`calReductionId` : CalReduction Table identifier.

`numReceptor` : The number or polarization receptors (one or two) for which the result is given.

`polarizationTypes` : The polarization types of the receptors being used.

`startValidTime` : The start of the time validity range for the result.

`endValidTime` : The end of the time validity range for the result.

`frequencyRange` : Frequency range over which the result is valid TOPO

`apertureEfficiency` : Antenna aperture efficiency with and/or without phase correction.

`apertureEfficiencyError` : Error on aperture efficiency measurement.

`correctionValidity` : Deduced validity of atmospheric path length correction (from Water Vapour Radiometers).





## SDM Tables Short Description

Doc#: COMP-70.75.00.00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 17

### 1.7 CalAntennaSolutions Table

Results of atmosphere calibration by TelCal. This calibration determines the system temperatures corrected for atmospheric absorption. Ionospheric effects are not dealt with in the Table.

CalAntennaSolutions		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
atmPhaseCorrection	AtmPhaseCorrection	describes how the atmospheric phase correction has been applied.
receiverBand	ReceiverBand	identifies the receiver band.
basebandName	BasebandName	identifies the baseband.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
refAntennaName	string	the name of the antenna used as a reference to get the antenna-based phases.
direction	Angle [2]	the direction of the source.
frequencyRange	Frequency [2]	the frequency range.
integrationTime	Interval	the integration duration for a data point.
polarizationTypes	PolarizationType [numReceptor]	the polarizations of the receptors (an array with one value per receptor).
correctionValidity	bool	the deduced validity of atmospheric path length correction (from water vapor radiometers).
phaseAnt	float [numReceptor]	the antenna based phase solution averaged over the scan (one value per receptor per antenna). See refAntennaName for the association of the values of this array with the antennas.
phaseAntRMS	float [numReceptor]	the RMS of the phase fluctuations relative to the antenna based average phase (one value per receptor per antenna). See refAntennaName for the association of the values of this array with the antennas.
amplitudeAnt	float [numReceptor]	the antenna based amplitude solution averaged over the scan (one value per receptor per antenna). See refAntennaName for the association of the values of this array with the antennas.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 18

CalAntennaSolutions – continued from previous page		
Name	Type (Shape)	Comment
amplitudeAntRMS	float [numReceptor]	the antenna based amplitude solution averaged over the scan (one value per receptor per antenna). See refAntennaName for the association of the values of this array with the antennas.

### Column Descriptions:

**antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**atmPhaseCorrection** : The atmospheric phase corrections states for which result is given.

**receiverBand** : The name of the front-end frequency band being used.

**basebandName** : long doc missing

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**numReceptor** : The number or polarization receptors (one or two) for which the result is given.

**refAntennaName** : long doc missing

**direction** : The antenna pointing direction in horizontal coordinates. AZELNOWAntenna.position

**frequencyRange** : Frequency range over which the result is valid TOPO

**integrationTime** : Integration time on a data point, to calculate rms.

**polarizationTypes** : The polarization types of the receptors being used.

**correctionValidity** : Deduced validity of atmospheric path length correction (from Water Vapour Radiometers; remark: It is not clear that correctionValidity is really an array. What about its size?).

**phaseAnt** : long doc missing

**phaseAntRMS** : long doc missing

**amplitudeAnt** : long doc missing

**amplitudeAntRMS** : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 19

### 1.8 CalAppPhase Table

The CalAppPhase table is relevant to the ALMA observatory when the antennas are being phased to form a coherent sum during the observation. For each scan, the table provides information about which antennas are included in the sum, their relative phase adjustments, the efficiency of the sum (relative to best performance) and the quality of each antenna participating in the system. This data is used in real-time to provide the phased sum signal, and after the observation to analyze the result.

CalAppPhase		
Name	Type (Shape)	Comment
<i>Key</i>		
basebandName	BasebandName	identifies the baseband.
scanNumber	int	The number of the scan processed by TELCAL. Along with an ExecBlock Id (which should be ExecBlock_0 most of the time), the value of scanNumber can be used as the key to retrieve informations related to the scan (e.g. its start time).
calDataId	Tag	identifies a unique row in the CalData table.
calReductionId	Tag	identifies a unique row in the CalReduction table.
<i>Required Data</i>		
startValidTime	ArrayTime	start of phasing solution validity.
endValidTime	ArrayTime	end of phasing solution validity.
adjustTime	ArrayTime	The time of the last adjustment to the phasing analysis via the ParameterTuning interface.
adjustToken	string	A parameter supplied via the ParameterTuning interface to indicate the form of adjustment(s) made at adjustTime. Note that TELCAL merely passes this datum and adjustTime through to this table.
phasingMode	string	The mode in which the phasing system is being operated.
numPhasedAntennas ( $N_p$ )	int	the number of antennas in phased sum, $N_p$ .
phasedAntennas	string [numPhasedAntennas]	the names of the phased antennas.
refAntennaIndex	int	the index of the reference antenna in the array phasedAntennas. It must be an integer value in the interval $[0, N_p - 1]$ .



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 20

CalAppPhase – continued from previous page		
Name	Type (Shape)	Comment
candRefAntennaIndex	int	the index of a candidate (new) reference antenna in the array phasedAntennas; it must be a integer in the interval $[0, N_p - 1]$ .
phasePacking	string	how to unpack phaseValues.
numReceptors ( $N_r$ )	int	the number of receptors per antenna, $N_r$ . The number ( $N_r \leq 2$ ) of receptors per antenna, usually two (polarizations), but it might be one in special cases.
numChannels ( $N_d$ )	int	the number of data channels, $N_d$ .
numPhaseValues ( $N_v$ )	int	The number of phase data values present in the table, $N_v$ .
phaseValues	float [numPhaseValues]	the array of phase data values.
numCompare ( $N_c$ )	int	the number of comparison antennas, $N_c$ .
numEfficiencies ( $N_e$ )	int	the number of efficiencies, $N_e$ .
compareArray	string [numCompare]	the names of the comparison antennas.
efficiencyIndices	int [numEfficiencies]	indices of the antenna(s) in compareArray used to calculate efficiencies; they must be distinct integers in the interval $[0, N_c]$ .
efficiencies	float [numEfficiencies] [numChannels]	an array of efficiencies of phased sum.
quality	float [numPhasedAntennas+numCompare]	quality of phased antennas.
phasedSumAntenna	string	the name of the phased sum antenna.
<i>Optional Data</i>		
typeSupports	string	encoding of supporting data values.
numSupports ( $N_s$ )	int	the number of supporting data values, $N_s$ .
phaseSupports	float [numSupports]	an array of supporting data values.

### Column Descriptions:

**basebandName** : identifies the baseband.

**scanNumber** : The number of the scan processed by TELCAL. Along with an ExecBlock Id (which should be ExecBlock.0 most of the time), the value of scanNumber can be used as the key to retrieve informations related to the scan (e.g. its start time).

**calDataId** : identifies a unique row in the CalData table.

**calReductionId** : identifies a unique row in the CalReduction table.

**startValidTime** : The start of the interval in which the phase solution was calculated. Normally the first few seconds of each scan include data before the previous slow phasing solution can be applied, so the valid interval corresponds to the last phasing correction.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 21

- endValidTime** : The end of the interval in which the phase solution was calculated. Note that  $startTime < startValidTime < endValidTime \leq endTime$ .
- adjustTime** : Usually, this is the timestamp of the commanding of the last slow phasing correction. However, other adjustments might also have been made (e.g. phasedArray membership changed in the correlator hardware).
- adjustToken** : A parameter supplied via the ParameterTuning interface to indicate the form of adjustment(s) made at adjustTime . Note that TELCAL merely passes this datum and adjustTime through to this table.
- phasingMode** : The mode in which the phasing system is being operated.
- numPhasedAntennas** : The number of antennas included in the phased sum.
- phasedAntennas** : The names of the  $N_p$  antennas contributing to the phased sum.
- refAntennaIndex** : the index of the reference antenna in the array phasedAntennas. It must be an integer value in the array phasedAntennas.
- candRefAntennaIndex** : TELCAL may recommend the adoption of a candidate (new) refAntenna with this entry (index in phasedAntennas ). This recommendation is always available (in case the current reference antenna becomes unsuitable for some reason), but the VOM is not obliged to adopt the recommendation. It must be an integer in the interval  $[0, N_p - 1]$ .
- phasePacking** : Indicates one of several possibilities for converting the phase data into TFB commands.
- numReceptors** : the number of receptors per antenna,  $N_r$ . The number ( $N_r \leq 2$ ) of receptors per antenna usually two (polarizations), but it might be one in special cases.
- numChannels** : The number of data channels for which efficiency data is presented,  $N_d$ .
- numPhaseValues** : The number of phase data values present in the table,  $N_v$ .
- phaseValues** : An array containing the  $N_v$  phase data values.
- numCompare** : The number of antennas not included in the phased sum,  $N_c$ .
- numEfficiencies** : The number  $N_e$  of antennas in the array compareArray used to calculate efficiencies.
- compareArray** : The names of the antennas not in the phased sum, which could be used as comparison antenna. The array of available antennas (to the observation) has  $(N_p + 1 + N_c)$  members;  $N_p$  are in the phase-sum, one is the phased-sum, and  $N_c$  are not.
- efficiencyIndices** : A list of  $N_e$  indices in compareArray for which efficiencies are calculated. The first index in the list refers to the nominal comparison antenna, the second index refers to a candidate replacement (should the first become unusable), and others may be listed.
- efficiencies** : An array of normalized efficiencies for the phased sum for each data channel. Those for the compareAntenna are to be used for decisions; the other values are advisory. The efficiencies are provided per channel for each antenna of compareArray mentioned in the list efficiencyIndices .
- quality** : A normalized figure of merit ( $0.0 \leq q \leq 1.0$ ) expressing the quality of the solution for every antenna.
- phasedSumAntenna** : The name of the antenna whose data is discarded in favor of the phased sum. The antenna is also known as cai63Antenna . The efficiency is calculated through the correlation of this antenna with antennas referenced by efficiencyIndices.
- typeSupports** : An indicator of which supporting data is being provided.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 22

**numSupports** : The number of supporting data values present,  $N_s$ .

**phaseSupports** : An array of  $N_s$  supporting data values. The presence and use of this array is unspecified; but might include channel average frequencies or supplementary quality data as an assist in the implementation. (Indeed, there is a long list of such items that TelCal could compute.)



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 23

### 1.9 CalAtmosphere Table

Results of atmosphere calibration by TelCal. This calibration determines the system temperatures corrected for atmospheric absorption. Ionospheric effects are not dealt with in the Table.

CalAtmosphere		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
receiverBand	ReceiverBand	identifies the receiver band.
basebandName	BasebandName	identifies the baseband.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
numFreq ( $N_{Freq}$ )	int	the number of frequency points.
numLoad ( $N_{Load}$ )	int	the number of loads.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
forwardEffSpectrum	float [numReceptor] [numFreq]	the spectra of forward efficiencies (one value per receptor, per frequency).
frequencyRange	Frequency [2]	the frequency range.
groundPressure	Pressure	the ground pressure.
groundRelHumidity	Humidity	the ground relative humidity.
frequencySpectrum	Frequency [numFreq]	the frequencies.
groundTemperature	Temperature	the ground temperature.
polarizationTypes	PolarizationType [numReceptor]	the polarizations of the receptors (an array with one value per receptor).
powerSkySpectrum	float [numReceptor] [numFreq]	the powers on the sky (one value per receptor per frequency).
powerLoadSpectrum	float [numLoad] [numReceptor] [numFreq]	the powers on the loads (one value per load per receptor per frequency).
syscalType	SyscalMethod	the type of calibration used.
tAtmSpectrum	Temperature [numReceptor] [numFreq]	the spectra of atmosphere physical temperatures (one value per receptor per frequency).
tRecSpectrum	Temperature [numReceptor] [numFreq]	the spectra of the receptors temperatures (one value per receptor per frequency).
tSysSpectrum	Temperature [numReceptor] [numFreq]	the spectra of system temperatures (one value per receptor per frequency).
tauSpectrum	float [numReceptor] [numFreq]	the spectra of atmospheric optical depths (one value per receptor per frequency).
tAtm	Temperature [numReceptor]	the atmosphere physical temperatures (one value per receptor).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 24

CalAtmosphere – continued from previous page		
Name	Type (Shape)	Comment
tRec	Temperature [numReceptor]	the receptors temperatures (one value per receptor).
tSys	Temperature [numReceptor]	the system temperatures (one value per receptor).
tau	float [numReceptor]	the atmospheric optical depths (one value per receptor).
water	Length [numReceptor]	the water vapor path lengths (one value per receptor).
waterError	Length [numReceptor]	the uncertainties of water vapor contents (one value per receptor).
<i>Optional Data</i>		
alphaSpectrum	float [numReceptor] [numFreq]	the alpha coefficients, two loads only (one value per receptor per frequency).
forwardEfficiency	float [numReceptor]	the forward efficiencies (one value per receptor).
forwardEfficiencyError	double [numReceptor]	the uncertainties on forwardEfficiency (one value per receptor).
sbGain	float [numReceptor]	the relative gains of LO1 sideband (one value per receptor).
sbGainError	float [numReceptor]	the uncertainties on the relative gains of LO1 sideband (one value per receptor).
sbGainSpectrum	float [numReceptor] [numFreq]	the spectra of relative sideband gains (one value per receptor per frequency).

### Column Descriptions:

antennaName : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

receiverBand : The name of the front-end frequency band being used.

basebandName : **long doc missing**

calDataId : CalData Table identifier.

calReductionId : CalReduction Table identifier.

startValidTime : The start of the time validity range for the result.

endValidTime : The end of the time validity range for the result.

numFreq : Number of frequency points for which the results are given.

numLoad :  $N_{Load}$  Number of loads used in calibration.

numReceptor : The number or polarization receptors (one or two) for which the result is given.

forwardEffSpectrum : The value of the forward efficiency for each frequency point.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 25

**frequencyRange** : Frequency range over which the result is valid TOPO

**groundPressure** : The atmospheric pressure at the altitude of the observatory.

**groundRelHumidity** : The relative atmospheric humidity (%) at the altitude of the observatory.

**frequencySpectrum** : The frequency values for which the results are given.

**groundTemperature** : The ambient temperature at the observatory.

**polarizationTypes** : The polarization types of the receptors being used.

**powerSkySpectrum** : Observed power on sky.

**powerLoadSpectrum** : Observed power on loads.

**syscalType** : The type of calibration used: a single-direction measurement, or a series of measurements at different elevations ('SkyDip')

**tAtmSpectrum** : The value of atmosphere physical temperature for each frequency point.

**tRecSpectrum** : The value of the receiver temperature for each frequency point.

**tSysSpectrum** : The value of the system temperature for each frequency point.

**tauSpectrum** : The value of the optical depth for each frequency point.

**tAtm** : The physical temperature of the atmosphere absorbing layers.

**tRec** : The receiver noise temperature (the reference plane is at the level where the calibration loads are inserted in the signal path).

**tSys** : The system temperature (corrected for atmospheric absorption and antenna losses).

**tau** : The optical depth of the atmosphere along the line of sight.

**water** : The amount of precipitable water vapour in the atmosphere.

**waterError** : The uncertainty of the amount of precipitable water vapour in the atmosphere.

**alphaSpectrum** : alpha coefficient (two-load only); see *Amplitude Calibration steps* memo.

**forwardEfficiency** : This is the coupling factor to the sky, that is the fraction of the antenna beam that sees the emission from the atmosphere.

**forwardEfficiencyError** : The uncertainty of **forwardEfficiency**

**sbGain** : The relative gain of the side band. This is the ratio of the gain in the first LO sideband used to obtain the **frequencyRange** relative to the total (dual-sideband) gain.

**sbGainError** : Uncertainty on **sbGain**.

**sbGainSpectrum** : The value of the relative side band gain for each spectral point. Optional for EVLA, mandatory for ALMA.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 26

### 1.10 CalBandpass Table

Result of passband calibration performed on-line by TelCal.

CalBandpass		
Name	Type (Shape)	Comment
<i>Key</i>		
basebandName	BasebandName	identifies the baseband.
sideband	NetSideband	identifies the first LO sideband.
atmPhaseCorrection	AtmPhaseCorrection	qualifies how the atmospheric phase correction has been applied.
typeCurve	CalCurveType	identifies the type of curve.
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
numAntenna ( $N_{Ante}$ )	int	the number of antennas.
numPoly ( $N_{Poly}$ )	int	the number of coefficients of the polynomial.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
antennaNames	string [numAntenna]	the names of the antennas.
refAntennaName	string	the name of the reference antenna.
freqLimits	Frequency [2]	the frequency range for the polynomial description of the passband.
polarizationTypes	PolarizationType [numReceptor]	the polarizations of the receptors (one value per receptor).
curve	float [numAntenna] [numReceptor] [numPoly]	the amplitude or phase coefficients, depending on the value of typeCurve (one array of numPoly values per antenna per receptor).
reducedChiSquared	double [numReceptor]	measures the quality of the least squares fits (one value per receptor).
<i>Optional Data</i>		
numBaseline ( $N_{Base}$ )	int	the number of baselines.
numFreq ( $N_{Freq}$ )	int	the number of frequency points.
rms	float [numReceptor] [numBaseline]	the amplitude or phase residuals ( one array of numBaseline values per receptor).
frequencyRange	Frequency [2]	the frequency range over which the result is valid.
numSpectralWindow ( $N_{Spec}$ )	int	The number of spectral windows.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 27

CalBandpass – continued from previous page		
Name	Type (Shape)	Comment
chanFreqStart	Frequency [numSpectralWindow]	the frequency of the first channel.
chanFreqStep	Frequency [numSpectralWindow]	the increment between two successive frequencies.
numSpectralWindowChan ( $N_{Spec}$ )	int [numSpectralWindow]	The number of channels for each spectral window.
spectrum	float [numAntenna] [numReceptor] [numFreq]	The antenna-based spectrum per receptor averaging over the entire scan range.

### Column Descriptions:

**basebandName** : The name of the 'baseband pair' which is measured. For ALMA a baseband pair is the signal path identified by a second local oscillator and has two polarizations. **BB\_ALL** may be used if all basebands are fitted together.

**sideband** : First LO Sideband: For sideband-separated spectra one must use different bandpasses for each individual sideband.

**atmPhaseCorrection** : the atmospheric phase corrections states for which result is given.

**typeCurve** : Defines the quantity which is fitted: amplitude or phase.

**receiverBand** : The name of the front-end frequency band being used.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**numAntenna** : Number of antennas for which the result is valid.

**numPoly** : Number of polynomial coefficients.

**numReceptor** : The number or polarization receptors (one or two) for which the result is given.

**antennaNames** : Refer uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**refAntennaName** : The name of the antenna used as reference to get the antenna-based phases.

**freqLimits** : The frequency limits for the polynomial description of the passband. This frequency interval is reduced to the (-1, 1) interval over which the Chebychev polynomials are defined.

**polarizationTypes** : The polarization types of the receptors being used.

**curve** : The amplitude or phase coefficients.

**reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit. This is a single number for each polarization as the baselines are to be fitted consistently.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 28

`numBaseline` : Number of baselines for which the result is given  
`numFreq` : Number of frequency points for which the results are given.  
`rms` : The rms of the amplitude/phase residuals for each baseline/polarisation.  
`frequencyRange` : Frequency range over which the result is valid TOPO  
`numSpectralWindow` : long doc missing  
`chanFreqStart` : long doc missing  
`chanFreqStep` : long doc missing  
`numSpectralWindowChan` : long doc missing  
`spectrum` : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 29

### 1.11 CalCurve Table

Result of time-dependent calibration performed on-line by TelCal

CalCurve		
Name	Type (Shape)	Comment
<i>Key</i>		
atmPhaseCorrection	AtmPhaseCorrection	qualifies how the atmospheric phase correction has been applied.
typeCurve	CalCurveType	identifies the type of curve.
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
frequencyRange	Frequency [2]	the range of frequencies over which the result is valid.
numAntenna ( $N_{Ante}$ )	int	the number of antennas.
numPoly ( $N_{Poly}$ )	int	the number of coefficients of the polynomials.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
antennaNames	string [numAntenna]	the names of the antennas.
refAntennaName	string	the name of the reference antenna.
polarizationTypes	PolarizationType [numReceptor]	identifies the polarizations of the receptors (one value per receptor).
curve	float [numAntenna] [numReceptor] [numPoly]	the coefficients of the polynomials (one array of numPoly coefficients per receptor per antenna).
reducedChiSquared	double [numReceptor]	measures the quality of the least squares fits (one value per receptor).
<i>Optional Data</i>		
numBaseline ( $N_{Base}$ )	int	the number of baselines.
rms	float [numReceptor] [numBaseline]	the amplitude or phase residuals (one array of numBaselines values per receptor).

#### Column Descriptions:

atmPhaseCorrection : the atmospheric phase correction state for which result is given.

typeCurve : Defines the quantity which is fitted: amplitude or phase.

receiverBand : The name of the front-end frequency band being used.

calDataId : CalData Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 30

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**frequencyRange** : Frequency range over which the result is valid. TOPO

**numAntenna** : Number of antennas for which the result is valid.

**numPoly** : The number of coefficients in the Chebichev polynomials used to fit the data.

**numReceptor** : The number or polarization receptors (one or two) for which the result is given.

**antennaNames** : Refer uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**refAntennaName** : The name of the antenna used as reference to get the antenna-based phases.

**polarizationTypes** : The polarization types of the receptors being used.

**curve** : These are Chebichev polynomial coefficients. The interval between **startValidTime** and **endValidTime** is reduced to the  $-1, 1$  interval over which the Chebychev coefficients are defined. For interferometer amplitude, data is expressed in terms of correlation coefficient; for interferomete phase, coefficients are given in radians.

**reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit.

**numBaseline** : Number of baselines ffor which the result is given.

**rms** : The root means square deviations of fit residuals.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 31

### 1.12 CalData Table

This table describes the data used to derive the calibration results.

CalData		
Name	Type (Shape)	Comment
<i>Key</i>		
calDataId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
startTimeObserved	ArrayTime	the start time of observation.
endTimeObserved	ArrayTime	the end time of observation.
execBlockUID	EntityRef	the UID of the Execution Block.
calDataType	CalDataOrigin	identifies the origin of the data used for the calibration.
calType	CalType	identifies the type of performed calibration.
numScan ( $N_{Scan}$ )	int	the number of scans (in this Execution Block).
scanSet	int [numScan]	the set of scan numbers.
<i>Optional Data</i>		
assocCalDataId	Tag	refers to an associate row in CalDataTable.
assocCalNature	AssociatedCalNature	identifies the nature of the relation with the associate row in CalDataTable.
fieldName	string [numScan]	the names of the fields (one name per scan).
sourceName	string [numScan]	the names of the sources as given during observations (one source name per scan).
sourceCode	string [numScan]	the special characteristics of sources expressed in a textual form (one string per scan).
scanIntent	ScanIntent [numScan]	identifies the intents of the scans (one value per scan).

#### Column Descriptions:

calDataId : Row identifier.

startTimeObserved : The start time of the data set used.

endTimeObserved : The end time of the data set used.

execBlockUID : Archive UID of the ExecBlock.

calDataType : The origin of the data used: Correlator (full resolution or channel averaged data), Total power detectors, WVR receivers, etc. This information is added as e.g. a pointing scan may have been reduced using either total power or interferometry, or the atmosphere may be calibrated using autocorrelations or total power detectors.

calType : This enumerated item tells in which calibration table the results is.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 32

**numScan** : The number of scans in the scan set used.

**scanSet** : The list of scan numbers in the set of scans used.

**assocCalDataId** : This is used to chain data sets obtained in different ExecBlocks, for which scan numbers are re-used.

**assocCalNature** : Nature of the association established by **assocCalDataId**. Normally this is used to refer to data in different execution blocks, for which scan numbers may be re-used.

**fieldName** : The name of the field the array was aimed at.

**sourceName** : Names of the sources as given during observations.

**sourceCode** : Special characteristics of source, e.g. passband calibrator, phase calibrator, flux calibrator.

**scanIntent** : The list of the intents associated with each scan in the data set.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 33

### 1.13 CalDelay Table

Result of delay offset calibration performed on-line by TelCal. This calibration determines the delay offsets to be added in the correlator to compensate for residual cable delays. Delays are entered in seconds but represented as double precision floating point numbers.

CalDelay		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
atmPhaseCorrection	AtmPhaseCorrection	qualifies how the atmospheric phase correction has been applied.
basebandName	BasebandName	Name of the Baseband
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of the result validity period.
endValidTime	ArrayTime	the end time of the result validity period.
refAntennaName	string	the name of the reference antenna.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
delayError	double [numReceptor]	the uncertainties on the measured delay offsets (one value per receptor).
delayOffset	double [numReceptor]	the measured delay offsets (one value per receptor).
polarizationTypes	PolarizationType [numReceptor]	identifies the polarizations of the receptors (one value per receptor).
reducedChiSquared	double [numReceptor]	measure of the quality of the fit (one value per receptor).
appliedDelay	double [numReceptor]	the delay that was applied (one value per receptor).
<i>Optional Data</i>		
crossDelayOffset	double	the measured cross delay offset (reference antenna only).
crossDelayOffsetError	double	the uncertainty for the cross delay offset.
numSideband ( $N_{Side}$ )	int	the number of sideband.
refFreq	Frequency [numSideband]	the reference frequencies (one value per sideband).
refFreqPhase	Angle [numSideband]	the phases at reference frequencies (one value per sideband).
sidebands	ReceiverSideband [numSideband]	identifies the receiver's sidebands (one value per sideband).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 34

### Column Descriptions:

- antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.
- atmPhaseCorrection** : The atmospheric phase corrections states for which result is given.
- basebandName** : The name of the 'baseband pair' which is measured. For ALMA a baseband pair is the signal path identified by a second local oscillator and has two polarizations. **BB\_ALL** may be used if all basebands are fitted together.
- receiverBand** : The name of the front-end frequency band being used.
- calDataId** : CalData Table identifier.
- calReductionId** : CalReduction Table identifier.
- startValidTime** : The start of the time validity range for the result.
- endValidTime** : The end of the time validity range for the result.
- refAntennaName** : The name of the antenna used as reference to get the antenna-based phases.
- numReceptor** : The number or polarization receptors (one or two) for which the result is given.
- delayError** : The statistical uncertainty on the delay offset found by TelCal for the specified antenna, receiver band, and baseband.
- delayOffset** : The delay offset found by TelCal for the specified antenna, receiver band, and baseband.
- polarizationTypes** : The nominal polarization types of the receptors being used.
- reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit.
- appliedDelay** : **long doc missing**
- crossDelayOffset** : The cross-polarization delay offset found by TelCal for the specified receiver band, and baseband . Note : this must be the same for all antennas; this is the delay to be added to Y signals relative to X signals to get a flat frequency dependence of phases for a polarized point source.
- crossDelayOffsetError** : The uncertainty on the cross-polarization delay offset found by TelCal for the specified receiver band, and baseband.
- numSideband** :  $N_{Side}$  Number of Sidebands: in the side-band separated case, data from both sidebands are available for a given baseband. The delay offset should be the same for both sidebands, but the phase in **refFreqPhase** should be sideband-dependent.
- refFreq** : A reference frequency within the band.
- refFreqPhase** : Phase fitted at the frequency **refFreq**.
- sidebands** : Receiver side bands of the reference frequencies given in **refFreq**.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 35

### 1.14 CalDevice Table

Calibration device characteristics. This table is not part of the Calibration Data Model but describes the actual observations; it refers to the amplitude calibration device which includes the hot loads. Calibration device properties are assumed independent of frequency throughout a spectral window.

CalDevice		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindow Table.
timeInterval	ArrayTimeInterval	the period of validity of the data recorded in this row.
feedId	int	refers to the collection of rows in FeedTable having this value of feedId in their key.
<i>Required Data</i>		
numCalload ( $N_{Call}$ )	int	the number of calibration loads.
calLoadNames	CalibrationDevice [numCalload]	identifies the calibration loads (an array with one value per load).
<i>Optional Data</i>		
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
calEff	float [numReceptor] [numCalload]	the calibration efficiencies (one value per receptor per load).
noiseCal	double [numCalload]	the equivalent temperatures of the of the noise sources used (one value per load).
coupledNoiseCal	float [numReceptor] [numCalload]	<b>doc missing</b>
temperatureLoad	Temperature [numCalload]	the physical temperatures of the loads for a black body calibration source (one value per load).

#### Column Descriptions:

antennaId : Antenna Table identifier.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Validity time interval for the data in the row.

feedId : Specifies which feed was used in the Feed Table.

numCalload : The number of calibration loads for which data are given.

calLoadNames : The names of the calibration loads for which data are provided.

numReceptor : The number of receptors.

calEff : The coupling factor of the calibration source to the receiver beam.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 36

`noiseCal` : The equivalent temperature of the noise source used.

`coupledNoiseCal` : `missing`

`temperatureLoad` : The physical temperature of the load (for a black-body calibration source).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 37

### 1.15 CalFlux Table

Result of flux calibration performed on-line by TelCal. Atmospheric absorption is corrected for. No ionosphere correction has been applied.

CalFlux		
Name	Type (Shape)	Comment
<i>Key</i>		
sourceName	string	the name of the source.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
numFrequencyRanges ( $N_{Freq}$ )	int	the number of frequency ranges.
numStokes ( $N_{Stok}$ )	int	the number of Stokes parameters.
frequencyRanges	Frequency [numFrequencyRanges] [2]	the frequency ranges (one pair of values per range).
fluxMethod	FluxCalibrationMethod	identifies the flux determination method.
flux	double [numStokes] [numFrequencyRanges]	the flux densities (one value par Stokes parameter per frequency range) expressed in Jansky (Jy).
fluxError	double [numStokes] [numFrequencyRanges]	the uncertainties on the flux densities (one value per Stokes parameter per frequency range).
stokes	StokesParameter [numStokes]	the Stokes parameter.
<i>Optional Data</i>		
direction	Angle [2]	the direction of the source.
directionCode	DirectionReferenceCode	identifies the reference frame of the source's direction.
directionEquinox	Angle	equinox associated with the reference frame of the source's direction.
PA	Angle [numStokes] [numFrequencyRanges]	the position's angles for the source model (one value per Stokes parameter per frequency range).
PAError	Angle [numStokes] [numFrequencyRanges]	the uncertainties on the position's angles (one value per Stokes parameter per frequency range).
size	Angle [numStokes] [numFrequencyRanges] [2]	the sizes of the source (one pair of angles per Stokes parameter per frequency range).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 38

CalFlux – continued from previous page		
Name	Type (Shape)	Comment
sizeError	Angle [numStokes] [numFrequencyRanges] [2]	the uncertainties of the sizes of the source (one pair of angles per Stokes parameter per frequency range).
sourceModel	SourceModel	identifies the source model.

### Column Descriptions:

**sourceName** : The name of the source for which flux density information was derived.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReductionTable identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**numFrequencyRanges** : The number of frequency ranges for which flux density information was derived

**numStokes** : The number of Stokes parameters which were measured for this source.

**frequencyRanges** : Frequency ranges over which the result is valid. TOPO

**fluxMethod** : The method which was used to derive flux densities.

**flux** : The derived flux density values expressed in Jansky (Jy).

**fluxError** : The statistical uncertainties of the flux densities which were derived.

**stokes** : The names of the Stokes parameters which were derived.

**direction** : The reference code for **direction**, if not J2000.

**directionCode** : The direction to the source in celestial coordinates.

**directionEquinox** : The reference equinox for **direction**, if required by **directionCode**

**PA** : Position angle for source model.

**PAError** : Uncertainty on position angle for source model.

**size** : Half power sizes of source (main axes of ellipse).

**sizeError** : Uncertainties on half power size of source (main axes of ellipse)

**sourceModel** : Model used for source, e.g., point-like or Gaussian.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 39

### 1.16 CalFocus Table

Result of focus calibration performed on-line by TelCal.

CalFocus		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of the result validity period.
endValidTime	ArrayTime	the end time of the result validity period.
ambientTemperature	Temperature	the ambient temperature.
atmPhaseCorrection	AtmPhaseCorrection	qualifies how the atmospheric phase correction has been applied.
focusMethod	FocusMethod	identifies the method used during the calibration.
frequencyRange	Frequency [2]	the frequency range over which the result is valid.
pointingDirection	Angle [2]	the antenna pointing direction (horizontal coordinates).
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
polarizationTypes	PolarizationType [numReceptor]	identifies the polarization types (one value per receptor).
wereFixed	bool [3]	coordinates were fixed (true) or not fixed (false) (one value per individual coordinate).
offset	Length [numReceptor] [3]	the measured focus offsets in X,Y,Z (one triple of values per receptor).
offsetError	Length [numReceptor] [3]	the statistical uncertainties on measured focus offsets (one triple per receptor).
offsetWasTied	bool [numReceptor] [3]	focus was tied (true) or not tied (false) (one value per receptor and focus individual coordinate).
reducedChiSquared	double [numReceptor] [3]	a measure of the quality of the fit (one triple per receptor).
position	Length [numReceptor] [3]	the absolute focus position in X,Y,Z (one triple of values per receptor).
<i>Optional Data</i>		
polarizationsAveraged	bool	Polarizations were averaged.
focusCurveWidth	Length [numReceptor] [3]	half power width of fitted focus curve (one triple per receptor).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 40

CalFocus – continued from previous page		
Name	Type (Shape)	Comment
focusCurveWidthError	Length [numReceptor] [3]	Uncertainty of the focus curve width.
focusCurveWasFixed	bool [3]	each coordinate of the focus curve width was set (true) or not set (false) to an assumed value.
offIntensity	Temperature [numReceptor]	the off intensity levels (one value per receptor).
offIntensityError	Temperature [numReceptor]	the uncertainties on the off intensity levels (one value per receptor).
offIntensityWasFixed	bool	the off intensity level was fixed (true) or not fixed (false).
peakIntensity	Temperature [numReceptor]	the maximum intensities (one value per receptor).
peakIntensityError	Temperature [numReceptor]	the uncertainties on the maximum intensities (one value per receptor).
peakIntensityWasFixed	bool	the maximum intensity was fixed (true) or not fixed (false).
astigmPlus	Length [numReceptor]	the astigmatism component with 0 degree symmetry axis.
astigmPlusError	Length [numReceptor]	the statistical error on astigmPlus
astigmMult	Length [numReceptor]	the astigmatism component with 45 degrees symmetry axis.
astigmMultError	Length [numReceptor]	the statistical error on astigmMult
illumOffset	Length [numReceptor] [2]	the illumination offset of the primary reflector expressed as a pair of values.
illumOffsetError	Length [numReceptor] [2]	the statistical error on illumOffset.
fitRMS	Length [numReceptor]	The RMS of the half path length after removing the best fit parabola.

### Column Descriptions:

- antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.
- receiverBand** : The name of the front-end frequency band being used.
- calDataId** : CalData Table identifier.
- calReductionId** : CalReduction Table identifier.
- startValidTime** : The start of the time validity range for the result.
- endValidTime** : The end of the time validity range for the result.
- ambientTemperature** : Ambient temperature at the time of measurement. For mm-wave antennas a temperature dependence of the focus correction is expected.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 41

`atmPhaseCorrection` : The atmospheric phase correction states for which result is given.

`focusMethod` : Method used, e.g., 'Interferometry' or '5 points'

`frequencyRange` : Frequency range over which the result is valid. TOPO

`pointingDirection` : The antenna pointing direction (horizontal coordinates). For mm-wave antennas an elevation dependence of the focus correction is expected. `AZELNOWAntenna.position`

`numReceptor` : Number of receptors.

`polarizationTypes` : The relevant polarizations for the measured focus parameters.

`wereFixed` : Indicates which focus coordinates were kept fixed during measurement (and thus were not measured).

`offset` : The measured focus offsets in X, Y, Z. This offset is relative to the nominal position of the focus, once the focus model has been applied.

`offsetError` : Uncertainty of `offset`.

`offsetWasTied` : True for a polarization and focus coordinate when this quantity was assumed fixed relative to the corresponding coordinate in the other polarization.

`reducedChiSquared` : Reduced  $\chi^2$  indicating the quality of the least-squares fit.

`position` : **long doc missing**

`polarizationsAveraged` : Set when polarizations were averaged over to improve sensitivity.

`focusCurveWidth` : Half-power width of fitted focus curve.

`focusCurveWidthError` : Statistical uncertainty of the half-power width of the fitted focus curve.

`focusCurveWasFixed` : Indicates that the half-power width of the fitted focus curve was fixed to an assumed value.

`offIntensity` : Off intensity level. This is needed for completeness to define the fitted beam function whenever the off level is non-zero (single-dish pointing).

`offIntensityError` : Off intensity level uncertainty

`offIntensityWasFixed` : Off intensity level was fixed.

`peakIntensity` : Fitted maximum intensity of signal.

`peakIntensityError` : Statistical uncertainty of the fitted maximum signal intensity.

`peakIntensityWasFixed` : Indicates that the maximal signal intensity was fixed to an assumed value.

`astigmPlus` : **long doc missing**

`astigmPlusError` : **long doc missing**

`astigmMult` : **long doc missing**

`astigmMultError` : **long doc missing**

`illumOffset` : **long doc missing**

`illumOffsetError` : **long doc missing**

`fitRMS` : **long doc missing**



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 42

### 1.17 CalFocusModel Table

Result of focus model calibration performed by TelCal.

CalFocusModel		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
receiverBand	ReceiverBand	identifies the receiver band.
polarizationType	PolarizationType	identifies the polarization type for which this focus model is valid.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
antennaMake	AntennaMake	identifies the antenna make.
numCoeff ( $N_{Coeff}$ )	int	the number of coefficients.
numSourceObs ( $N_{Source}$ )	int	the number of source directions observed to derive the model.
coeffName	string [numCoeff]	the names given to the coefficients in the model.
coeffFormula	string [numCoeff]	the coefficients formula (one string per coefficient).
coeffValue	float [numCoeff]	the fitted values of the coefficients.
coeffError	float [numCoeff]	the statistical uncertainties on the derived coefficients (one value per coefficient).
coeffFixed	bool [numCoeff]	one coefficient was fixed (true) or not fixed (false) (one boolean value per coefficient).
focusModel	string	the name of this focus model.
focusRMS	Length [3]	the RMS deviations of residuals of focus coordinates.
reducedChiSquared	double	a measure of the quality of the least-square fit.

#### Column Descriptions:

antennaName : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

receiverBand : The name of the front-end frequency band being used.

polarizationType : Polarization component for which the focus model is valid.

calDataId : CalData Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 43

`calReductionId` : CalReduction Table identifier.

`startValidTime` : The start of the time validity range for the result.

`endValidTime` : The end of the time validity range for the result.

`antennaMake` : The antenna make (e.g., for ALMA, the manufacturer name such as AEC, Vertex, or Melco).

`numCoeff` : Number of coefficients in the focus model.

`numSourceObs` : Number of source directions observed to derive the model.

`coeffName` : The given names of the coefficients in the model.

`coeffFormula` : The formula describing the fitted functional dependence for the focus coordinate.

`coeffValue` : The fitted value for the coefficient.

`coeffError` : The statistical uncertainty on the derived coefficients.

`coeffFixed` : A boolean specifying that the coefficient was fixed to an assumed value.

`focusModel` : Name of this focus model.

`focusRMS` : The root mean square deviation of residuals in focus coordinates.

`reducedChiSquared` : Reduced  $\chi^2$  indicating the quality of the least-squares fit.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 44

### 1.18 CalGain Table

This Table is a placeholder to be used to wrap up casa gain tables produced in the Science Pipeline and Offline so that they can be archived in the ALMA Calibration Data Base.

CalGain		
Name	Type (Shape)	Comment
<i>Key</i>		
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReductionTable.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
gain	float	TBD
gainValid	bool	TBD
fit	float	TBD
fitWeight	float	TBD
totalGainValid	bool	TBD
totalFit	float	TBD
totalFitWeight	float	TBD

#### Column Descriptions:

calDataId : CalData Table identifier.

calReductionId : CalReduction Table identifier.

startValidTime : The start of the time validity range for the result.

endValidTime : The end of the time validity range for the result.

gain : TBD

gainValid : TBD

fit : TBD

fitWeight : TBD

totalGainValid : TBD

totalFit : TBD

totalFitWeight : TBD



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 45

### 1.19 CalHolography Table

Result of holography calibration performed by TelCal.

CalHolography		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
antennaMake	AntennaMake	identifies the antenna make.
startValidTime	ArrayTime	Start time of result validity period
endValidTime	ArrayTime	the end time of result validity period.
ambientTemperature	Temperature	the ambient temperature.
focusPosition	Length [3]	the focus position.
frequencyRange	Frequency [2]	the range of frequencies for which the measurement is valid.
illuminationTaper	double	the amplitude illumination taper.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
polarizationTypes	PolarizationType [numReceptor]	identifies the polarization types (one value per receptor).
numPanelModes ( $N_{Pane}$ )	int	the number panel modes fitted.
receiverBand	ReceiverBand	identifies the receiver band.
beamMapUID	EntityRef	refers to the beam map image.
rawRMS	Length	the RMS of the pathlength residuals.
weightedRMS	Length	the weighted RMS of the pathlength residuals.
surfaceMapUID	EntityRef	refers to the resulting antenna surface map image.
direction	Angle [2]	the direction of the source.
<i>Optional Data</i>		
numScrew ( $N_{Scre}$ )	int	the number of screws.
screwName	string [numScrew]	the names of the screws (one value per screw).
screwMotion	Length [numScrew]	the prescribed screw motions (one value per screw).
screwMotionError	Length [numScrew]	the uncertainties on the prescribed screw motions (one value per screw).
gravCorrection	bool	indicates if a gravitational correction was applied (true) or not (false).
gravOptRange	Angle [2]	the range of gravitational optimization.
tempCorrection	bool	indicates if a temperature correction was applied (true) or not (false).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 46

### CalHolography – continued from previous page

Name	Type (Shape)	Comment
tempOptRange	Temperature [2]	the range of temperature optimization.

#### Column Descriptions:

**antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**antennaMake** : The antenna make (e.g., for ALMA, the manufacturer name such as AEC, Vertex, or Melco).

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**ambientTemperature** : Ambient temperature at the time of measurement. The surface deformations are expected to depend on temperature.

**focusPosition** : The optimal focus position (in XYZ) as derived from the aperture map phases. REFLECTOR

**frequencyRange** : Frequency range over which the result is valid. TOPO

**illuminationTaper** : Power illumination taper assumed to calculate weighted rms.

**numReceptor** : The number or polarization receptors (one or two) for which the result is given.

**polarizationTypes** : The polarization types of the receptors being used.

**numPanelModes** : The number of panel independent position/deformation modes that have been fitted.

**receiverBand** : The name of the front-end frequency band being used.

**beamMapUID** : The beam map UID provides a link to the resulting beam map image either as a disk file or in the ALMA Archive. The disk file name is built from the UID string by replacing all colons and slashes by underscores.

**rawRMS** : The root mean square of the pathlength residuals, measured along Z, that is perpendicular to the aperture plane when looking a source at infinite distance.

**weightedRMS** : The root mean square of pathlength residuals (along Z); weighted assuming a primary beam illumination as specified by **illuminationTaper**.

**surfaceMapUID** : The surface map UID provides a link to the resulting antenna surface map image either as a disk file or in the ALMA Archive. The disk file name is built from the UID string by replacing all colons and slashes by underscores.

**direction** : The antenna pointing direction (horizontal coordinates) AZELNOWAntenna..position

**numScrew** : Number of screws to be adjusted using surface map data.

**screwName** : The string identification of the panel screws.

**screwMotion** : The prescribed panel screw adjustments derived from the panel fit to the aperture map phases.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 47

**screwMotionError** : The statistical uncertainties on the prescribed panel screw adjustments derived from the panel fit to the aperture map phases.

**gravCorrection** : Optimization target elevation range for the gravitaionnal correction applied.

**gravOptRange** : Optimization target elevation range for the gravitaionnal correction applied.

**tempCorrection** : A temperature correction was applied in the screw motion data.

**tempOptRange** : Optimization target temperature range.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 48

### 1.20 CalPhase Table

Result of the phase calibration performed by TelCal.

CalPhase		
Name	Type (Shape)	Comment
<i>Key</i>		
basebandName	BasebandName	identifies the baseband.
receiverBand	ReceiverBand	identifies the receiver band.
atmPhaseCorrection	AtmPhaseCorrection	describes how the atmospheric phase correction has been applied.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
numBaseline ( $N_{Base}$ )	int	the number of baselines.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
ampli	float [numReceptor] [numBaseline]	the amplitudes (one value per receptor per baseline).
antennaNames	string [numBaseline] [2]	the names of the antennas (one pair of strings per baseline).
baselineLengths	Length [numBaseline]	the physical lengths of the baselines (one value per baseline).
decorrelationFactor	float [numReceptor] [numBaseline]	the decorrelation factors (one value per receptor per baseline).
direction	Angle [2]	the direction of the source.
frequencyRange	Frequency [2]	the frequency range over which the result is valid.
integrationTime	Interval	the integration duration for a data point.
phase	float [numReceptor] [numBaseline]	the phases of the averaged interferometer signal (one value per receptor per baseline).
polarizationTypes	PolarizationType [numReceptor]	identifies the polarization types of the receptors (one value per receptor).
phaseRMS	float [numReceptor] [numBaseline]	the RMS of phase fluctuations relative to the average signal (one value per receptor per baseline).
statPhaseRMS	float [numReceptor] [numBaseline]	the RMS of phase deviations expected from the thermal fluctuations (one value per receptor per baseline).
<i>Optional Data</i>		





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 49

CalPhase – continued from previous page		
Name	Type (Shape)	Comment
correctionValidity	bool [numBaseline]	the deduced validity of atmospheric path length correction (from water vapor radiometers).
numAntenna ( $N_{Ante}$ )	int	the number of antennas. Defines the size singleAntennaName, phaseAnt, phaseAntRMS. One must pay attention to the fact that numBaseline and numAntenna must verify the relation : numBaseline == numAntenna * ( numAntenna - 1 ) / 2
singleAntennaName	string [numAntenna]	the ordered list of antenna names. The size of the array must be equal to the number of antennas.
refAntennaName	string	the name of the antenna used as a reference to get the antenna-based phases.
phaseAnt	float [numReceptor] [numAntenna]	the antenna based phase solution averaged over the scan (one value per receptor per antenna). See singleAntennaName for the association of the values of this array with the antennas.
phaseAntRMS	float [numReceptor] [numAntenna]	the RMS of the phase fluctuations relative to the antenna based average phase (one value per receptor per antenna). See singleAntennaName for the association of the values of this array with the antennas.

### Column Descriptions:

**basebandName** : The name of the 'baseband pair' which is measured. For ALMA, a baseband pair is the signal path identified by a second local oscillator and has two polarizations.

**receiverBand** : The name of the front-end frequency band being used.

**atmPhaseCorrection** : The atmospheric phase corrections states for which result is given.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**numBaseline** : Number of baselines for which the result is given.

**numReceptor** : The number or polarization receptors (one or two) for which the result is given.

**ampli** : Amplitude of averaged signal.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 50

**antennaNames** : Refer uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**baselineLengths** : The physical length of each baseline.

**decorrelationFactor** : The calculated decorrelation factor (amplitude loss) due to non-thermal phase fluctuations.

**direction** : The antenna pointing direction in horizontal coordinates. AZELNOWAntenna.position

**frequencyRange** : Frequency range over which the result is valid TOPO

**integrationTime** : Integration time on a data point, to calculate rms.

**phase** : The phase of the averaged interferometer signal.

**polarizationTypes** : The polarization types of the receptors being used.

**phaseRMS** : The root mean square of phase fluctuations relative to the average signal.

**statPhaseRMS** : The root mean square of phase deviations expected from thermal fluctuations.

**correctionValidity** : Deduced validity of atmospheric path length correction (from Water Vapour Radiometers; remark: It is not clear that correctionValidity is really an array. What about its size?).

**numAntenna** : long doc missing

**singleAntennaName** : long doc missing

**refAntennaName** : long doc missing

**phaseAnt** : long doc missing

**phaseAntRMS** : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 51

### 1.21 CalPointing Table

Result of the pointing calibration performed on-line by TelCal.

CalPointing		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	Antenna Name
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
ambientTemperature	Temperature	the ambient temperature.
antennaMake	AntennaMake	identifies the antenna make.
atmPhaseCorrection	AtmPhaseCorrection	describes how the atmospheric phase correction has been applied.
direction	Angle [2]	the antenna pointing direction.
frequencyRange	Frequency [2]	the frequency range over which the result is valid.
pointingModelMode	PointingModelMode	identifies the pointing model mode.
pointingMethod	PointingMethod	identifies the pointing method.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
polarizationTypes	PolarizationType [numReceptor]	identifies the polarizations types (one value per receptor).
collOffsetRelative	Angle [numReceptor] [2]	the collimation offsets (relative) (one pair of angles per receptor).
collOffsetAbsolute	Angle [numReceptor] [2]	the collimation offsets (absolute) (one pair of angles per receptor).
collError	Angle [numReceptor] [2]	the uncertainties on collimation (one pair of angles per receptor)
collOffsetTied	bool [numReceptor] [2]	indicates if a collimation offset was tied (true) or not tied (false) to another polar (one pair of boolean values per receptor).
reducedChiSquared	double [numReceptor]	a measure of the quality of the least square fit.
<i>Optional Data</i>		
averagedPolarizations	bool	true when the polarizations were averaged together to improve sensitivity.
beamPA	Angle [numReceptor]	the fitted beam position angles (one value per receptor).
beamPAError	Angle [numReceptor]	the uncertainties on the fitted beam position angles (one value per receptor).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 52

CalPointing – continued from previous page		
Name	Type (Shape)	Comment
beamPAWasFixed	bool	indicates if the beam position was fixed (true) or not fixed (false).
beamWidth	Angle [numReceptor] [2]	the fitted beam widths (one pair of angles per receptor).
beamWidthError	Angle [numReceptor] [2]	the uncertainties on the fitted beam widths (one pair of angles per receptor).
beamWidthWasFixed	bool [2]	indicates if the beam width was fixed (true) or not fixed (true) (one pair of booleans).
offIntensity	Temperature [numReceptor]	the off intensity levels (one value per receptor).
offIntensityError	Temperature [numReceptor]	the uncertainties on the off intensity levels (one value per receptor).
offIntensityWasFixed	bool	indicates if the off intensity level was fixed (true) or not fixed (false).
peakIntensity	Temperature [numReceptor]	the maximum intensities (one value per receptor).
peakIntensityError	Temperature [numReceptor]	the uncertainties on the maximum intensities (one value per receptor).
peakIntensityWasFixed	bool	the maximum intensity was fixed.

### Column Descriptions:

**antennaName** : Refers uniquely to the hardware antenna object as present in the original ASDM Antenna table.

**receiverBand** : The name of the front-end frequency band being used.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**ambientTemperature** : Ambient temperature at the time of measurement. For mm-wave antennas, a temperature dependence of the pointing correction may be expected.

**antennaMake** : The antenna make (e.g., for ALMA, the antenna manufacturer name such as AEC, Vertex, or Melco).

**atmPhaseCorrection** : The atmospheric phase correction states for which result is given.

**direction** : The antenna pointing direction (horizontal coordinates) AZELNOWAntenna.position

**frequencyRange** : Frequency range over which the result is valid TOPO

**pointingModelMode** : Radio pointing or Optical pointing.

**pointingMethod** : Observing method used to determine the collimation offsets.

**numReceptor** : Number of receptors.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 53

**polarizationTypes** : The relevant polarizations for the measured pointing parameters.

**collOffsetRelative** : The collimation offsets found required to center the source, relative to the expected direction of the source, using a predetermined pointing model. These are the collimation offsets to be applied for reference pointing, or for a more refined local pointing model. `AZELNOWAntenna.position[virtual]`

**collOffsetAbsolute** : The collimation offsets found required to center the source, relative to the expected direction of the source assuming a perfect antenna mount. These are collimation offsets to be used for determination of the pointing model. `AZELNOWAntenna.positiontarget`

**collError** : Statistical uncertainties in the determination of azimuth and elevation collimations.

**collOffsetTied** : True for a polarization coordinate when this quantity was assumed fixed relative to the corresponding coordinate in the other polarization.

**reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit.

**averagedPolarizations** : Set when polarizations were averaged together to improve sensitivity.

**beamPA** : Position angle of fitted antenna beam.

**beamPAError** : Statistical uncertainty of position angle of fitted antenna beam.

**beamPAWasFixed** : Indicates that the position angle of the fitted antenna beam was fixed to an assumed value.

**beamWidth** : Half-power width of fitted antenna beam.

**beamWidthError** : Statistical uncertainty of the half-power width of the fitted antenna beam.

**beamWidthWasFixed** : Indicates that the half-power width of antenna beam was fixed to an assumed value.

**offIntensity** : Off intensity level. This is needed for completeness to define the fitted beam function whenever the off level is non-zero (single-dish pointing).

**offIntensityError** : Off intensity level uncertainty.

**offIntensityWasFixed** : Off intensity level was fixed.

**peakIntensity** : Fitted maximum intensity of signal.

**peakIntensityError** : Statistical uncertainty of the fitted maximum signal intensity.

**peakIntensityWasFixed** : Indicates that the maximal signal intensity was fixed to an assumed value.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 54

### 1.22 CalPointingModel Table

Result of pointing model calibration performed by TelCal.

CalPointingModel		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
antennaMake	AntennaMake	the antenna make.
pointingModelMode	PointingModelMode	identifies the pointing model mode.
polarizationType	PolarizationType	identifies the polarization type.
numCoeff ( $N_{Coef}$ )	int	the number of coefficients in the pointing model.
coeffName	string [numCoeff]	the names of the coefficients (one string per coefficient).
coeffVal	float [numCoeff]	the values of the coefficients resulting from the pointing model fitting (one value per coefficient).
coeffError	float [numCoeff]	the uncertainties on the pointing model coefficients (one value per coefficient).
coeffFixed	bool [numCoeff]	indicates if one coefficient was fixed (true) or not fixed (false) (one boolean per coefficient).
azimuthRMS	Angle	Azimuth RMS (on Sky)
elevationRms	Angle	Elevation rms (on Sky)
skyRMS	Angle	rms on sky
reducedChiSquared	double	measures the quality of the least square fit.
<i>Optional Data</i>		
numObs ( $N_{Obs}$ )	int	the number of source directions observed to derive the pointing model.
coeffFormula	string [numCoeff]	formulas used for the fitting (one string per coefficient).

#### Column Descriptions:

**antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 55

**receiverBand** : The name of the front-end frequency band being used.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**antennaMake** : The antenna make (e.g., for ALMA, the manufacturer name such as AEC, Vertex, or Melco).

**pointingModelMode** : Pointing Model mode (Radio or optical)

**polarizationType** : Polarization component for which the pointing model is valid.

**numCoeff** : The number of coefficients in the pointing model.

**coeffName** : The names of the coefficients, following **tpoint** software conventions (generic functions, see **tpoint** software documentation by P. Wallace).

**coeffVal** : The fitted pointing model coefficients.

**coeffError** : Statistical uncertainties of pointing model coefficients.

**coeffFixed** : Indicates that the coefficient was kept fixed to an assumed value.

**azimuthRMS** : Root mean squared of azimuth residuals (as a true angle on the sky).

**elevationRms** : Root mean of squared elevation residuals (as a true angle on the sky).

**skyRMS** : Root mean squared of angular distance deviations.

**reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit.

**numObs** : The number of source directions observed used to derive the pointing model.

**coeffFormula** : Formula used. This describes the functions fitted, for the corresponding coefficient. This is useful when **tpoint** software has not been used.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 56

### 1.23 CalPosition Table

Result of antenna positions calibration performed by TelCal.

CalPosition		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
atmPhaseCorrection	AtmPhaseCorrection	describes how the atmospheric phase correction has been applied.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
antennaPosition	Length [3]	the position of the antenna.
stationName	string	the name of the station.
stationPosition	Length [3]	the position of the station.
positionMethod	PositionMethod	identifies the method used for the position calibration.
receiverBand	ReceiverBand	identifies the receiver band.
numAntenna ( $N_{Ante}$ )	int	the number of antennas of reference.
refAntennaNames	string [numAntenna]	the names of the antennas of reference (one string per antenna).
axesOffset	Length	the measured axe's offset.
axesOffsetErr	Length	the uncertainty on the determination of the axe's offset.
axesOffsetFixed	bool	the axe's offset was fixed (true) or not fixed (false).
positionOffset	Length [3]	the measured position offsets (a triple).
positionErr	Length [3]	the uncertainties on the measured position offsets (a triple).
reducedChiSquared	double	measures the quality of the fit.
<i>Optional Data</i>		
delayRms	double	the RMS deviation for the observed delays.
phaseRms	Angle	the RMS deviation for the observed phases.

#### Column Descriptions:

antennaName : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

atmPhaseCorrection : The atmospheric phase correction states for which result is given.

calDataId : CalData Table identifier.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 57

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**antennaPosition** : The antenna position measured values in the X, Y, Z horizontal system, relative to the station. `AZELStation.position`

**stationName** : The name of the station where the antenna was set.

**stationPosition** : The station position in the X, Y, Z geocentric system. These are included as references for `stationPosition`.

**positionMethod** : Position measurement method used (fit to delays or fit to phases).

**receiverBand** : The name of the front-end frequency band being used.

**numAntenna** : The number of antennas used as reference for the antenna with unknown position.

**refAntennaNames** : The names of the antennas used as reference to get the antenna unknown position.

**axesOffset** : Measured offsets between azimuth and elevation axes. This is the horizontal component perpendicular to the elevation axis, counted positive in the direction where the antenna is pointed at, when horizon-looking.

**axesOffsetErr** : Statistical uncertainties of measured offsets between azimuth and elevation axes.

**axesOffsetFixed** : The offsets between azimuth and elevation axes were held fixed at an assumed value.

**positionOffset** : The measured position offsets in the X, Y, Z horizontal system, relative to the values assumed at the time of observing and used to track the phases. `AZELstationPosition`

**positionErr** : The statistical uncertainties of the measured position offsets in the X, Y, Z horizontal system. `AZELstationPosition`

**reducedChiSquared** : Reduced  $\chi^2$  indicating the quality of the least-squares fit.

**delayRms** : The root mean squared deviations for the observed delays.

**phaseRms** : The root mean squared deviations for the observed phases.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 58

### 1.24 CalPrimaryBeam Table

Result of Primary Beam Map measurement.

CalPrimaryBeam		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
receiverBand	ReceiverBand	identifies the receiver band.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
antennaMake	AntennaMake	the antenna make.
numSubband ( $N_{Subb}$ )	int	the number of subband images (frequency ranges simultaneously measured).
frequencyRange	Frequency [numSubband] [2]	the range of frequencies over which the result is valid.
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
polarizationTypes	PolarizationType [numReceptor]	identifies the polarizations types of the receptors (one value per receptor).
mainBeamEfficiency	double [numReceptor]	the main beam efficiency as derived from the beam map.
beamDescriptionUID	EntityRef	refers to the beam description image.
relativeAmplitudeRms	float	the RMS fluctuations in terms of the relative beam amplitude.
direction	Angle [2]	the center direction.
minValidDirection	Angle [2]	the minimum center direction of validity.
maxValidDirection	Angle [2]	the maximum center direction of validity.
descriptionType	PrimaryBeamDescription	quantity used to describe beam.
imageChannelNumber	int [numSubband]	channel number in image for each subband.
imageNominalFrequency	Frequency [numSubband]	nominal frequency for subband.

#### Column Descriptions:

antennaName : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

receiverBand : The name of the front-end frequency band being used.

calDataId : CalData Table identifier.

calReductionId : CalReduction Table identifier.

startValidTime : The start of the time validity range for the result.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 59

`endValidTime` : The start of the time validity range for the result.

`antennaMake` : The antenna make (e.g., for ALMA, the manufacturer name such as AEC, Vertex, or Melco).

`numSubband` : **long doc missing**

`frequencyRange` : Frequency range over which the result is valid. TOPO

`numReceptor` : The number or polarization receptors (one or two) for which the result is given.

`polarizationTypes` : The polarization types of the receptors being used.

`mainBeamEfficiency` : The main beam efficiency as derived for the beam map.

`beamDescriptionUID` : **long doc missing**

`relativeAmplitudeRms` : The root mean square fluctuations in terms of relative beam amplitude, i.e. the antenna gain scaled by its maximal value (on axis).

`direction` : **long doc missing**

`minValidDirection` : **long doc missing**

`maxValidDirection` : **long doc missing**

`descriptionType` : **long doc missing**

`imageChannelNumber` : **long doc missing**

`imageNominalFrequency` : **long doc missing**



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 60

### 1.25 CalReduction Table

Generic items describing the data reduction process.

CalReduction		
Name	Type (Shape)	Comment
<i>Key</i>		
calReductionId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
numApplied ( $N_{Appl}$ )	int	the number of applied calibrations prior the reduction.
appliedCalibrations	string [numApplied]	the list of applied calibrations (one string per calibration).
numParam ( $N_{Para}$ )	int	the number of listed parameters used for calibration.
paramSet	string [numParam]	the input parameters expressed as (key-word,value) pairs (one string per parameter).
numInvalidConditions ( $N_{Inva}$ )	int	the number of invalidating conditions.
invalidConditions	InvalidatingCondition [numInvalidConditions]	invalidating use cases (one string per case).
timeReduced	ArrayTime	the epoch at which the data reduction was finished.
messages	string	messages issued by the data reduction software.
software	string	the name of the data reduction software used.
softwareVersion	string	version information about the data reduction software used.

#### Column Descriptions:

calReductionId : CalReduction row identifier.

numApplied : The number of calibrations applied to data before solving for the result.

appliedCalibrations : List of calibrations applied before solving for the result.

numParam : The number of listed parameters as used for this calibration.

paramSet : The list of parameters needed to specify the calibration applied given as (keyword,value) pairs.

numInvalidConditions : The number of use cases that may invalidate the result.

invalidConditions : The list of use cases that may invalidate the result.

timeReduced : The epoch at which the data reduction was finished.

messages : Messages issued by the data reduction software.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 61

**software** : The name of the data reduction software used to derive the result.

**softwareVersion** : The version of the data reduction software used to derive the result.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 62

### 1.26 CalSeeing Table

The seeing parameters deduced from TelCal calibrations.

CalSeeing		
Name	Type (Shape)	Comment
<i>Key</i>		
atmPhaseCorrection	AtmPhaseCorrection	describes how the atmospheric phase correction has been applied.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to a unique row in CalReduction Table.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
frequencyRange	Frequency [2]	the range of frequencies over which this result is valid.
integrationTime	Interval	the duration of averaging for the evaluation of the RMS.
numBaseLengths ( $N_{Base}$ )	int	the number of baselines for which the the RMS phase data is evaluated.
baselineLengths	Length [numBaseLengths]	the lengths of the baselines (one value per baseline).
phaseRMS	Angle [numBaseLengths]	the RMS of phase fluctuations (one value per baseline).
seeing	Angle	the seeing parameter, deduced for the LO1.
seeingError	Angle	the uncertainty on the seeing parameter.
<i>Optional Data</i>		
exponent	float	the exponent of the spatial structure function.
outerScale	Length	the outer scale.
outerScaleRMS	Angle	the RMS of phase fluctuations at scale length outerScale.

#### Column Descriptions:

atmPhaseCorrection : The atmospheric phase correction states for which result is given.

calDataId : CalData Table identifier.

calReductionId : CalReduction Table identifier.

startValidTime : The start of the time validity range for the result.

endValidTime : The end of the time validity range for the result.

frequencyRange : Frequency range over which the result is valid. TOPO



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 63

**integrationTime** : Averaging time for evaluation of rms fluctuations.

**numBaseLengths** : The number of baselines for which the rms phase data is evaluated.

**baselineLengths** : The baseline lengths at which the phase rms is evaluated.

**phaseRMS** : Root mean squared phase fluctuations for each baseline length.

**seeing** : The seeing parameter deduced for the calculated rms phases. This is the half-power width of the beam that would be synthesized if those phase fluctuations were not corrected.

**seeingError** : The uncertainty on **seeing**.

**exponent** : The exponents of the fitted power laws in the phase rms data. There may be two values (inner, outer) if an outer scale is given.

**outerScale** : The outer scale of turbulence (validity limit of power law in phase structure function).

**outerScaleRMS** : Root mean squared phase fluctuations at scale length **outerScale**. This number allows to calculate the modelled phase structure function at any scale (above and below **outerScale**).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 64

### 1.27 CalWVR Table

Result of the water vapour radiometric calibration performed by TelCal.

CalWVR		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaName	string	the name of the antenna.
calDataId	Tag	refers to a unique row in CalData Table.
calReductionId	Tag	refers to unique row in CalReductionTable.
<i>Required Data</i>		
startValidTime	ArrayTime	the start time of result validity period.
endValidTime	ArrayTime	the end time of result validity period.
wvrMethod	WVRMethod	identifies the method used for the calibration.
numInputAntennas ( $N_{Inpu}$ )	int	the number of input antennas (i.e. equipped with functional WVRs).
inputAntennaNames	string [numInputAntennas]	the names of the input antennas (one string per antenna).
numChan ( $N_{Chan}$ )	int	the number of frequency channels in the WVR receiver.
chanFreq	Frequency [numChan]	the channel frequencies (one value per channel).
chanWidth	Frequency [numChan]	the widths of the channels (one value per channel).
refTemp	Temperature [numInputAntennas] [numChan]	the reference temperatures (one value per input antenna per channel).
numPoly ( $N_{Poly}$ )	int	the number of polynomial coefficients.
pathCoeff	float [numInputAntennas] [numChan] [numPoly]	the path length coefficients (one value per input antenna per channel per polynomial coefficient).
polyFreqLimits	Frequency [2]	the limits of the interval of frequencies for which the path length coefficients are computed.
wetPath	float [numPoly]	The wet path as a function frequency (expressed as a polynomial).
dryPath	float [numPoly]	The dry path as a function frequency (expressed as a polynomial).
water	Length	The precipitable water vapor corresponding to the reference model.

#### Column Descriptions:





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 65

**antennaName** : Refers uniquely to the hardware antenna object, as present in the original ASDM Antenna table.

**calDataId** : CalData Table identifier.

**calReductionId** : CalReduction Table identifier.

**startValidTime** : The start of the time validity range for the result.

**endValidTime** : The end of the time validity range for the result.

**wvrMethod** : Method used, e.g, ab initio, Empirical.

**numInputAntennas** : The number of antennas equipped with functional WVRs, from which the data should be interpolated, using the path length coefficients calculated, to obtain the pathlength correction to be applied to the antenna given as 'antennaName'.

**inputAntennaNames** :

**inputAntennaNames** : The names of the antennas equipped with functional WVRs, from which the data should be interpolated, using the path length coefficients calculated, to obtain the pathlength correction to be applied to the antenna given as 'antennaName'.

**numChan** : Number of frequency channels in the WVR receiver.

**chanFreq** : The center frequency of the WVR channels. TOPO

**chanWidth** : The frequency width of the WVR channels.

**refTemp** : The reference temperature  $T_{Rcj}$  for each WVR channel to be used in the path length formula.

**numPoly** : The number of polynomial coefficients given, to obtain the frequency dependence of the pathlength correction.

**pathCoeff** : The path length coefficients to be used to obtain the pathlength correction to be applied to the antenna given as 'antennaName'. These are the coefficients  $C_{kcj}$  ( $k = 1, N_{Poly}$ ) used to obtain the path length as a linear combinations of the data from the  $N_{Chan}$  WVR channels (in temperature units). Each coefficient is a term of a polynomial expansion ( $N_{Poly}$  coefficients) of the predicted path length as a function of observing frequency in the astronomical band (frequency limits in PolyFreqLimits). These polynomials are Chebichev polynomials in this frequency interval reduced to  $[-1., 1.]$ . For the given Antenna (antennaName), the path length correction to be applied is:

$$\sum_{j=1, N_{InpA}} \left[ \sum_{c=1, N_{Chan}} P_{cj}(\nu)(T_{cj} - T_{Rcj}) \right]$$

where

- $T_{Rcj}$  is the reference WVR temperature for channel  $c$  of antenna  $j$
- $T_{cj}$  is the observed WVR temperature for channel  $c$  of antenna  $j$
- $P_{cj}(\nu)$  is the value of the Chebichev polynomial with coefficients evaluated at sky frequency  $\nu$  with coefficients  $C_{kcj}$  ( $k = 1, N_{Poly}$ )

In the most frequent case there is a single input antenna (AntennaName). If the WVR device on a given antenna is not available or fails, the above formula gives the desired way to interpolate the correction for that antenna, based of other antennas (close neighbours).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 66

**polyFreqLimits** : Frequency limits of the frequency interval for which the path length coefficients are computed.

**wetPath** : The wet path as a function of frequency expressed as Chebichev polynomial in the frequency range reduced to  $[-1, 1]$ . This corresponds to the reference model that reproduces the average line shape and is used in the delay server to track the phases and delays, while the departures from the average water line shape are used for the pathlength correction applied to the correlator.

**dryPath** : The dry path as a function of frequency expressed as a Chebichev polynomial in the frequency range reduced to  $[-1, 1]$ . This corresponds to the same reference model as wetPath.

**water** : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 67

### 1.28 ConfigDescription Table

Defines the hardware configuration used to obtain the science data.

ConfigDescription		
Name	Type (Shape)	Comment
<i>Key</i>		
configDescriptionId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
numAntenna ( $N_{Ante}$ )	int	the number of antennas.
numDataDescription ( $N_{Data}$ )	int	the number of data descriptions.
numFeed ( $N_{Feed}$ )	int	the number of feeds.
correlationMode	CorrelationMode	identifies the correlation mode.
numAtmPhaseCorrection ( $N_{AtmP}$ )	int	the number of descriptions of the atmospheric phase correction.
atmPhaseCorrection	AtmPhaseCorrection [numAtmPhaseCorrection]	describe how the atmospheric phase corrections have been applied (one value per correction).
processorType	ProcessorType	identifies the generic processor's type.
spectralType	SpectralResolutionType	identifies the spectral type of the data.
antennaId	Tag [numAntenna]	identifies numAntenna rows in AntennaTable.
feedId	int [numAntenna*numFeed]	refers to many collections of rows in the Feed Table.
switchCycleId	Tag [numDataDescription]	refers to a unique row in the SwitchCycle Table.
dataDescriptionId	Tag [numDataDescription]	refers to one or more rows in DataDescriptionTable.
processorId	Tag	refers to a unique row in ProcessorTable.
<i>Optional Data</i>		
phasedArrayList	int [numAntenna]	phased array identifiers.
numAssocValues ( $N_{Asso}$ )	int	the number of associated config descriptions.
assocNature	SpectralResolutionType [numAssocValues]	the natures of the associations with other config descriptions (one value per association).
assocConfigDescriptionId	Tag [numAssocValues]	refers to one or more rows in ConfigDescriptionTable.

#### Column Descriptions:

configDescriptionId : Identifies the row in the Configuration Description Table.

numAntenna : The number of antennas used (given by the antennaId array).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 68

**numDataDescription** : Number of data descriptions for this row. This is equal to the number of spectral windows.

**numFeed** : Number of feeds (given by the **feedId** array). For ALMA, **numFeed** is always one and **feedId** is zero.

**correlationMode** : The correlation mode used; for ALMA this is either Autocorrelation only, or Correlation and Autocorrelation.

**numAtmPhaseCorrection** : Number of Atmospheric Phase Corrections.

**atmPhaseCorrection** : The atmospheric phase correction states of data given (corrected, uncorrected, or both).

**processorType** : The generic processor type, such as, e.g., CORRELATOR, SPECTROMETER, or RADIO-METER.

**spectralType** : The spectral type of this data. It may be e.g direct spectral processor data (at full resolution), or channel averaged spectral processor data, or total power detector data.

**antennaId** : The number of antennas used (given by the **antennaId** table).

**feedId** : Specifies which feed was used in the Feed Table.

**switchCycleId** : SwitchCycle Table identifier.

**dataDescriptionId** : DataDescription Table identifier.

**processorId** : The Processor Identifier provides a direct link to a row in the Processor Table.

**phasedArrayList** : List of phased array identifiers; normally not used for ALMA.

**numAssocValues** : The number of associated config descriptions.

**assocNature** : The nature of the associations established by the **assocConfigDescriptionId** array.

**assocConfigDescriptionId** : ConfigDescription Table identifier



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 69

### 1.29 CorrelatorMode Table

Contains information on a Correlator processor.

CorrelatorMode		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>correlatorModeId</b>	<b>Tag</b>	refers to a unique row in the table.
<i>Required Data</i>		
<b>numBaseband</b> ( $N_{Base}$ )	int	the number of basebands.
<b>basebandNames</b>	BasebandName [numBaseband]	identifies the basebands (one value per basebands).
<b>basebandConfig</b>	int [numBaseband]	encodes the basebands configurations (one value per baseband).
<b>accumMode</b>	AccumMode	identifies the accumulation mode.
<b>binMode</b>	int	the binning mode.
<b>numAxes</b> ( $N_{Axes}$ )	int	the number of axes in the binary data blocks.
<b>axesOrderArray</b>	AxisName [numAxes]	the order of axes in the binary data blocks.
<b>filterMode</b>	FilterMode [numBaseband]	identifies the filters modes (one value per baseband).
<b>correlatorName</b>	CorrelatorName	identifies the correlator's name.

#### Column Descriptions:

**correlatorModeId** : Identifies the row in the Correlator Mode Table.

**numBaseband** : The number of baseband pairs used; this may be up to four for ALMA. A pair has two orthogonal polarization channels.

**basebandNames** : Baseband names, that is the baseband pairs that are used ; there are four for ALMA.

**basebandConfig** : Baseband Configuration; for ALMA currently expressed as a number like '103' for Time division mode, or '1' for tunable filter mode; there is one of these for each baseband pair.

**accumMode** : The accumulation mode: for ALMA this is either FAST (For 1ms dumps, autocorrelation only) or NORMAL (for 16ms minimum dumps, and simultaneous correlation and autocorrelation).

**binMode** : The number of data bins: data bins are used together for switch cycles. For instance we have two for frequency switching of nutator switching, but one only for interferometry.

**numAxes** : The number of axes in the binary data blocks.

**axesOrderArray** : The standard order of axes in the binary data blocks. Axes may be omitted (See the BDF documentation).

**filterMode** : The mode of operation of the digital filters used at the input of the ALMA correlator. These are the TDM (Time Division Mode) or TFB (Tunable Filter Bank) modes.

**correlatorName** : The name of the correlator; in ALMA we have the 'baseline' correlator and the 'ACA' correlator.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 70

### 1.30 DataDescription Table

Spectro-polarization description.

DataDescription		
Name	Type (Shape)	Comment
<i>Key</i>		
dataDescriptionId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
polOrHoloId	Tag	refers to a unique row in PolarizationTable or HolograpyTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
<i>Optional Data</i>		
pulsarId	Tag	doc missing

#### Column Descriptions:

dataDescriptionId : DataDescription Table identifier.

polOrHoloId : Polarization Table identifier or Holography Table identifier.

spectralWindowId : SpectralWindow Table identifier.

pulsarId : missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 71

### 1.31 DelayModel Table

Contains the delay model components. For ALMA this includes all TMCDB delay model components.

DelayModel		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectraWindowTable.
timeInterval	ArrayTimeInterval	time interval for which the row's content is valid.
<i>Required Data</i>		
numPoly ( $N_{Poly}$ )	int	the number of coefficients of the polynomials.
phaseDelay	double [numPoly]	the phase delay polynomial (rad).
phaseDelayRate	double [numPoly]	Phase delay rate polynomial (rad/s).
groupDelay	double [numPoly]	Group delay polynomial (s).
groupDelayRate	double [numPoly]	Group delay rate polynomial (s/s)
fieldId	Tag	<b>doc missing</b>
<i>Optional Data</i>		
timeOrigin	ArrayTime	value used as the origin for the evaluation of the polynomials.
atmosphericGroupDelay	double	Atmosphere group delay.
atmosphericGroupDelayRate	double	Atmosphere group delay rate.
geometricDelay	double	Geometric delay.
geometricDelayRate	double	Geometric delay.
numLO ( $N_{LO}$ )	int	the number of local oscillators.
L0offset	Frequency [numLO]	Local oscillator offset.
L0offsetRate	Frequency [numLO]	Local oscillator offset rate.
dispersiveDelay	double	Dispersive delay.
dispersiveDelayRate	double	Dispersive delay rate.
atmosphericDryDelay	double	the dry atmospheric delay component.
atmosphericWetDelay	double	the wet atmospheric delay.
padDelay	double	Pad delay.
antennaDelay	double	Antenna delay.
numReceptor ( $N_{Rece}$ )	int	<b>doc missing</b>
polarizationType	PolarizationType [numReceptor]	describes the polarizations of the receptors (one value per receptor).
electronicDelay	double [numReceptor]	the electronic delay.
electronicDelayRate	double [numReceptor]	the electronic delay rate.
receiverDelay	double [numReceptor]	the receiver delay.
IFDelay	double [numReceptor]	the intermediate frequency delay.
L0Delay	double [numReceptor]	the local oscillator delay.
crossPolarizationDelay	double	the cross polarization delay.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 72

### Column Descriptions:

**antennaId** : Antenna identifier, as indexed from an element in the antennaArray collection in the configDescription table.

**spectralWindowId** : long doc missing

**timeInterval** : Time interval for which the parameters in the row are valid. The same reference used for the Time column in the Main Table must be used.

**numPoly** : Series order for the delay time polynomial expansions.

**phaseDelay** : long doc missing

**phaseDelayRate** : long doc missing

**groupDelay** : long doc missing

**groupDelayRate** : long doc missing

**fieldId** : missing

**timeOrigin** : long doc missing

**atmosphericGroupDelay** : long doc missing

**atmosphericGroupDelayRate** : long doc missing

**geometricDelay** : long doc missing

**geometricDelayRate** : long doc missing

**numL0** : long doc missing

**L0Offset** : long doc missing

**L0OffsetRate** : long doc missing

**dispersiveDelay** : long doc missing

**dispersiveDelayRate** : long doc missing

**atmosphericDryDelay** : Dry atmosphere delay component.

**atmosphericWetDelay** : Wet atmosphere delay component.

**padDelay** : long doc missing

**antennaDelay** : long doc missing

**numReceptor** : missing

**polarizationType** : long doc missing

**electronicDelay** : long doc missing

**electronicDelayRate** : long doc missing

**receiverDelay** : long doc missing

**IFDelay** : long doc missing

**L0Delay** : long doc missing

**crossPolarizationDelay** : long doc missing





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 73

### 1.32 DelayModelFixedParameters Table

missing documentation

DelayModelFixedParameters		
Name	Type (Shape)	Comment
<i>Key</i>		
delayModelFixedParametersId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
delayModelVersion	string	should include the name of the software and its version. Something like "CALC v11" or "VDT v1.0" or "MODEST v2.1".
execBlockId	Tag	refers to a unique row of the ExecBlock table.
<i>Optional Data</i>		
gaussConstant	AngularRate	the Gauss gravitational constant (should be of order $1.720209895 \cdot 10^{-2} rad/d$ but in SI units of $rad s^{-1}$ ).
newtonianConstant	double	the newtonian constant of gravitation (should be of order $6.67259 \cdot 10^{-11} m^3 kg^{-1} s^2$ ).
gravity	double	the gravity acceleration in $ms^{-2}$ .
earthFlattening	double	the ratio of equatorial to polar radii.
earthRadius	Length	the earth equatorial radius in $m$ .
moonEarthMassRatio	double	<b>doc missing</b>
ephemerisEpoch	string	should always be 'J2000'.
earthTideLag	double	<b>doc missing</b>
earthGM	double	the earth gravitation constant in $m^3 s^{-2}$ .
moonGM	double	the moon gravitation constant in $m^3 s^{-2}$ .
sunGM	double	the sun gravitation constant in $m^3 s^{-2}$ .
loveNumberH	double	the earth global Love number H.
loveNumberL	double	the earth global Love number L.
precessionConstant	AngularRate	the general precession constant in $arcsec s^{-1}$ .
lightTime1AU	double	the light time for 1 AU in seconds.
speedOfLight	Speed	the speed of light in $ms^{-1}$ .
delayModelFlags	string	the delay model switches.

#### Column Descriptions:

delayModelFixedParametersId : **long doc missing**

delayModelVersion : **long doc missing**

execBlockId : **long doc missing**



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 74

gaussConstant : long doc missing  
newtonianConstant : long doc missing  
gravity : long doc missing  
earthFlattening : long doc missing  
earthRadius : long doc missing  
moonEarthMassRatio : missing  
ephemerisEpoch : long doc missing  
earthTideLag : missing  
earthGM : long doc missing  
moonGM : long doc missing  
sunGM : long doc missing  
loveNumberH : long doc missing  
loveNumberL : long doc missing  
precessionConstant : long doc missing  
lightTime1AU : long doc missing  
speedOfLight : long doc missing  
delayModelFlags : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 75

### 1.33 DelayModelVariableParameters Table

missing documentation

DelayModelVariableParameters		
Name	Type (Shape)	Comment
<i>Key</i>		
delayModelVariableParametersId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
time	ArrayTime	the day and time relevant for the data in this row.
ut1_utc	double	$UT1 - UTC$ in <i>second</i> .
iat_utc	double	$IAT - UTC$ in <i>second</i> .
timeType	DifferenceType	the type of the two time differences expressed in $ut1_{utc} - iat_{utc}$ in <i>radian</i> .
gstAtUt0	Angle	in $radian s^{-1}$ (the seconds are in <i>IAT</i> ).
earthRotationRate	AngularRate	the $X, Y$ polar offsets in <i>arcsec</i> .
polarOffsets	double [2]	the type of the polar offsets (values found in polarOffsets).
polarOffsetsType	DifferenceType	refers to a unique row of the DelayModelFixedParameters table.
delayModelFixedParametersIdTag		
<i>Optional Data</i>		
nutationsInLongitude	Angle	the nutation in longitude ( the part parallel to the ecliptic) in <i>radian</i> .
nutationsInLongitudeRate	AngularRate	the rate of nutation in longitude in $radian s^{-1}$ .
nutationsInObliquity	Angle	the nutation in obliquity (the part perpendicular to the ecliptic) in <i>radian</i> .
nutationsInObliquityRate	AngularRate	the rate of nutation in obliquity in $radian s^{-1}$ .

#### Column Descriptions:

delayModelVariableParametersId : long doc missing

time : long doc missing

ut1\_utc : long doc missing

iat\_utc : long doc missing

timeType : long doc missing

gstAtUt0 : long doc missing

earthRotationRate : long doc missing

polarOffsets : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 76

polarOffsetsType : long doc missing  
delayModelFixedParametersId : long doc missing  
nututationInLongitude : long doc missing  
nututationInLongitudeRate : long doc missing  
nututationInObliquity : long doc missing  
nututationInObliquityRate : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 77

### 1.34 Doppler Table

Doppler tracking information. This table defines how velocity information is converted into a frequency offset to compensate in real time for the Doppler effect. This table may be omitted for ALMA when the Doppler tracking is not corrected.

Doppler		
Name	Type (Shape)	Comment
<i>Key</i>		
dopplerId	int	identifies a collection of rows in the table. refers to a collection of rows in SourceTable.
sourceId	int	
<i>Required Data</i>		
transitionIndex	int	selects the transition in the source table for which the doppler tracking is done.
velDef	DopplerReferenceCode	identifies the definition of the velocity.

#### Column Descriptions:

dopplerId : Identifies the row in the Doppler Table.

sourceId : Identifies a source in the Source table.

transitionIndex : Identifies a particular spectral transition (for a source in the Source Table).

velDef : Velocity definition of the Doppler Shift, e.g. RADIO or OPTICAL. The value of the velocity is found in the Source Table as `sysVel[transitionIndex]`.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 78

### 1.35 Ephemeris Table

Ephemeris		
Name	Type (Shape)	Comment
<i>Key</i>		
<code>timeInterval</code>	<code>ArrayTimeInterval</code>	interval of time during which the data are relevant.
<code>ephemerisId</code>	<code>int</code>	identifies a collection of rows in the table.
<i>Required Data</i>		
<code>observerLocation</code>	<code>double [3]</code>	<p>a triple of double precision values defining the observer location. This triple contains in that order the longitude, the latitude and the altitude of the observer :</p> <ul style="list-style-type: none"> <li>– the longitude is expressed in radian. An east (resp. west) longitude is denoted as a positive (resp. negative) quantity.</li> <li>– the latitude is expressed in radian. A north (resp. south) latitude is denoted as a positive (resp. negative) quantity.</li> <li>– the altitude is expressed in meter. It's the altitude above the reference ellipsoid.</li> </ul> <p>A triple with all its elements equal to 0.0 will mean that a geocentric coordinate system is in use instead of a topocentric one.</p>
<code>equinoxEquator</code>	<code>double</code>	epoch at which equator and equinox were calculated for ephemeris. Expresses a year as a decimal value (J2000 would be represented as 2000.0).
<code>numPolyDir (<math>N_{Poly}</math>)</code>	<code>int</code>	the number of coefficients of the polynomial stored in phaseDir. It has to be $\geq 1$ .



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 79

Ephemeris – continued from previous page		
Name	Type (Shape)	Comment
<b>dir</b>	double [numPolyDir] [2]	the ephemeris direction expressed in radian. The nominal entry in the phaseDir, delayDir, or ReferenceDir in the Field table serves as additional offset to the direction described by "dir". The actual direction is obtained by composition, e.g. actual phase direction = [phasDir value from Field table] + [dir]. The direction described by dir is the result of the sum $dir_{0,i} + dir_{1,i} * dt + dir_{2,i} * dt^2 + \dots + dir_{numPolyDir-1,i} * dt^{numPolyDir-1}, \forall i \in \{0, 1\}$ where $dt = t - timeOrigin$
numPolyDist ( $N_{Poly}$ )	int	the number of coefficients of the polynomial stored in distance. It has to be $\geq 1$ .
<b>distance</b>	double [numPolyDist]	the coefficients of the polynomial used to calculate the distance, expressed in meter, to the object from the position of the antenna along the given direction. This distance is the result of the sum : $distance_0 + distance_1 * dt + distance_2 * dt^2 + \dots + distance_{numPolyDist-1} * dt^{numPolyDist-1}$ where $dt = t - timeOrigin$ .
<b>timeOrigin</b>	ArrayTime	the time origin used in the evaluation of the polynomial expressions.
<b>origin</b>	string	the origin of the ephemeris information.
<i>Optional Data</i>		
numPolyRadVel ( $N_{Poly}$ )	int	the number of coefficients of the polynomial stored in radVel . It has to be $\geq 1$ .
<b>radVel</b>	double [numPolyRadVel]	the coefficients of a polynomial expressing a radial velocity as a function of the time expressed in m/s. The time origin used to tabulate the polynomial is stored in time-Origin.

### Column Descriptions:

timeInterval : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 80

ephemerisId : long doc missing

observerLocation : long doc missing

equinoxEquator : long doc missing

numPolyDir : long doc missing

dir : long doc missing

numPolyDist : long doc missing

distance : long doc missing

timeOrigin : long doc missing

origin : Typically one should see here e.g. a JPL identifier, eventually orbital parameters, etc...". for example, one might see in that string:

origin = 'JPL Horizons - DE405,JUP230'

In any case, the observing system of ALMA or VLA should feel free to put in there whatever string they think best describes the information.

numPolyRadVel : long doc missing

radVel : long doc missing





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 81

### 1.36 ExecBlock Table

Characteristics of the Execution block.

ExecBlock		
Name	Type (Shape)	Comment
<i>Key</i>		
execBlockId	Tag	identifies a unique row in ExecBlock Table.
<i>Required Data</i>		
startTime	ArrayTime	the start time of the execution block.
endTime	ArrayTime	the end time of the execution block.
execBlockNum	int	indicates the position of the execution block in the project (sequential numbering starting at 1).
execBlockUID	EntityRef	the archive's UID of the execution block.
projectUID	EntityRef	the archive's UID of the project.
configName	string	the name of the array's configuration.
telescopeName	string	the name of the telescope.
observerName	string	the name of the observer.
numObservingLog ( $N_{Obse}$ )	int	the number of elements in the (array) attribute observingLog.
observingLog	string [numObservingLog]	logs of the observation during this execution block.
sessionReference	EntityRef	the observing session reference.
baseRangeMin	Length	the length of the shortest baseline.
baseRangeMax	Length	the length of the longest baseline.
baseRmsMinor	Length	the minor axis of the representative ellipse of baseline lengths.
baseRmsMajor	Length	the major axis of the representative ellipse of baseline lengths.
basePa	Angle	the baselines position angle.
aborted	bool	the execution block has been aborted (true) or has completed (false).
numAntenna ( $N_{Ante}$ )	int	the number of antennas.
antennaId	Tag [numAntenna]	refers to the relevant rows in AntennaTable.
sBSummaryId	Tag	refers to a unique row in SBSummaryTable.
<i>Optional Data</i>		
releaseDate	ArrayTime	the date when the data go to the public domain.
schedulerMode	string	the mode of scheduling.
siteAltitude	Length	the altitude of the site.
siteLongitude	Angle	the longitude of the site.
siteLatitude	Angle	the latitude of the site.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 82

ExecBlock – continued from previous page		
Name	Type (Shape)	Comment
observingScript	string	The text of the observation script.
observingScriptUID	EntityRef	A reference to the Entity which contains the observing script.
scaleId	Tag	refers to a unique row in the table Scale.

### Column Descriptions:

**execBlockId** : Identifies the row in the ExecBlock Table.

**startTime** : Scheduled time of start of data taking.

**endTime** : Scheduled time of end of data taking.

**execBlockNum** : Number of the ExecBlock: in ALMA Execution blocks in a project are consecutively numbered starting from 1.

**execBlockUID** : Archive UID of the ExecBlock (the container of the data set).

**projectUID** : The archive UID of the Project.

**configName** : Name of the array baseline configuration.

**telescopeName** : Name of the telescope (e.g. 'ALMA')

**observerName** : Name of the observer.

**numObservingLog** : **long doc missing**

**observingLog** : Logs of observations (information entered at execution time by the Operator).

**sessionReference** : This is useful for grouping execblocks. Data capture know the session reference so this information is easily available.

**baseRangeMin** : Length of the minimum baseline. For Alma this is expected to be filled from the unprojected baselines available in the array being used in this ExecBlock.

**baseRangeMax** : Length of the maximum baseline. For Alma this is expected to be filled from the unprojected baselines available in the array being used in this ExecBlock.

**baseRmsMinor** : Minor axis of the representative ellipse of baseline lengths. For Alma this is expected to be filled from the unprojected baselines available in the array being used in this ExecBlock.

**baseRmsMajor** : Major axis of the representative ellipse of baseline lengths. For Alma this is expected to be filled from the unprojected baselines available in the array being used in this ExecBlock.

**basePa** : Position angle of the major axis on the representative ellipse of baseline lengths. For Alma this is expected to be filled from the unprojected baselines available in the array being used in this ExecBlock.

**aborted** : Set when the execution was aborted.

**numAntenna** : Number of antennas used in the ExecBlock.

**antennaId** : Antenna Table identifier.

**sBSummaryId** : SBSummary Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 83

`releaseDate` : The date when the data will become public.  
`schedulerMode` : Mode of the Scheduling when this data was taken (Dynamic, Interactive, ...)  
`siteAltitude` : Latitude of the site (array center).  
`siteLongitude` : Longitude of the site (array center).  
`siteLatitude` : Latitude of the site (array center).  
`observingScript` : long doc missing  
`observingScriptUID` : long doc missing  
`scaleId` : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 84

### 1.37 Feed Table

Contains characteristics of the feeds.

Feed		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
timeInterval	ArrayTimeInterval	the time interval of validity of the content of the row.
feedId	int	identifies a collection of rows in the table.
<i>Required Data</i>		
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
beamOffset	double [numReceptor] [2]	the offsets of the beam (one pair per receptor).
focusReference	Length [numReceptor] [3]	the references for the focus position (one triple per receptor).
polarizationTypes	PolarizationType [numReceptor]	identifies the polarization types (one value per receptor).
polResponse	Complex [numReceptor] [numReceptor]	the polarization response (one value per pair of receptors).
receptorAngle	Angle [numReceptor]	the receptors angles (one value per receptor).
receiverId	int [numReceptor]	refers to one or more collections of rows in ReceiverTable.
<i>Optional Data</i>		
feedNum	int	the feed number to be used for multi-feed receivers.
illumOffset	Length [2]	the illumination offset.
position	Length [3]	the position of the feed.
skyCoupling	float	the sky coupling is the coupling efficiency to the sky of the WVR radiometer's. Note that in general one expects to see whether <u>no</u> sky coupling efficiency recorded or <u>only one</u> of the two forms scalar (skyCoupling) or array (skyCouplingSpectrum, numChan).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 85

Feed – continued from previous page		
Name	Type (Shape)	Comment
numChan ( $N_{Chan}$ )	int	the size of skyCouplingSpectrum. This attribute must be present when the (array) attribute skyCouplingSpectrum is present since it defines its number of elements. The value of this attribute must be equal to the value of numChan in the row of the SpectralWindow table referred to by spectralWindowId.
skyCouplingSpectrum	float [numChan]	the sky coupling is the coupling efficiency to the sky of the WVR radiometer's. This column differs from the skyCoupling column because it contains one value for each of the individual channels of that spectralWindow. See the documentation of numChan for the size and the presence of this attribute. Note that in general one expects to see whether <u>no</u> sky coupling efficiency recorded or <u>only one</u> of the two forms scalar (skyCoupling) or array (skyCouplingSpectrum, numChan).

### Column Descriptions:

antennaId : Antenna Table identifier.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Time Interval of validity of the feed information.

feedId : Feed Table identifier.

numReceptor : The number of receptors for which the result is given.

beamOffset : Offset of the beam.

focusReference : Reference for the focus position.

polarizationTypes : The polarization types of the receptors being used.

polResponse : The polarization response of the receptors.

receptorAngle : Position angle for X polarization direction.

receiverId : Points to the receivers corresponding to this feed.

feedNum : Feed number is to be used for multi-feed receivers (there are none in ALMA; so feedNum is always one).

illumOffset : Illumination offset for this feed, measured in linear distance from the center of the primary reflector. REFLECTOR



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 86

position : The position of the feed.

skyCoupling : long doc missing

numChan : long doc missing

skyCouplingSpectrum : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 87

### 1.38 Field Table

The field position for each source.

Field		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>fieldId</b>	<b>Tag</b>	identifies a unique row in the table.
<i>Required Data</i>		
<b>fieldName</b>	string	the name of the field.
<b>numPoly</b> ( $N_{Poly}$ )	int	number of coefficients of the polynomials.
<b>delayDir</b>	Angle [numPoly] [2]	the delay tracking direction.
<b>phaseDir</b>	Angle [numPoly] [2]	the phase tracking direction.
<b>referenceDir</b>	Angle [numPoly] [2]	the reference direction.
<i>Optional Data</i>		
<b>time</b>	ArrayTime	value used as the origin for the polynomials.
<b>code</b>	string	describes the function of the field.
<b>directionCode</b>	DirectionReferenceCode	the direction reference code of the field.
<b>directionEquinox</b>	ArrayTime	the direction reference equinox of the field.
<b>assocNature</b>	string	identifies the nature of the association with the row referred to by fieldId.
<b>ephemerisId</b>	int	refers to a collection of rows in the EphemerisTable.
<b>sourceId</b>	int	refers to a collection of rows in SourceTable.
<b>assocFieldId</b>	Tag	Associated Field ID

#### Column Descriptions:

**fieldId** : Field Table identifier.

**fieldName** : Name of this Field (usually a representative source, or one of several fields in a mosaic).

**numPoly** : Number of coefficients used for polynomial expansion of tracked directions.

**delayDir** : Direction in the sky for which delays due to Earth motion are compensated in real time  
 directionCodedirectionEquinox-

**phaseDir** : Direction in the sky for which phases due to Earth motion are tracked in real time  
 directionCodedirectionEquinox-

**referenceDir** : Direction of reference.

- In Interferometry this is the correlated field center (common pointing direction for all antennas)

- In single dish this is the reference direction directionCodedirectionEquinox-

**time** : Used as an origin for expansion polynomials for tracked directions.

**code** : Used to identify the function of this field (target, calibration, etc.). Purely informative.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 88

`directionCode` : The common reference code for field directions in the row, if not J2000.

`directionEquinox` : The common reference equinox for field directions in the row, if required by `directionCode`.

`assocNature` : Gives the meaning of Associated Field rows.

`ephemerisId` : **long doc missing**

`sourceId` : Source Table identifier.

`assocFieldId` : Refers to a unique associate row in the table.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 89

### 1.39 Flag Table

This table is used for flagging visibility data and is used in addition to the Binary Data Format flags produced by the correlator software.

Flag		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>flagId</b>	<b>Tag</b>	identifies a unique row in the table.
<i>Required Data</i>		
<b>startTime</b> <b>endTime</b> <b>reason</b> <b>numAntenna</b> ( $N_{Ante}$ )  <b>antennaId</b>	<b>ArrayTime</b> <b>ArrayTime</b> <b>string</b> <b>int</b>  <b>Tag</b> [numAntenna]	the start time of the flagging period. the end time of the flagging period. Extensible list of flagging conditions. The number of antennas to which the flagging refers. By convention numAntenna==0 means that the flag applies to all the existing antennas, in such a case the array antennaId can be left empty. An array of Tag which refers to a collection of rows in the Antenna table. The flag applies to the antennas described in these rows. It is an error to have different elements with a same value in this array.
<i>Optional Data</i>		
<b>numPolarizationType</b> ( $N_{Pola}$ )	<b>int</b>	The number of polarization types , i.e. the size of the attribute polarizationType. By convention numPolarizationType == 0 means that the flag applies to all the defined polarization types. Remark : numPolarizationType and polarizationType, both optional, must be both present or both absent in one same row of the table, except if numPolarizationType==0 in which case all the defined polarization types are involved in the flagging.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 90

Flag – continued from previous page		
Name	Type (Shape)	Comment
<code>numSpectralWindow</code> ( $N_{Spec}$ )	<code>int</code>	The number of spectral windows targeted by the flagging. By convention <code>numSpectralWindow == 0</code> means that the flag applies to all the existing spectral windows. Remark : <code>numSpectralWindow</code> and <code>spectralWindow</code> , both optional, must be both present or both absent in one same row of the table, except if <code>numSpectralWindow==0</code> , in which case all the declared spectral windows are involved in the flagging.
<code>numPairedAntenna</code> ( $N_{Pair}$ )	<code>int</code>	The number of antennas to be paired with to form the flagged baselines. By convention, <code>numPairedAntenna == 0</code> means that the flag applies to all baselines built on the antennas declared in the attribute <code>antennaId</code> . Remark: <code>numPairedAntenna</code> and <code>pairedAntenna</code> , both optional, must be both present or both absent except if <code>numPairedAntenna==0</code> in which case one has to consider all the baselines defined upon the antennas announced in <code>antennaId</code> .
<code>numChan</code> ( $N_{Chan}$ ) <code>polarizationType</code>	<code>int</code> <code>PolarizationType</code> <code>[numPolarizationType]</code>	Number of channels to be flagged. An array of values of type <code>PolarizationType</code> . It specifies the polarization types where the flagging applies. It is an error to have different elements with a same value in this array.
<code>channel</code>	<code>int [numChan] [3]</code>	An array of triplets where the first element is the number <code>spectralWindowId</code> . The second and third values are the <code>startChannel</code> and <code>endChannel</code> , respectively, which specify the channels where flagging applies. It is an error to have different elements with a same value in this array.
<code>pairedAntennaId</code>	<code>Tag [numPairedAntenna]</code>	An array of <code>Tag</code> which refers to rows in the <code>Antenna</code> table. These rows contain the description of the antennas which are paired to form the flagged baselines. It is an error to have distinct elements with a same value in this array.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 91

### Flag – continued from previous page

Name	Type (Shape)	Comment
spectralWindowId	Tag [numSpectralWindow]	An array of Tag which refers to a collection of rows in the SpectralWindow table. The flag applies to the spectral windows described in these rows. It is an error to have different elements with a same value in this array.

### Column Descriptions:

flagId : long doc missing  
 startTime : long doc missing  
 endTime : long doc missing  
 reason : long doc missing  
 numAntenna : long doc missing  
 antennaId : long doc missing  
 numPolarizationType : long doc missing  
 numSpectralWindow : long doc missing  
 numPairedAntenna : long doc missing  
 numChan : long doc missing  
 polarizationType : long doc missing  
 channel : long doc missing  
 pairedAntennaId : long doc missing  
 spectralWindowId : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 92

### 1.40 Focus Table

Contains the focus information.

Focus		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId timeInterval	Tag ArrayTimeInterval	refers to a unique row in AntennaTable. time interval for which the row's content is valid.
<i>Required Data</i>		
focusTracking	bool	the focus motions have been tracked (true) or not tracked (false).
focusOffset	Length [3]	focus offset relative to the tracked position (a triple).
focusRotationOffset	Angle [2]	focus rotation offset relative to the tracked position (tip, tilt).
focusModelId	int	refers to a collection of rows in FocusModelTable.
<i>Optional Data</i>		
measuredFocusPosition	Length [3]	the measured focus position.
measuredFocusRotation	Angle [2]	the measured focus rotation (tip, tilt).

#### Column Descriptions:

antennaId : Antenna Table identifier.

timeInterval : Time Interval of validity of the focus information.

focusTracking : Set if the subreflector was tracking the focus motions.

focusOffset : Focus offset introduced relative to the tracked position REFLECTORVirtual

focusRotationOffset : **long doc missing**

focusModelId : Specifies which Focus Model was used (FocusModel Table).

measuredFocusPosition : Measured Focus position. REFLECTOR

measuredFocusRotation : **long doc missing**



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 93

### 1.41 FocusModel Table

Contains the focus model data (function of elevation and temperature).

FocusModel		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>antennaId</b>	<b>Tag</b>	refers to a unique row in AntennaTable.
<b>focusModelId</b>	<b>int</b>	refers to a collection of rows in the table.
<i>Required Data</i>		
<b>polarizationType</b>	<b>PolarizationType</b>	identifies the polarization type.
<b>receiverBand</b>	<b>ReceiverBand</b>	identifies the receiver band.
<b>numCoeff</b> ( $N_{Coeff}$ )	<b>int</b>	the number of coefficients.
<b>coeffName</b>	<b>string [numCoeff]</b>	the names of the coefficients (one string per coefficient).
<b>coeffFormula</b>	<b>string [numCoeff]</b>	textual representations of the fitted functions (one string per coefficient).
<b>coeffVal</b>	<b>float [numCoeff]</b>	the values of the coefficients used (one value per coefficient).
<b>assocNature</b>	<b>string</b>	nature of the association with the row referred to by associatedFocusModelId.
<b>assocFocusModelId</b>	<b>int</b>	refers to a collection of rows in the table.

#### Column Descriptions:

**antennaId** : Antenna Table identifier.

**focusModelId** : Identifies the focus model.

**polarizationType** : Polarization component for which the focus model is valid.

**receiverBand** : The name of the front-end frequency band being used.

**numCoeff** : The number of coefficients in the analytical form of the model.

**coeffName** : Given names of coefficients.

**coeffFormula** : Analytical formula: explains the function fitted (e.g.  $\cos(el)$  or  $\ln(T)$ ).

**coeffVal** : The values of the coefficients used.

**assocNature** : Nature of associated focus model, e.g., receiver-specific, local, ...

**assocFocusModelId** : Associates another focus model used in addition. Used for the auxiliary pointing model (e.g. the local pointing model). The actual associated row is obtained by associating the current **antennaId** with **associatedFocusModelId** to form the key.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 94

### 1.42 FreqOffset Table

Frequency offset information. Contains an additional antenna-based frequency offset relative to the frequencies in the Spectral Windows. Useful for such thing as Doppler tracking.

FreqOffset		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
timeInterval	ArrayTimeInterval	the time interval of validity of the row's content.
feedId	int	refers to a collection of rows in FeedTable.
<i>Required Data</i>		
offset	Frequency	frequency offset.

#### Column Descriptions:

antennaId : Antenna Table identifier.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Time Interval of validity of the frequency offset information.

feedId : Specifies which feed was used in the Feed Table.

offset : Frequency offset to be added to the frequency set in the spectral window Table.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 95

### 1.43 GainTracking Table

Gain tracking information. Contains variable control parameters affecting the signal coming from a receiver in an antenna.

GainTracking		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
timeInterval	ArrayTimeInterval	time interval for which the row's content is valid.
feedId	int	refers to a unique row in Feed Table
<i>Required Data</i>		
numReceptor ( $N_{Rece}$ )	int	the number of receptors.
attenuator	float [numReceptor]	the nominal value of the attenuator (one value per receptor).
polarizationType	PolarizationType [numReceptor]	describes the polarizations of the receptors (one value per receptor).
<i>Optional Data</i>		
samplingLevel	float	the sampling level.
numAttFreq ( $N_{AttF}$ )	int	the sizes of attSpectrum and attFreq.
attFreq	double [numAttFreq]	the attenuator frequencies.
attSpectrum	Complex [numAttFreq]	the attenuator's measured spectrum.

#### Column Descriptions:

antennaId : Antenna Table identifier.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Time Interval of validity of the feed information.

feedId : Specifies which feed was used in the Feed Table.

numReceptor : The number of receptors.

attenuator : Gain due to the hardware attenuation selected for the Spectral window in this antenna. This is the nominal value of the attenuator.

polarizationType : The polarization types of the receptors being used.

samplingLevel : Correlator sampling level. Cannot change for ALMA...

numAttFreq : Number of frequency points in attSpectrum

attFreq : Frequencies for the values in attSpectrum.

attSpectrum : Gain due to the hardware attenuation selected for the Spectral window in this antenna. This is the actual calibrated spectrum measured in the lab (complex values) as a function of frequency.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 96

### 1.44 Holography Table

Used for Single-Dish holography with a fixed transmitter.

Holography		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>holographyId</b>	<b>Tag</b>	identifies a unique row in the table.
<i>Required Data</i>		
<b>distance</b>	<b>Length</b>	the distance to transmitter.
<b>focus</b>	<b>Length</b>	displacement of the feed from the primary nominal focus.
<b>numCorr</b> ( $N_{Corr}$ )	<b>int</b>	the number of stored correlations.
<b>type</b>	<b>HolographyChannelType</b> [numCorr]	identifies the types of the correlation signals.

#### Column Descriptions:

**holographyId** : Identifies the row in the Holography Table.

**distance** : Distance from intersection of mount axes to transmitter.

**focus** : Displacement of signal feed from the primary nominal focus, used to compensate for the finite distance of transmitter.

**numCorr** : Number of correlations stored (3 autocorrelations, 3 correlations from the 3 receptors (signal feed, reference feed, quadrature signal feed)).

**type** : Identifies each of the numCorr correlation signals.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 97

### 1.45 Pointing Table

Antenna pointing information.

Pointing		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
timeInterval	ArrayTimeInterval	the time interval of validity of the row's content.
<i>Required Data</i>		
numSample ( $N_{Sample}$ )	int	the number of time samples.
encoder	Angle [numSample] [2]	Encoder values
pointingTracking	bool	the antenna was in tracking mode (true) or not (false).
usePolynomials	bool	use polynomials expansions (true) or not (false).
timeOrigin	ArrayTime	the value used as origin in the polynomials expansions.
numTerm ( $N_{Term}$ )	int	the number of terms of the polynomials.
pointingDirection	Angle [numTerm] [2]	the commanded pointing direction.
target	Angle [numTerm] [2]	the direction of the target.
offset	Angle [numTerm] [2]	Horizon mapping offsets
pointingModelId	int	refers to a collection of rows in Pointing-ModelTable.
<i>Optional Data</i>		
overTheTop	bool	pointing at elevations larger than 90 degrees (true) or lower (false).
sourceOffset	Angle [numTerm] [2]	sources offsets (one pair per term of the polynomial).
sourceOffsetReferenceCode	DirectionReferenceCode	the direction reference code associated to the source offset.
sourceOffsetEquinox	ArrayTime	the equinox information (if needed by sourceReferenceCode).
sampledTimeInterval	ArrayTimeInterval [numSample]	an array of ArrayTimeInterval which must be given explicitly as soon as the data are irregularly sampled.
atmosphericCorrection	Angle [numTerm] [2]	This is the correction applied to the commanded position to take into account refraction and any other atmospheric effects. This term will always be zero if there is no atmosphere. For ALMA this is the atmospheric refraction correction and will result in a correction in just the elevation axis.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 98

### Column Descriptions:

**antennaId** : Antenna Table identifier.

**timeInterval** : Time Interval of validity of the feed information.

**numSample** : The number of time samples for **encoder**. The sampling intervals divide **timeInterval** into  $N_{Samp}$  contiguous intervals of equal duration. This is also used for the other direction columns (**offset**, **pointingDirection**, **target**, **sourceOffset**) when **usePolynomials** is **false**: in that case  $N_{Term} = N_{Samp}$ .

**encoder** : The values measured from the antenna. They may be however affected by metrology, if applied. Note that for ALMA this column will contain positions obtained using the AZ\_POSN\_RSP and EL\_POSN\_RSP monitor points of the ACU and not the GET\_AZ\_ENC and GET\_EL\_ENC monitor points (as these do not include the metrology corrections). It is agreed that the the vendor pointing model will never be applied.  
AZELNOWAntenna.position

**pointingTracking** : Indicates that the antenna is in tracking mode.

**usePolynomials** : See **numSample** and **numTerm**.

**timeOrigin** : The time origin for polynomial expansions of **pointingDirection**, **target**, **offset**, and **sourceOffset**. Equal to the midpoint of **timeInterval** if  $N_{Term}=1$ .

**numTerm** :

- If **usePolynomials** is **false**:  $N_{Term} = N_{Samp}$ , and the values in the direction columns (**offset**, **pointingDirection**, **target**, **sourceOffset**) correspond to the same sampling intervals used for **encoder**.
- If **usePolynomials** is **true**:  $N_{Term}$  is the number of terms in the polynomial expansion for the direction columns (**offset**, **pointingDirection**, **target**, **sourceOffset**). The time origin for these polynomials is **timeOrigin**.

**pointingDirection** : This is the commanded direction of the antenna. It is obtained by adding the **target** and **offset** columns, and then applying the pointing model referenced by **PointingModelId**. The pointing model can be the composition of the absolute pointing model and of a local pointing model. In that case their coefficients will both be in the **PointingModel** table.

**target** : This is the field center direction (as given in the Field Table), possibly affected by the optional antenna-based **sourceOffset**. This column is in horizontal coordinates. AZELNOWAntenna.position

**offset** : Additional offsets in horizontal coordinates (usually meant for measuring the pointing corrections, mapping the antenna beam, ...). AZELNOWAntenna.positiontarget

**pointingModelId** : Link to the pointing model applied.

**overTheTop** : The antenna is pointing at elevations larger than 90 degrees. Deprecated for ALMA, should not happen.

**sourceOffset** : Optionally, the antenna-based mapping offsets in the field. These are in the equatorial system, and used, for instance, in on-the-fly mapping when the antennas are driven independently across the field.

**sourceOffsetReferenceCode** : Source offset reference code, defaults to J2000.

**sourceOffsetEquinox** : Source offset equinox, if needed by **sourceOffsetReference**.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 99

sampledTimeInterval : long doc missing  
atmosphericCorrection : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 100

### 1.46 PointingModel Table

The pointing models used to point the antennas.

PointingModel		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>antennaId</b>	<b>Tag</b>	refers to a unique row in AntennaTable. pointingModel identifier
<b>pointingModelId</b>	<b>int</b>	
<i>Required Data</i>		
<b>numCoeff</b> ( $N_{Coef}$ )	<b>int</b>	the number of coefficients used in the analytical form of the model. the names of the coefficients. the values of the coefficients. identifies the polarization type. identifies the receiver band. nature of the association with the row referred to by associatedPointingModelId. refers to a collection of rows in the table.
<b>coeffName</b>	<b>string [numCoeff]</b>	
<b>coeffVal</b>	<b>float [numCoeff]</b>	
<b>polarizationType</b>	<b>PolarizationType</b>	
<b>receiverBand</b>	<b>ReceiverBand</b>	
<b>assocNature</b>	<b>string</b>	
<b>assocPointingModelId</b>	<b>int</b>	
<i>Optional Data</i>		
<b>coeffFormula</b>	<b>string [numCoeff]</b>	the fitted functions

#### Column Descriptions:

**antennaId** : Antenna Table identifier.

**pointingModelId** : Identifies the pointing model used.

**numCoeff** : The number of coefficients in the analytical form of the model.

**coeffName** : Standard names used by tpoint.

**coeffVal** : The values of the coefficients used.

**polarizationType** : Polarization component for which the pointing model is valid.

**receiverBand** : The name of the front-end frequency band being used.

**assocNature** : Nature of the associated pointing model: e.g. local pointing model, receiver-specific.

**assocPointingModelId** : Associates another pointing model used in addition. Used for the auxiliary pointing model (e.g. local pointing model, ...). The actual associated row is obtained by associating the current **antennaId** with **associatedPointingModelId** to form the key.

**coeffFormula** : Analytical formulae. This is not needed for ALMA as we use tpoint generic coefficients.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 101

### 1.47 Polarization Table

Polarization information.

Polarization		
Name	Type (Shape)	Comment
<i>Key</i>		
polarizationId	Tag	Polarization Table identifier
<i>Required Data</i>		
numCorr ( $N_{Corr}$ )	int	Number of correlation products
corrType	StokesParameter [numCorr]	Correlation type
corrProduct	PolarizationType [numCorr] [2]	Correlation product.

#### Column Descriptions:

**polarizationId** : Polarization Table identifier.

**numCorr** : The number of correlation products. This could be 1 (e.g. XX or YY), 2 (e.g. XX and YY), 3 (full polarization for auto-correlation), or 4 (full polarization for cross-correlation).

**corrType** : For each correlation product this indicates the Stokes type as defined in the Stokes parameters enumeration.

**corrProduct** : For each correlation product, a pair of integers, specifying the receptors from which the signal originated. The polarization of each receptor is defined in the **polarizationType** column in the Feed table. An example would be (0,0), (0,1), (1,0), (1,1) to specify all possible correlation products between two receptors.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 102

### 1.48 Processor Table

Processor characteristics. This table holds summary information for the back-end processing devices used to generate the basic science data.

Processor		
Name	Type (Shape)	Comment
<i>Key</i>		
<code>processorId</code>	<code>Tag</code>	Processor identifier
<i>Required Data</i>		
<code>modeId</code>	<code>Tag</code>	refers to a unique row in CorrelatorModeTable or SquareLawDetectorTable or AlmaRadiometerTable.
<code>processorType</code>	<code>ProcessorType</code>	identifies the generic type of the processor.
<code>processorSubType</code>	<code>ProcessorSubType</code>	identifies the type of processor referred to by modeId.

#### Column Descriptions:

`processorId` : Processor Table identifier.

`modeId` : Processor table identifier.

`processorType` : The generic type of processor used.

`processorSubType` : Identifies the SDM table containing the processor-dependent information.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 103

### 1.49 Pulsar Table

Polarization information.

Pulsar		
Name	Type (Shape)	Comment
<i>Key</i>		
pulsarId	Tag	Pulsar Table identifier
<i>Required Data</i>		
refTime	ArrayTime	Reference time for a polynomial
refPulseFreq	Frequency	Reference pulse frequency
refPhase	double	Reference pulse phase (turns)
numBin ( $N_{Bin}$ )	int	Number of phase bins
<i>Optional Data</i>		
numPoly ( $N_{Poly}$ )	int	Number of polynomial coefficients
phasePoly	double [numPoly]	The phase polynomial coefficients (Tempo units)
timeSpan	Interval	Time range over which the polynomial is valid
startPhaseBin	float [numBin]	Start phase for each bin (turns)
endPhaseBin	float [numBin]	End phase for each bin (turns)
dispersionMeasure	double	Dispersion measure applied, if data have been dedispersed (pc cm <sup>3</sup> )
refFrequency	Frequency	Reference radio frequency for dedispersion

#### Column Descriptions:

pulsarId : Pulsar Table identifier.

refTime : long doc missing

refPulseFreq : long doc missing

refPhase : long doc missing

numBin : long doc missing

numPoly : long doc missing

phasePoly : long doc missing

timeSpan : long doc missing

startPhaseBin : long doc missing

endPhaseBin : long doc missing

dispersionMeasure : long doc missing

refFrequency : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 104

### 1.50 Receiver Table

Receiver properties.

Receiver		
Name	Type (Shape)	Comment
<i>Key</i>		
receiverId	int	Receiver identifier
spectralWindowId	Tag	refers to a unique row in SpectralwindowTable.
timeInterval	ArrayTimeInterval	time interval for which the content is valid.
<i>Required Data</i>		
name	string	the name of the frontend.
numLO ( $N_{LO}$ )	int	the number of frequencies of the local oscillator.
frequencyBand	ReceiverBand	identifies the band of frequencies.
freqLO	Frequency [numLO]	the frequencies of the local oscillator.
receiverSideband	ReceiverSideband	the receiver sideband used.
sidebandLO	NetSideband [numLO]	the sideband conversions.

#### Column Descriptions:

receiverId : Receiver Table identifier. Note that this is always zero for ALMA.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Time Interval of validity of the receiver information.

name : Name of the frontend.

numLO : The number of frequency changes in the receiver chain.

frequencyBand : The name of this frequency band (bands 1 to 10 for ALMA) These correspond to receiver cartridges in the ALMA dewars.

freqLO : Frequencies of the Local Oscillators in the receiving chain.

receiverSideband : The receiver sideband used.

sidebandLO : The sideband conversion for each of the local oscillators. Used to check the frequency plan.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 105

### 1.51 SBSummary Table

Characteristics of the Scheduling Block that has been executed. Much of the data here is reproduced from the Scheduling block itself.

SBSummary		
Name	Type (Shape)	Comment
<i>Key</i>		
sBSummaryId	Tag	refers to a unique row in the table.
<i>Required Data</i>		
sbSummaryUID	EntityRef	the scheduling block archive's UID.
projectUID	EntityRef	the projet archive's UID.
obsUnitSetUID	EntityRef	the observing unit set archive's UID.
frequency	double	a representative frequency.
frequencyBand	ReceiverBand	the frequency band.
sbType	SBType	the type of scheduling block.
sbDuration	Interval	the duration of the scheduling block.
numObservingMode ( $N_{Obse}$ )	int	the number of observing modes.
observingMode	string [numObservingMode]	the observing modes.
numberRepeats ( $N_{berR}$ )	int	the number of repeats.
numScienceGoal ( $N_{Scie}$ )	int	the number of scientific goals.
scienceGoal	string [numScienceGoal]	the scientific goals.
numWeatherConstraint ( $N_{Weat}$ )	int	the number of weather constraints.
weatherConstraint	string [numWeatherConstraint]	the weather constraints.
<i>Optional Data</i>		
centerDirection	Angle [2]	the representative target direction.
centerDirectionCode	DirectionReferenceCode	identifies the direction reference frame associated with centerDirection.
centerDirectionEquinox	ArrayTime	the equinox associated to centerDirection-ReferenceCode (if needed).

#### Column Descriptions:

sBSummaryId : Identifies each row of the SBSummary table.

sbSummaryUID : Archive UID of the scheduling block.

projectUID : Archive UID of the project.

obsUnitSetUID : Archive UID of the observing unit set.

frequency : Representative frequency.

frequencyBand : Frequency band used for the SB.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 106

**sbType** : Type of Scheduling Block (e.g. science, calibration, ...)

**sbDuration** : The duration of this SB (as planned).

**numObservingMode** : The number of observing modes.

**observingMode** : Standard observing mode, e.g. singleField, mosaic. One SB cannot have more than one standard observing mode. Examples: Single Field Interferometry, Pointed Mosaic, ...

**numberRepeats** : Number of executions scheduled for this SB.

**numScienceGoal** : Number of science goals.

**scienceGoal** : The science goals.

**numWeatherConstraint** : The number of weather constraints.

**weatherConstraint** : Weather scheduling constraints, as specified in the Observing Tool.

**centerDirection** : Direction of the representative target.

**centerDirectionCode** : The center direction reference code, if not J2000.

**centerDirectionEquinox** : The center direction reference equinox, if required by **centerDirectionCode**.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 107

### 1.52 Scale Table

Specifies the time scales and units used in the dataset.

Scale		
Name	Type (Shape)	Comment
<i>Key</i>		
scaleId	Tag	identifies a unique row in the table Scale.
<i>Required Data</i>		
timeScale	TimeScale	a TimeScale value.
crossDataScale	DataScale	the unit of the cross data in the BDF.
autoDataScale	DataScale	the unit of the auto data in the BDF.
weightType	WeightType	a type of weighting.

#### Column Descriptions:

scaleId : long doc missing

timeScale : long doc missing

crossDataScale : long doc missing

autoDataScale : long doc missing

weightType : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 108

### 1.53 Scan Table

A summary of information for each scan.

Scan		
Name	Type (Shape)	Comment
<i>Key</i>		
<code>execBlockId</code>	Tag	refers to a unique row in ExecBlockTable.
<code>scanNumber</code>	int	the scan number.
<i>Required Data</i>		
<code>startTime</code>	ArrayTime	the actual start time of the scan.
<code>endTime</code>	ArrayTime	the actual end time of the scan.
<code>numIntent</code> ( $N_{Inte}$ )	int	the number of intents for this scan.
<code>numSubscan</code> ( $N_{Subs}$ )	int	the number of subscans contained by this scan.
<code>scanIntent</code>	ScanIntent [numIntent]	identifies the intents of this scan.
<code>calDataType</code>	CalDataOrigin [numIntent]	identifies the calibration data types (one value per intent).
<code>calibrationOnLine</code>	bool [numIntent]	the online calibration was required (true) or not (false) (one value per intent).
<i>Optional Data</i>		
<code>calibrationFunction</code>	CalibrationFunction [numIntent]	identifies the calibration functions (one value per intent).
<code>calibrationSet</code>	CalibrationSet [numIntent]	attaches this scan to a calibration set (one value per intent).
<code>calPattern</code>	AntennaMotionPattern [numIntent]	identifies the antenna motion patterns used for the calibration.
<code>numField</code> ( $N_{Fiel}$ )	int	the number of fields observed.
<code>fieldName</code>	string [numField]	the names of the observed fields (one value per field).
<code>sourceName</code>	string	the name of the observed source.

#### Column Descriptions:

`execBlockId` : ExecBlock Table identifier.

`scanNumber` : The scan number. This increments starting from 1 in each Execution Block.

`startTime` : The time when this scan actually started acquiring data.

`endTime` : The time when this scan actually finished acquiring data.

`numIntent` : The scan intents for this scan.

`numSubscan` : The number of subscans used to achieve this scan.

`scanIntent` : The scan intents for this scan.

`calDataType` : Calibration data type used for data reduction.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 109

`calibrationOnLine` : True if on-line calibration was required.

`calibrationFunction` : Function of the scan in the calibration set. This is used in on-line calibration.

`calibrationSet` : Identifies that the scan is part of a set of scans aimed at a particular calibration.

`calPattern` : Identifies the antenna motion pattern used for calibration; data reduction may use this information.

`numField` : The number of fields observed during this scan.

`fieldName` : The names of the fields observed during this scan.

`sourceName` : The name of the source observed (optional).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 110

### 1.54 Source Table

Summary of astronomical source information.

Source		
Name	Type (Shape)	Comment
<i>Key</i>		
sourceId	int	identifies a collection of rows in the table.
timeInterval	ArrayTimeInterval	the time interval of validity of the row's content.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
<i>Required Data</i>		
code	string	indicates the nature of the source.
direction	Angle [2]	the direction of the source.
properMotion	AngularRate [2]	the proper motion of the source.
sourceName	string	the name of the source.
<i>Optional Data</i>		
directionCode	DirectionReferenceCode	identifies the direction reference frame associated to direction.
directionEquinox	ArrayTime	the equinox associated to the direction reference frame (if required).
calibrationGroup	int	the calibration group number.
catalog	string	the name of the catalog.
deltaVel	Speed	the velocity resolution.
position	Length [3]	the position of the source.
numLines ( $N_{Line}$ )	int	the number of line transitions.
transition	string [numLines]	the names of the transitions.
restFrequency	Frequency [numLines]	the rest frequencies (one value per transition line).
sysVel	Speed [numLines]	the systemic velocity.
rangeVel	Speed [2]	the velocity range.
sourceModel	SourceModel	identifies the source model.
frequencyRefCode	FrequencyReferenceCode	the frequency reference code.
numFreq ( $N_{Freq}$ )	int	the number of frequencies.
numStokes ( $N_{Stok}$ )	int	the number of Stokes parameters.
frequency	Frequency [numFreq]	the array of frequencies (one value per frequency).
frequencyInterval	Frequency [numFreq]	an array of frequency intervals (one value per interval).
stokesParameter	StokesParameter [numStokes]	the array of Stokes parameters (one value per parameter).
flux	Flux [numFreq] [numStokes]	the array of flux densities expressed in Jansky (Jy).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 111

Source – continued from previous page		
Name	Type (Shape)	Comment
fluxErr	Flux [numFreq] [numStokes]	the array of uncertainties on flux densities.
positionAngle	Angle [numFreq]	the major axis position angles (one value per frequency).
positionAngleErr	Angle [numFreq]	the uncertainties on major axis position angles.
size	Angle [numFreq] [2]	the sizes of source (one pair of values per frequency).
sizeErr	Angle [numFreq] [2]	the uncertainties on the source sizes (one pair of value per frequency).
velRefCode	RadialVelocityReferenceCode	the velocity reference code for velocities: sysVel, rangeVel, deltaVel.

### Column Descriptions:

- sourceId : Identifies each row of the Source table.
- timeInterval : Time Interval of validity of the source information.
- spectralWindowId : SpectralWindow Table identifier.
- code : Source code, e.g., Bandpass calibrator.
- direction : The source direction, usually EQ J2000. directionCodedirectionEquinox-
- properMotion : Source proper motion (change of directiuon with time).
- sourceName : The source name (please respect UAI/IAU standard conventions).
- directionCode : The source direction reference code, if not J2000.
- directionEquinox : The source direction reference equinox , if required by directionCode.
- calibrationGroup : Used to group sources for calibration purposes (kept for further use).
- catalog : Gives the origin for source information if taken from a catalog.
- deltaVel : Velocity resolution required for this source (from observer input; kept for further use).
- position : Source position (when 3-dimentional information is available, like a local transmitter). ITRF
- numLines : Number of line transitions for which information is given.
- transition : The line of each spectral line transition.
- restFrequency : The rest frequency for each transition considered. LABREST
- sysVel : The source radial velocity in each of the line transitions. LSR
- rangeVel : Range of radial velocities present in the source (for spectroscopy).
- sourceModel : A model for source.
- frequencyRefCode : The reference code for frequency (if not LSRK)
- numFreq : The number of frequencies for which parameters are provided.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 112

**numStokes** : The number of Stokes parameters that are provided at each frequency.

**frequency** : The list of frequencies for the flux densities LSRK

**frequencyInterval** : The list of frequency intervals over which flux densities were measured.

**stokesParameter** : The array of Stokes parameters (one value per parameter).

**flux** : The values of fluxes provided in Jansky (Jy).

**fluxErr** : The statistical uncertainties on the fluxes.

**positionAngle** : Position angles of the major axes for the elliptical sources.

**positionAngleErr** : Statistical uncertainties for the major axis position angles.

**size** : Source sizes measured along the major and minor axis.

**sizeErr** : Statistical uncertainties on the source sizes.

**velRefCode** : **long doc missing**





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 113

### 1.55 SpectralWindow Table

Spectral window description. The convention in ALMA is to describe the frequency axis in the topocentric reference frame. If this is not the case (for instance if active Doppler tracking is implemented) then `measFreqRef` should be set accordingly.

SpectralWindow		
Name	Type (Shape)	Comment
<i>Key</i>		
<code>spectralWindowId</code>	Tag	identifies a unique row in the table.
<i>Required Data</i>		
<code>basebandName</code>	BasebandName	identifies the baseband.
<code>netSideband</code>	NetSideband	identifies the net sideband.
<code>numChan (<math>N_{Chan}</math>)</code>	int	the number of frequency channels.
<code>refFreq</code>	Frequency	the reference frequency.
<code>sidebandProcessingMode</code>	SidebandProcessingMode	identifies the sideband processing mode.
<code>totBandwidth</code>	Frequency	the total bandwidth.
<code>windowFunction</code>	WindowFunction	identifies the window function.
<i>Optional Data</i>		
<code>chanFreqStart</code>	Frequency	the frequency of the first channel.
<code>chanFreqStep</code>	Frequency	the increment between two successive frequencies.
<code>chanFreqArray</code>	Frequency [ <code>numChan</code> ]	the frequencies defined as an array ( <code>numChan</code> values).
<code>chanWidth</code>	Frequency	the width of the frequency channel (supposedly constant).
<code>chanWidthArray</code>	Frequency [ <code>numChan</code> ]	Array of channel widths
<code>correlationBit</code>	CorrelationBit	identifies the number of bits used in the signal representation.
<code>effectiveBw</code>	Frequency	the effective noise bandwidth.
<code>effectiveBwArray</code>	Frequency [ <code>numChan</code> ]	array of effective bandwidths (one value per channel).
<code>freqGroup</code>	int	the frequency group number.
<code>freqGroupName</code>	string	the frequency group name.
<code>lineArray</code>	bool [ <code>numChan</code> ]	indicates lines (true) versus baselines (false).
<code>measFreqRef</code>	FrequencyReferenceCode	the reference frame of the frequencies.
<code>name</code>	string	a name for this spectral window.
<code>oversampling</code>	bool	data are "oversampled" (true) or not (false).
<code>quantization</code>	bool	a quantization correction has been applied (true) or not applied (false).
<code>refChan</code>	double	the reference channel "number".
<code>resolution</code>	Frequency	the half power frequency resolution (supposedly constant for all the channels).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 114

SpectralWindow – continued from previous page		
Name	Type (Shape)	Comment
resolutionArray	Frequency [numChan]	the frequency resolutions (possibly variable)(one value per channel).
numAssocValues ( $N_{Ass0}$ )	int	the number of associated values.
assocNature	SpectralResolutionType [numAssocValues]	the natures of the associations with the rows referred to by assocSpectralWindowId.
assocSpectralWindowId	Tag [numAssocValues]	refers to a collection of associated rows in the table.
imageSpectralWindowId	Tag	refers to a unique row in the table (image sideband description).
dopplerId	int	refers to a collection of rows in DopplerTable.

### Column Descriptions:

**spectralWindowId** : Identifies each row of the SpectralWindow table.

**basebandName** : Name of the baseband this spectral window is connected to.

**netSideband** : Equivalent sideband of spectrum frequency axis. Can be USB, LSB but also DSB , or NOSB (in the case of direct amplification).

**numChan** : The number of frequency channels.

**refFreq** : This is the reference frequency of the spectrum, it corresponds to the channel number **refChan** in the case of equidistant channels. This is normally set to the zero-frequency edge of the spectral window, for correlation data, for compatibility with the Measurement Set. TOPO

**sidebandProcessingMode** : In the case of single side band data, provides information on how side bands were separated, or how image sideband data was eliminated.

**totBandwidth** : The total bandwidth for the spectral window.

**windowFunction** : Indicates which window function was applied to the time-domain data before performing Fourier transform, for correlator data. Applying a window spectrum provides apodization of the spectral response to a monochromatic line.

**chanFreqStart** : The central frequency for the first channel of the spectrum. Used for regularly spaced frequencies. Either the couple (chanFreqStart, chanFreqStep) or chanFreqArray must be present. TOPO

**chanFreqStep** : The channel frequency separation. Used for regularly spaced frequencies. Either the couple (chanFreqStart, chanFreqStep) or chanFreqArray must be present. TOPO

**chanFreqArray** : The central frequency for each channel of the spectrum. Present for irregularly spaced frequencies. Either the couple (chanFreqStart, chanFreqStep) or chanFreqArray must be present. TOPO

**chanWidth** : The channel width (at half power) of all channels. Used an array of identical channels. Either **chanWidth** or **chanWidthArray** must be present.

**chanWidthArray** : The channel width at half power. Either **chanWidth** or **chanWidthArray** must be present.

**correlationBit** : Indicates how many bits were used to represent the signal to be correlated.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 115

- effectiveBw** : The effective noise bandwidth of all channels in the spectrum (that is the white noise bandwidth that produces the same output noise fluctuations). Either **effectiveBw** or **effectiveBwArray** must be present.
- effectiveBwArray** : The array of effective noise bandwidth for each channel in the spectrum (that is the white noise bandwidth that produces the same output noise fluctuations). Either **effectiveBw** or **effectiveBwArray** must be present.
- freqGroup** : Frequency group number. Used to associate spectral windows for calibration purposes.
- freqGroupName** : Name of the frequency group. Used to associate spectral windows for calibration purposes.
- lineArray** : Indicates line vs. baseline. For channel averaged data, indicates the channels with line signal as opposed to the ones with baseline data. Used for single-dish spectral line pointing.
- measFreqRef** : The reference frame for frequencies (if not topocentric).
- name** : Name of this spectral window.
- oversampling** : Oversampling is true if the data is sampled at more than the Nyquist rate (improving signal to noise).
- quantization** : True if the quantization correction has been applied to the data.
- refChan** : This is the channel number corresponding to the frequency **refFreq**. It does not need to be an integer (for instance the reference frequency may fall between two channels if a half-channel is introduced in the correlator software).
- resolution** : The half-power width of the frequency channels. Used for identical channels. Either **resolution** or **resolutionArray** must be present.
- resolutionArray** : The array of half-power widths of the frequency channels. Either **resolution** or **resolutionArray** must be present.
- numAssocValues** : Number of associated spectral windows.
- assocNature** : Nature of association between spectral windows. In some cases two spectral windows are generated with the same data (full resolution and channel averaged); the association mechanism links these together.
- assocSpectralWindowId** : Associates another focus model used in addition. Used for the auxiliary pointing model (e.g. local pointing model, ...). The actual associated row is obtained by associating the current **antennaId** with **associatedFocusModelId** to form the key.
- imageSpectralWindowId** : The row in the SpectralWindow table which contains the description of the image sideband.
- dopplerId** : Doppler Table identifier.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 116

### 1.56 SquareLawDetector Table

Processor information for total power detectors.

SquareLawDetector		
Name	Type (Shape)	Comment
<i>Key</i>		
squareLawDetectorId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
numBand ( $N_{Band}$ )	int	the number of bands.
bandType	DetectorBandType	identifies the band type.

#### Column Descriptions:

squareLawDetectorId : Identifies each row of the Square law detector table.

numBand : The number of band detectors.

bandType : Band type, e.g. BASEBAND (for Alma there is also a detector higher in the chain, covering all basebands).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 117

### 1.57 State Table

State information.

State		
Name	Type (Shape)	Comment
<i>Key</i>		
stateId	Tag	identifies a unique row in the table.
<i>Required Data</i>		
calDeviceName	CalibrationDevice	the name of the calibration device.
sig	bool	data to be used for signal measurement (true) or not (false).
ref	bool	data to be used for reference measurement (true) or not (false).
onSky	bool	the beam is on the sky (true) or not (false).
<i>Optional Data</i>		
weight	float	used for combining data.

#### Column Descriptions:

stateId : Identifies each row of the State table.

calDeviceName : Name of the calibration device (must be there if onSky is false).

sig : Data will be used for signal measurement.

ref : Data will be used for reference measurement.

onSky : True if the receiver is getting radiation from the sky.

weight : Weight to be used for combining data (useful when there are more than one signal or reference states).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 118

### 1.58 Station Table

Antenna station information.

Station		
Name	Type (Shape)	Comment
<i>Key</i>		
stationId	Tag	Station identifier.
<i>Required Data</i>		
name	string	the name of the station.
position	Length [3]	the position of the station.
type	StationType	identifies the type of the station.
<i>Optional Data</i>		
time	ArrayTime	the time of position measurement.

#### Column Descriptions:

stationId : Identifies each row of the Station table.

name : The name of the station.

position : The position of the station in geocentric frame of reference (X, Y, Z coordinates). ITRF

type : The station type, e.g. ANTENNA or WEATHER.

time : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 119

### 1.59 Subscan Table

Subscan-based information.

Subscan		
Name	Type (Shape)	Comment
<i>Key</i>		
execBlockId	Tag	identifies a unique row in ExecBlockTable.
scanNumber	int	the number of the scan this subscan belongs to.
subscanNumber	int	the subscan number.
<i>Required Data</i>		
startTime	ArrayTime	the actual start time of the subscan.
endTime	ArrayTime	the actual end time of the subscan.
fieldName	string	the name of the observed field.
subscanIntent	SubscanIntent	the intent of the subscan.
numIntegration ( $N_{Inte}$ )	int	the number of integrations during the scan.
numSubintegration ( $N_{Subi}$ )	int [numIntegration]	the number of subintegrations for each integration.
<i>Optional Data</i>		
subscanMode	SwitchingMode	identifies the data acquisition mode during the subscan.
correlatorCalibration	CorrelatorCalibration	identifies the correlator calibration during the subscan.

#### Column Descriptions:

execBlockId : ExecBlock Table identifier.

scanNumber : The scan number. This increments starting from 1 in each Execution Block.

subscanNumber : The subscans in a scan are numbered incrementally starting from 1 in each new scan.

startTime : The time when the subscan started collecting science data.

endTime : The time when the subscan finished collecting science data.

fieldName : The name of the field observed during this subscan.

subscanIntent : The intent for this subscan.

numIntegration : The number of integrations in this subscan.

numSubintegration : The number of sub-integrations in each one of the integrations of this subscan.

subscanMode : Describe the mode in which data was taken. Can be e.g. nutator switching, frequency switching, or no switching.

correlatorCalibration : Indicates whether this subscan is used for correlator internal calibration.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 120

### 1.60 SwitchCycle Table

Cycle information in switching modes. Describe each step in a switching cycle.

SwitchCycle		
Name	Type (Shape)	Comment
<i>Key</i>		
<b>switchCycleId</b>	<b>Tag</b>	identifies a unique row in the table.
<i>Required Data</i>		
<b>numStep</b> ( $N_{Step}$ )	int	the number of steps.
<b>weightArray</b>	float [numStep]	the weights (one value per step).
<b>dirOffsetArray</b>	Angle [numStep] [2]	the pointing direction offsets (one pair per step).
<b>freqOffsetArray</b>	Frequency [numStep]	the frequencies offsets (one value per step).
<b>stepDurationArray</b>	Interval [numStep]	the duration of the steps (one value per steps).
<i>Optional Data</i>		
<b>directionCode</b>	DirectionReferenceCode	the reference frame associated to dirOffsetArray.t
<b>directionEquinox</b>	ArrayTime	the equinox associated to directionCode (if required).

#### Column Descriptions:

**switchCycleId** : Identifies each row of the Switch Cycle table.

**numStep** : The number of steps in the swtching cycle.

**weightArray** : Specify a weight to be used for each step of the switching cycle, when combining data (useful to differentiate signal and reference steps).

**dirOffsetArray** : Gives the pointing direction offsets in each step of the switching cycle AZELNOWAntenna.position

**freqOffsetArray** : Gives the frequency offsets in each step of the switching cycle.

**stepDurationArray** : The durations of the steps in the switching cycle.

**directionCode** : The reference frame associated to dirOffsetArray.

**directionEquinox** : The source direction reference equinox , if required by **directionCode** (e.g. being other than AZEL or J2000)





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 121

### 1.61 SysCal Table

System calibration. Gives information on the conversion of data to temperature scale. This table is reduced to follow the contents of the Measurement Set SysCal table. Use only spectral values (use a single channel spectral window for single numbers). `numChan` can be found in the SpectralWindow Table. The contents of this table are used to scale the data in the filler.

SysCal		
Name	Type (Shape)	Comment
<i>Key</i>		
<code>antennaId</code>	Tag	refers to a unique row in AntennaTable.
<code>spectralWindowId</code>	Tag	refers to a unique row in SpectralWindowTable.
<code>timeInterval</code>	ArrayTimeInterval	time interval for which the row's content is valid.
<code>feedId</code>	int	refers to a collection of rows in FeedTable.
<i>Required Data</i>		
<code>numReceptor</code> ( $N_{Rece}$ )	int	the number of receptors.
<code>numChan</code> ( $N_{Chan}$ )	int	the number of frequency channels.
<i>Optional Data</i>		
<code>tcalFlag</code>	bool	the calibration temperature flag.
<code>tcalSpectrum</code>	Temperature [numReceptor] [numChan]	the calibration temperatures (one value per receptor per channel).
<code>trxFlag</code>	bool	the receiver temperature flag.
<code>trxSpectrum</code>	Temperature [numReceptor] [numChan]	the receiver temperatures (one value per receptor per channel).
<code>tskyFlag</code>	bool	the sky temperature flag.
<code>tskySpectrum</code>	Temperature [numReceptor] [numChan]	the sky temperatures (one value per receptor per channel).
<code>tsysFlag</code>	bool	the system temperature flag.
<code>tsysSpectrum</code>	Temperature [numReceptor] [numChan]	the system temperatures (one value per receptor per channel).
<code>tantFlag</code>	bool	the tant flag.
<code>tantSpectrum</code>	float [numReceptor] [numChan]	the Tant spectrum (one value per receptor per channel).
<code>tantTsysFlag</code>	bool	the Tant/Tsys flag.
<code>tantTsysSpectrum</code>	float [numReceptor] [numChan]	the Tant/Tsys spectrum (one value per receptor per channel).
<code>phaseDiffFlag</code>	bool	the phase difference flag.
<code>phaseDiffSpectrum</code>	float [numReceptor] [numChan]	the phase difference spectrum (one value per receptor per channel).

#### Column Descriptions:



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 122

**antennaId** : Specifies which antenna was used in the Antenna Table.

**spectralWindowId** : SpectralWindow Table identifier.

**timeInterval** : Time Interval of validity of the SysCal information

**feedId** : Specifies which feed was used in the Feed Table.

**numReceptor** : The number of receptors.

**numChan** : The number of frequency channels.

**tcalFlag** : Calibration temperature flag.

**tcalSpectrum** : Calibration temperature for each channel.

**trxFFlag** : Receiver temperature flag.

**trxSpectrum** : Receiver temperature for each channel.

**tskyFlag** : Sky temperature flag.

**tskySpectrum** : Sky temperature for each channel

**tsysFlag** : System temperature flag.

**tsysSpectrum** : System temperature for each channel.

**tantFlag** : Tant Flag (MS compatibility).

**tantSpectrum** : Tant Spectrum (MS compatibility).

**tantTsysFlag** : Tant/Tsys Flag (MS compatibility).

**tantTsysSpectrum** : Tant/Tsys Spectrum (MS compatibility).

**phaseDiffFlag** : Phase Difference Flag (MS compatibility)

**phaseDiffSpectrum** : Phase Difference Spectrum (MS compatibility)



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 123

### 1.62 SysPower Table

This table is intended to store power measurements based on a synchronous power detector as used at the EVLA. While the table is intended to be general enough for use with other arrays, it is deeply entwined with the EVLA data acquisition scheme. The units of  $P_{diff}$  and  $P_{sum}$  are such that the system temperature,  $T_{sys}$ , is :  $T_{sys} = \frac{P_{sum}}{P_{diff}} \cdot \frac{T_{cal}}{2}$  where  $T_{cal}$  is the temperature of the noise tube.

SysPower		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	doc missing
spectralWindowId	Tag	doc missing
feedId	int	doc missing
timeInterval	ArrayTimeInterval	time interval over which the content of the row was measured.
<i>Required Data</i>		
numReceptor ( $N_{Rece}$ )	int	The number of receptors.
<i>Optional Data</i>		
switchedPowerDifference	float [numReceptor]	the switched power difference $P_{diff}$ defined by $P_{diff} = G * (P_{on} - P_{off})$ .
switchedPowerSum	float [numReceptor]	the switched power sum $P_{sum}$ defined by $P_{sum} = G(P_{on} + P_{off})$ .
requantizerGain	float [numReceptor]	refers to the gain inserted after the synchronous power detector. For WIDAR, it is the requantizer gain ( $G$ ).

#### Column Descriptions:

antennaId : missing  
 spectralWindowId : missing  
 feedId : missing  
 timeInterval : long doc missing  
 numReceptor : long doc missing  
 switchedPowerDifference : long doc missing  
 switchedPowerSum : long doc missing  
 requantizerGain : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 124

### 1.63 TotalPower Table

Total power data monitoring.

TotalPower		
Name	Type (Shape)	Comment
<i>Key</i>		
time	ArrayTime	doc missing
configDescriptionId	Tag	doc missing
fieldId	Tag	doc missing
<i>Required Data</i>		
scanNumber	int	doc missing
subscanNumber	int	doc missing
integrationNumber	int	doc missing
uvw	Length [ConfigDescription.numAntenna] [3]	doc missing
exposure	Interval [ConfigDescription.numAntenna] [CorrelatorMode.numBaseband]	doc missing
timeCentroid	ArrayTime [ConfigDescription.numAntenna] [CorrelatorMode.numBaseband]	doc missing
floatData	float [] [] []	doc missing
flagAnt	int [ConfigDescription.numAntenna]	doc missing
flagPol	int [] []	doc missing
interval	Interval	doc missing
stateId	Tag [ConfigDescription.numAntenna]	doc missing
execBlockId	Tag	doc missing
<i>Optional Data</i>		
subintegrationNumber	int	doc missing

#### Column Descriptions:

time : missing

configDescriptionId : missing

fieldId : missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 125

scanNumber : missing  
subscanNumber : missing  
integrationNumber : missing  
uvw : missing  
exposure : missing  
timeCentroid : missing  
floatData : missing  
flagAnt : missing  
flagPol : missing  
interval : missing  
stateId : missing  
execBlockId : missing  
subintegrationNumber : missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 126

### 1.64 WVMCal Table

Coefficients to use water vapour monitor information to correct for pathlength variations. This contains the coefficients actually used, while CalWVR contains the coefficients derived from TelCal calibration.

WVMCal		
Name	Type (Shape)	Comment
<i>Key</i>		
antennaId	Tag	refers to a unique row in AntennaTable.
spectralWindowId	Tag	refers to a unique row in SpectralWindowTable.
timeInterval	ArrayTimeInterval	the time interval for which the row's content is valid.
<i>Required Data</i>		
wvrMethod	WVRMethod	identifies the calibration method.
polyFreqLimits	Frequency [2]	the range of frequencies in which the computation is performed.
numInputAntenna ( $N_{Inpu}$ )	int	The number of antennas used for the calculations.
numChan ( $N_{Chan}$ )	int	the number of WVR channels.
numPoly ( $N_{Poly}$ )	int	the number of coefficients used in the polynomial expansions.
pathCoeff	float [numInputAntenna] [numChan] [numPoly]	the pathlengths coefficients (one value per antenna per chan per coefficient).
refTemp	Temperature [numInputAntenna] [numChan]	the reference temperatures (one value per antenna per channel).
inputAntennaId	Tag [numInputAntenna]	Refers to row(s) in the Antenna table describing the antenna(s) used for the calculations. It is a 1D array expected to have numInputAntenna elements.

#### Column Descriptions:

antennaId : Antenna Table identifier.

spectralWindowId : SpectralWindow Table identifier.

timeInterval : Time Interval of validity of the Water Vapour information.

wvrMethod : Calibration method (see CalWVR table).

polyFreqLimits : Frequency limits of the frequency interval for which the path length coefficients are computed.

numInputAntenna : **long doc missing**

numChan : The number of WVR channels.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 127

`numPoly` : Number of coefficients in polynomial expansion on frequency.

`pathCoeff` : Pathlength coefficients (see CalWVR table).

`refTemp` : Reference temperatures (see CalWVR table).

`inputAntennaId` : **long doc missing**



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
 Date: March 19, 2018  
 Status: Draft  
 Page 128

### 1.65 Weather Table

Weather station information.

Weather		
Name	Type (Shape)	Comment
<i>Key</i>		
stationId	Tag	refers to a unique row in StationTable.
timeInterval	ArrayTimeInterval	the time interval for which the row's content is valid.
<i>Required Data</i>		
<i>Optional Data</i>		
pressure	Pressure	the ambient pressure.
relHumidity	Humidity	the relative humidity.
temperature	Temperature	the ambient temperature.
windDirection	Angle	the wind direction.
windSpeed	Speed	the wind speed.
windMax	Speed	the maximum wind speed
dewPoint	Temperature	the dew point's value.
numLayer ( $N_{Layer}$ )	int	NLayer the number of layers in the temperature profile.
layerHeight	Length [numLayer]	the height of each layer for the temperature profile.
temperatureProfile	Temperature [numLayer]	the temperature on the atmosphere at each height.
cloudMonitor	Temperature	the temperature of the cloud monitor.
numWVR ( $N_{WVR}$ )	int	the number of WVR channels.
wvrTemp	Temperature [numWVR]	the observed temperature in each WVR channel.
water	double	the water precipitable content.

#### Column Descriptions:

stationId : Station Table identifier.

timeInterval : Time Interval of validity of the weather information.

pressure : Ambient pressure (observatory ground level).

relHumidity : Relative humidity (related to dewpoint temperature).

temperature : Ambient temperature.

windDirection : Wind direction (counted East from North).

windSpeed : Average wind speed in interval.

windMax : Maximal wind speed in time interval.

dewPoint : Dewpoint temperature (related to humidity)





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 129

numLayer : long doc missing  
layerHeight : long doc missing  
temperatureProfile : long doc missing  
cloudMonitor : long doc missing  
numWVR : long doc missing  
wvrTemp : long doc missing  
water : long doc missing



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 130

## 2 List of Enumerations



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 131

### 2.1 Versioning information for the enumerations.

- UML description : `/home/gondor/bgarwood/alma/almasw/ICD/HLA/Enumerations/idl/ASDM_Enumerations.mdzip`
- CVS revision : -1
- CVS branch :



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 132

### 2.2 ACAPolarization

version 1 ACA-specific ways to store pre-processed data products

ACA\_STANDARD : Data product is the standard way (it is a standard observed Stokes parameter)

ACA\_XX\_YY\_SUM : ACA has calculated I by averaging XX and YY

ACA\_XX\_50 : ACA has averaged XX and XX delayed by half a FFT period

ACA\_YY\_50 : ACA has averaged YY and YY delayed by half a FFT period

### 2.3 AccumMode

version 1 Accumulation modes for the Correlator

FAST : fast dump time. ALMA use case : 1 ms dump time, available only for autocorrelation.

NORMAL : normal dump time. ALMA use case : 16ms dump time, available for both autocorrelation and cross-orrelation.

UNDEFINED : Not defined or not applicable.

### 2.4 AntennaMake

version 1 The physical types of antenna

AEM\_12 : 12m AEM antenna

MITSUBISHI\_7 : 7-m Mitsubishi antenna (ACA)

MITSUBISHI\_12\_A : 12-m Mitsubishi antenna (ACA) (refurbished prototype)

MITSUBISHI\_12\_B : 12-m Mitsubishi antenna (ACA) (production)

VERTEX\_12\_ATF : 12-m Vertex antenna prototype

AEM\_12\_ATF : 12-m AEM antenna prototype

VERTEX\_12 : 12-m Vertex antenna

IRAM\_15 : 15-m IRAM antenna

UNDEFINED : Not defined or not applicable.

### 2.5 AntennaMotionPattern

version 1 Motion pattern of antenna , e.g. in a calibration scan.

NONE : No pattern.

CROSS\_SCAN : Crossed scan (continuous pattern)

SPIRAL : Spiral pattern

CIRCLE : Circular pattern

THREE\_POINTS : Three points pattern.

FOUR\_POINTS : Four points pattern.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 133

FIVE\_POINTS : Five points pattern.

TEST : Reserved for development.

UNSPECIFIED : Unspecified pattern.

STAR :

LISSAJOUS :

### 2.6 AntennaType

version 1 Functional types of antenna

GROUND\_BASED : Ground-based antenna

SPACE\_BASED : Antenna in a spacecraft

TRACKING\_STN : Space-tracking station antenna

### 2.7 AssociatedCalNature

version 1 These are the associated calibration natures

ASSOCIATED\_EXECBLOCK : The associated execblock id concatenated to produce the data set

### 2.8 AssociatedFieldNature

version 1 [ASDM.Field] Nature of the associated field

ON : The associated field is used as ON source data

OFF : The associated field is used as OFF source data

PHASE\_REFERENCE : The associated field is used as Phase reference data

### 2.9 AtmPhaseCorrection

version 1 Status of Phase correction

AP\_UNCORRECTED : Data has no WVR phase correction

AP\_CORRECTED : Data phases have been corrected using WVR data

### 2.10 AxisName

version 1 Axis names.

TIM : Time axis.

BAL : Baseline axis.

ANT : Antenna axis.

BAB : Baseband axis.

SPW : Spectral window axis.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 134

SIB : Sideband axis.

SUB : Subband axis.

BIN : Bin axis.

APC : Atmosphere phase correction axis.

SPP : Spectral point axis.

POL : Polarization axis (Stokes parameters).

STO : Stokes parameter axis.

HOL : Holography axis.

### 2.11 BasebandName

version 1 Baseband names

NOBB : Baseband not applicable.

BB\_1 : Baseband one

BB\_2 : Baseband two

BB\_3 : Baseband three

BB\_4 : Baseband four

BB\_5 : Baseband five (not ALMA)

BB\_6 : Baseband six (not ALMA)

BB\_7 : Baseband seven (not ALMA)

BB\_8 : Baseband eight (not ALMA)

BB\_ALL : All ALMA basebands (i.e. all available basebands)

A1C1\_3BIT :

A2C2\_3BIT :

AC\_8BIT :

B1D1\_3BIT :

B2D2\_3BIT :

BD\_8BIT :

### 2.12 BaselineReferenceCode

version 1 defines reference frames to qualify the measure of a baseline.

J2000 : mean equator, equinox J2000.0

B1950 : mean equator, equinox B1950.0

GALACTIC : galactic coordinates.

SUPERGAL : supergalactic coordinates.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 135

ECLIPTIC : ecliptic for J2000.0

JMEAN : mean equator.

JTRUE : true equator.

APP : apparent geocentric.

BMEAN : mean equator.

BTRUE : true equator.

JNAT : geocentric natural frame.

MECLIPTIC : ecliptic for mean equator.

TECLIPTIC : ecliptic for true equator.

TOPO : apparent geocentric

MERCURY : from JPL DE table.

VENUS :

MARS :

JUPITER :

SATURN :

NEPTUN :

SUN :

MOON :

HADEC :

AZEL :

AZELGEO :

AZELSW : topocentric Az/El (N =<sub>i</sub> E).

AZELNE : idem AZEL.

ITRF : ITRF earth frame.

### 2.13 BinaryDataFlags

version 1 This enumeration declares an ordered list of flagging conditions used to build the flag part in the BDF content. Each enumerator is associated to one bit in a bitset. A bit set to one (resp. zero) means that the corresponding flagging condition is set (resp. unset). The current convention limits the length of the enumeration to 32; the position (0-based) of the enumerator in the enumeration defines the bit position. Any bit whose position is greater or equal to the length of the enumeration and less than 32 should be ignored by the software since it does not correspond to any flagging condition.

INTEGRATION\_FULLY\_BLANKED : All dumps within an integration duration are blanked. When this flag is raised the effect is to have the bin part actualDurations containing zeros? In other words it means 'all dumps affected'. Bit position == 0

WVR\_APC : Coefficients not received. Apply to all BAL involving the antenna. Bit position == 1



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 136

**CORRELATOR\_MISSING\_STATUS** : Correlator status was not retrieved for the period. So yielded data are not reliable. Apply to all BBs handled by the correlator. Bit position == 2

**MISSING\_ANTENNA\_EVENT** : Antenna delay event was not retrieved for the period. So yielded data are not reliable. BALs including the antenna. Bit position == 3

**DELTA\_SIGMA\_OVERFLOW** : In data transmission between the MTI cards, there are one or more channels whose absolute value differences between adjacent channel values are bigger than the maximum number. Bit position == 4

**DELAY\_CORRECTION\_NOT\_APPLIED** : no residual delay correction was applied. It implies that either base-band offset delays from TMCDB were not available or that delay events from the delay server were not received on time to compute and apply a phase rotation to base-lines in the array. == 5

**SYNCHRONIZATION\_ERROR** : cdp node(s) not properly synchronized to the array timing signal (48ms.) All data produced by that node(s) are suspicious. Lags and spectral processing goes as normal, it is just the flag presence in the bdf what indicates that something is suspicious. Bit position == 6

**FFT\_OVERFLOW** : Overflowed POL and derived outputs from it. Dumps between the timestamp marked as FFT overflowed and the time back to 96msec before. Bit position == 7

**TFB\_SCALING\_FACTOR\_NOT\_RETRIEVED** : CCC cannot retrieve scaling factors during calibration for specific antennas the calibration would still end successfully but the cdp will record the faulty scaling factors and add a flag to all involved base-lines. Bit position == 8

**ZERO\_LAG\_NOT\_RECEIVED** : CDP node handling only cross antenna intersections did not receive lag zero information from node(s) handling auto intersections for involved antennas in that cross intersection. Bit position == 9

**SIGMA\_OVERFLOW** : Auto-correlation sigma levels makes impossible any 2 bits quantization correction on lags data. One sigma value out of range affects that antenna itself and all base-lines containing that antenna. Is it possible to merge this flags with *DELTA\_SIGMA\_OVERFLOW*? The difference seem to be the granularity. If it is *POLACACORR* would have to repeat the outputs spectra are made from invalid input signals, e.g., broken optical frames, missing synchronization or no input signal.

**UNUSABLE\_CAI\_OUTPUT\_FAILED** : Quantization correction not applied due to unsuitable lag zero value. BL-CORR note: every possible signal level should be actually accepted (too small or too big), the presence of this bit signals more a software problem than an antenna signal problem. Bit position == 12

**NOISY\_TDM\_CHANNELS** : First TDM channels are normally noisy and they have a large amplitude. If that excess of amplitude in those channels would be the sole reason for keeping the integration storage at 32 bits integers then the software clips those channels and flags the data. Thus preventing large storage for otherwise 16 bits friendly dynamic range. Bit position == 13

**SPECTRAL\_NORMALIZATION\_FAILED** : Auto-correlation and zero-lags figures are required to normalize cross-correlation spectra as prescribed in Scott's 'Specifications and Clarifications of ALMA Correlator Details'. If those figures are not available on time during on-line processing then crosscorrelations are not normalized and the integration flagged. Bit position == 14

**DROPPED\_PACKETS** : T.B.D. Bit position == 15

**DETECTOR\_SATURATED** : T.B.D. Bit position == 16

**NO\_DATA\_FROM\_DIGITAL\_POWER\_METER** : The current data from digital power meter are available for the calculation of the 3-bit linearity correction. An old correction factor is applied. Bit position == 17





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 137

RESERVED\_18 : Not assigned.  
RESERVED\_19 : Not assigned.  
RESERVED\_20 : Not assigned.  
RESERVED\_21 : Not assigned.  
RESERVED\_22 : Not assigned.  
RESERVED\_23 : Not assigned.  
RESERVED\_24 : Not assigned.  
RESERVED\_25 : Not assigned.  
RESERVED\_26 : Not assigned.  
RESERVED\_27 : Not assigned.  
RESERVED\_28 : Not assigned.  
RESERVED\_29 : Not assigned.  
RESERVED\_30 : Not assigned.

ALL\_PURPOSE\_ERROR : This bit designates data flagged in the correlator but does not provide information as to the reason for the flag. Readers are expected not to process the data when this bit is set. Bit position == 31.

### 2.14 CalCurveType

version 1 [CalDM.CalCurve] type pf calibration curve

AMPLITUDE : Calibration curve is Amplitude

PHASE : Calibration curve is phase

UNDEFINED : Not applicable.

### 2.15 CalDataOrigin

version 1

TOTAL\_POWER

WVR

CHANNEL\_AVERAGE\_AUTO

CHANNEL\_AVERAGE\_CROSS

FULL\_RESOLUTION\_AUTO

FULL\_RESOLUTION\_CROSS

OPTICAL\_POINTING

HOLOGRAPHY

NONE



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 138

### 2.16 CalType

version 1 [CalDM.CalData] Used to point to a given CalResult table

CAL\_AMPLI :

CAL\_ATMOSPHERE :

CAL\_BANDPASS :

CAL\_CURVE :

CAL\_DELAY :

CAL\_FLUX :

CAL\_FOCUS :

CAL\_FOCUS\_MODEL :

CAL\_GAIN :

CAL\_HOLOGRAPHY :

CAL\_PHASE :

CAL\_POINTING :

CAL\_POINTING\_MODEL :

CAL\_POSITION :

CAL\_PRIMARY\_BEAM :

CAL\_SEEING :

CAL\_WVR :

CAL\_APPPHASE : Calibration for phasing of ALMA. Applicable at ALMA.

### 2.17 CalibrationDevice

version 1 Devices that may be inserted in the optical path in front of the receiver.

AMBIENT\_LOAD : An absorbing load at the ambient temperature.

COLD\_LOAD : A cooled absorbing load.

HOT\_LOAD : A heated absorbing load.

NOISE\_TUBE\_LOAD : A noise tube.

QUARTER\_WAVE\_PLATE : A transparent plate that introduces a 90-degree phase difference between orthogonal polarizations.

SOLAR\_FILTER : An optical attenuator (to protect receiver from solar heat).

NONE : No device, the receiver looks at the sky (through the telescope).



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 139

### 2.18 CalibrationFunction

version 1 Function of a scan in a calibration set. Useful only in real time.

FIRST : the scan is the first in a calibration set.

LAST : the scan is the last in a calibration set.

UNSPECIFIED : the function is not specified.

### 2.19 CalibrationMode

version 1 Modes of calibration

HOLOGRAPHY : Holography receiver

INTERFEROMETRY : interferometry

OPTICAL : Optical telescope

RADIOMETRY : total power

WVR : water vapour radiometry receiver

### 2.20 CalibrationSet

version 1 Defines sets of calibration scans to be reduced together for a result.

NONE : Scan is not part of a calibration set.

AMPLI\_CURVE : Amplitude calibration scan (calibration curve to be derived).

ANTENNA\_POSITIONS : Antenna positions measurement.

PHASE\_CURVE : Phase calibration scan (calibration curve to be derived).

POINTING\_MODEL : Pointing calibration scan (pointing model to be derived).

ACCUMULATE : Accumulate a scan in a calibration set.

TEST : Reserved for development.

UNSPECIFIED : Unspecified calibration intent.

### 2.21 CorrelationBit

version 1 [APDM] Number of bits used for correlation

BITS\_2x2 : two bit correlation

BITS\_3x3 : three bit correlation

BITS\_4x4 : four bit correlation



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 140

### 2.22 CorrelationMode

version 1 [ASDM.Binary] Actual data products in binary data

CROSS\_ONLY : Cross-correlations only [not for ALMA]

AUTO\_ONLY : Auto-correlations only

CROSS\_AND\_AUTO : Auto-correlations and Cross-correlations

### 2.23 CorrelatorCalibration

version 1 Internal correlator calibrations performed during this subscan

NONE : No internal correlator calibration

CORRELATOR\_CALIBRATION : Internal correlator calibration.

REAL\_OBSERVATION : A 'real' observation.

### 2.24 CorrelatorName

version 1

ALMA\_ACA

ALMA\_BASELINE

ALMA\_BASELINE\_ATF

ALMA\_BASELINE\_PROTO\_OSF

HERSCHEL

IRAM\_PDB

IRAM\_30M\_VESPA

IRAM\_WILMA

NRAO\_VLA

NRAO\_WIDAR

### 2.25 CorrelatorType

version 1 defines the type of a correlator.

FX : identifies a digital correlator of type FX.

XF : identifies a digital correlator of type XF.

FXF : identifies a correlator of type FXF.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 141

### 2.26 DataContent

version 1 [ASDM.Binaries] Contents of binary data attachment

CROSS\_DATA : Cross-correlation data

AUTO\_DATA : Auto-correlation data

ZERO\_LAGS : Zero-lag data

ACTUAL\_TIMES : :Actual times (mid points of integrations)

ACTUAL\_DURATIONS : Actual duration of integrations

WEIGHTS : Weights

FLAGS : Baseband based flags

### 2.27 DataScale

version 1 Units of the cross and auto data in the BDF.

K : Visibilities in Antenna temperature scale (in Kelvin).

JY : Visibilities in Flux Density scale (Jansky).

CORRELATION : Correlated Power: WIDAR raw output, normalised by DataValid count.

CORRELATION\_COEFFICIENT : Correlation Coefficient (Correlated Power scaled by autocorrelations).

### 2.28 DetectorBandType

version 1 [ASDM.SquareLawDetector] Types of detectors

BASEBAND : Detector in Baseband Processor

DOWN\_CONVERTER : Detector in Down - Converter

HOLOGRAPHY\_RECEIVER : Detector in Holography Receiver

SUBBAND : Detector in subband (tunable digital filter).

### 2.29 DifferenceType

version 1 An enumeration to qualify the values in the columns polarOffsetsType and timeType in the table DelayModelVariableParameters.

PREDICTED :

PRELIMINARY :

RAPID :

FINAL :



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 142

### 2.30 DirectionReferenceCode

version 1 defines reference frames to qualify the measure of a direction.

J2000 : mean equator and equinox at J2000.0

JMEAN : mean equator and equinox at frame epoch.

JTRUE : true equator and equinox at frame epoch.

APP : apparent geocentric position.

B1950 : mean epoch and ecliptic at B1950.0.

B1950\_VLA :

BMEAN : mean equator and equinox at frame epoch.

BTRUE : true equator and equinox at frame epoch.

GALACTIC : galactic coordinates.

HADEC : topocentric HA and declination.

AZELSW : topocentric Azimuth and Elevation (N through E).

AZELSWGEO :

AZELNE : idem AZEL

AZELNEGEO :

JNAT : geocentric natural frame.

ECLIPTIC : ecliptic for J2000.0 equator, equinox.

MECLIPTIC : ecliptic for mean equator of date.

TECLIPTIC : ecliptic for true equator of date.

SUPERGAL : supergalactic coordinates.

ITRF : coordinates wrt ITRF earth frame.

TOPO : apparent topocentric position.

ICRS :

MERCURY : from JPL DE table.

VENUS :

MARS :

JUPITER :

SATURN :

URANUS :

NEPTUNE :

PLUTO :

SUN :

MOON :



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 143

### 2.31 DopplerReferenceCode

version 1 defines reference frames to qualify the measure of a radial velocity expressed as doppler shift.

RADIO : radio definition :  $1 - F$

Z : redshift :  $-1 + 1/F$

RATIO : frequency ratio :  $F$

BETA : relativistic :  $(1 - F^2)/(1 + F^2)$

GAMMA :  $(1 + F^2)/(2 * F)$

OPTICAL :  $ZZ$

RELATIVISTIC : idem BETA

### 2.32 DopplerTrackingMode

version 1 Enumerations of different modes used in doppler tracking.

NONE : No Doppler tracking.

CONTINUOUS : Continuous (every integration) Doppler tracking.

SCAN\_BASED : Doppler tracking only at scan boundaries. This means we update the observing frequency to the correct value, but only at scan boundaries.

SB\_BASED : Doppler tracking only at the beginning of the Scheduling Block. We set the frequency at the beginning of the observation but leave it fixed thereafter. For the EVLA this is referred to as 'Doppler setting'.

### 2.33 FieldCode

version 1 [ASDM.Field] code for Field

NONE :

### 2.34 FilterMode

version 1 [APDM.Correlator] Modes of correlator input filtering

FILTER\_NA : Not Applicable (2 antenna prototype). The Tunable Filter Banks are not implemented

FILTER\_TDM : Time Division Mode. In this mode the Tunable Filter banks are bypassed

FILTER\_TFB : The Tunable Filter Bank is implemented and used

UNDEFINED : Not defined or not applicable.

### 2.35 FluxCalibrationMethod

version 1 [CalDM.CalFlux] Methods for flux calibration

ABSOLUTE : Absolute flux calibration (based on standard antenna)

RELATIVE : Relative flux calibration (based on a primary calibrator)

EFFICIENCY : Flux calibrator based on tabulated antenna efficiency



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 144

### 2.36 FocusMethod

version 1 [CalDM.CalFocus] Method of focus measurement

THREE\_POINT : Three-point measurement

FIVE\_POINT : Five-point measurement

HOLOGRAPHY :

### 2.37 FrequencyReferenceCode

version 1 defines reference frames to qualify the measure of a frequency.

LABREST : spectral line rest frequency.

LSRD : dynamic local standard of rest.

LSRK : kinematic local standard rest.

BARY : barycentric frequency.

REST : spectral line frequency

GEO : geocentric frequency.

GALACTO : galactocentric frequency.

TOPO : topocentric frequency.

### 2.38 HolographyChannelType

version 1 [ASDM.Holography] Type sof holography receiver output channels

Q2 : Quadrature channel auto-product

QR : Quadrature channel times Reference channel cross-product

QS : Quadrature channel times Signal channel cross-product

R2 : Reference channel auto-product

RS : Reference channel times Signal channel cross-product

S2 : Signal channel auto-product

### 2.39 InvalidatingCondition

version 1 [CalDM.CalReduction] Contitions invalidating result

ANTENNA\_DISCONNECT : Antenna was disconnected

ANTENNA\_MOVE : Antenna was moved

ANTENNA\_POWER\_DOWN : Antenna was powered down

RECEIVER\_EXCHANGE : Receiver was exchanged

RECEIVER\_POWER\_DOWN : Receiver was powered down





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 145

### 2.40 NetSideband

version 1 [ASDM.SpectralWindow] Equivalent side band of spectrum frequency axis

NOSB : No side band (no frequency conversion)

LSB : Lower side band

USB : Upper side band

DSB : Double side band

### 2.41 PointingMethod

version 1 [CalDM.CalPointing] Method of pointing measurement

THREE\_POINT : Three-point scan

FOUR\_POINT : Four-point scan

FIVE\_POINT : Five-point scan

CROSS : Cross scan

CIRCLE : Circular scan

HOLOGRAPHY :

### 2.42 PointingModelMode

version 1 [CalDM.PointingModel] Mode of Pointing Model

RADIO : Radio pointing model

OPTICAL : Optical Pointing Model

### 2.43 PolarizationType

version 1 The polarizations a single receptor can detect

R : Right-handed Circular

L : Left-handed Circular

X : X linear

Y : Y linear

BOTH : The receptor responds to both polarizations.

### 2.44 PositionMethod

version 1 [CalDM.CalPositions] Method used for measuring antenna positions

DELAY\_FITTING : Delays are measured for each source; the delays are used for fitting antenna position errors.

PHASE\_FITTING : Phases are measured for each source; these phases are used to fit antenna position errors.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 146

### 2.45 PositionReferenceCode

version 1 defines reference frames to qualify the measure of a position.

ITRF : International Terrestrial Reference Frame.

WGS84 : World Geodetic System.

SITE : Site reference coordinate system (ALMA-80.05.00.00-009-B-SPE).

STATION : Antenna station reference coordinate system (ALMA-80.05.00.00-009-SPE).

YOKE : Antenna yoke reference coordinate system (ALMA-980.05.00.00-009-B-SPE)

REFLECTOR : Antenna reflector reference coordinate system (ALMA-80.05.00.00-009-B-SPE).

### 2.46 PrimaryBeamDescription

version 1 Nature of the quantity tabulated to describe the primary beam.

COMPLEX\_FIELD\_PATTERN : Electric Field Pattern image at infinite distance from antenna.

APERTURE\_FIELD\_DISTRIBUTION : Electric Field aperture distribution.

### 2.47 PrimitiveDataType

version 1 [ASDM.Binaries] Primitive data types for binary MIME attachments

INT16\_TYPE : 2 bytes signed integer (short).

INT32\_TYPE : 4 bytes signed integer (int).

INT64\_TYPE : 8 bytes signed integer (long long).

FLOAT32\_TYPE : 4 bytes float (float).

FLOAT64\_TYPE : 8 bytes float (double).

### 2.48 ProcessorSubType

version 1 [ASDM.Processor] The tables used to contain device configuration data

ALMA\_CORRELATOR\_MODE : ALMA correlator.

SQUARE\_LAW\_DETECTOR : Square law detector.

HOLOGRAPHY : Holography.

ALMA\_RADIOMETER : ALMA radiometer.

### 2.49 ProcessorType

version 1 [ASDM.Processor] Types of processors

CORRELATOR : A digital correlator

RADIOMETER : A radiometer

SPECTROMETER : An (analogue) multi-channel spectrometer



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 147

### 2.50 RadialVelocityReferenceCode

version 1

LSRD

LSRK

GALACTO

BARY

GEO

TOPO

### 2.51 ReceiverBand

version 1 [ASDM.Receiver] Receiver band names

ALMA\_RB\_01 : ALMA Receiver band 01

ALMA\_RB\_02 : ALMA Receiver band 02

ALMA\_RB\_03 : ALMA Receiver band 03

ALMA\_RB\_04 : ALMA Receiver band 04

ALMA\_RB\_05 : ALMA Receiver band 05

ALMA\_RB\_06 : ALMA Receiver band 06

ALMA\_RB\_07 : ALMA Receiver band 07

ALMA\_RB\_08 : ALMA Receiver band 08

ALMA\_RB\_09 : ALMA Receiver band 09

ALMA\_RB\_10 : ALMA Receiver band 10

ALMA\_RB\_ALL : all ALMA receiver bands.

ALMA\_HOLOGRAPHY\_RECEIVER : Alma transmitter Holography receiver.

BURE\_01 : Plateau de Bure receiver band 1.

BURE\_02 : Plateau de Bure receiver band 2.

BURE\_03 : Plateau de Bure receiver band 3.

BURE\_04 : Plateau de Bure receiver band 4

EVLA\_4 :

EVLA\_P :

EVLA\_L :

EVLA\_C :

EVLA\_S :

EVLA\_X :

EVLA\_Ku :



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 148

EVLA\_K :

EVLA\_Ka :

EVLA\_Q :

UNSPECIFIED : receiver band of unspecified origin.

### 2.52 ReceiverSideband

version 1 [ASDM.SpectralWindow] The type of receiver output a spectral window is fed with

NOSB : direct output signal (no frequency conversion).

DSB : double side band output.

SSB : single side band receiver.

TSB : receiver with dual output.

### 2.53 SBType

version 1 [ASDM.SBSummary] Types of Scheduling Block

OBSERVATORY : Observatory mode scheduling block

OBSERVER : Observer mode scheduling block

EXPERT : Expert mode scheduling block

### 2.54 ScanIntent

version 1 [ASDM.Scan] Scan intents

CALIBRATE\_AMPLI : Amplitude calibration scan

CALIBRATE\_ATMOSPHERE : Atmosphere calibration scan

CALIBRATE\_BANDPASS : Bandpass calibration scan

CALIBRATE\_DELAY : Delay calibration scan

CALIBRATE\_FLUX : flux measurement scan.

CALIBRATE\_FOCUS : Focus calibration scan. Z coordinate to be derived

CALIBRATE\_FOCUS\_X : Focus calibration scan; X focus coordinate to be derived

CALIBRATE\_FOCUS\_Y : Focus calibration scan; Y focus coordinate to be derived

CALIBRATE\_PHASE : Phase calibration scan

CALIBRATE\_POINTING : Pointing calibration scan

CALIBRATE\_POLARIZATION : Polarization calibration scan

CALIBRATE\_SIDEHAND\_RATIO : measure relative gains of sidebands.

CALIBRATE\_WVR : Data from the water vapor radiometers (and correlation data) are used to derive their calibration parameters.



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 149

DO\_SKYDIP : Skydip calibration scan

MAP\_ANTENNA\_SURFACE : Holography calibration scan

MAP\_PRIMARY\_BEAM : Data on a celestial calibration source are used to derive a map of the primary beam.

OBSERVE\_TARGET : Target source scan

CALIBRATE\_POL\_LEAKAGE :

CALIBRATE\_POL\_ANGLE :

TEST : used for development.

UNSPECIFIED : Unspecified scan intent

CALIBRATE\_ANTENNA\_POSITION : Requested by EVLA.

CALIBRATE\_ANTENNA\_PHASE : Requested by EVLA.

MEASURE\_RFI : Requested by EVLA.

CALIBRATE\_ANTENNA\_POINTING\_MODEL : Requested by EVLA.

SYSTEM\_CONFIGURATION : Requested by EVLA.

CALIBRATE\_APPPHASE\_ACTIVE : Calculate and apply phasing solutions. Applicable at ALMA.

CALIBRATE\_APPPHASE\_PASSIVE : Apply previously obtained phasing solutions. Applicable at ALMA.

OBSERVE\_CHECK\_SOURCE :

CALIBRATE\_DIFFGAIN : Enable a gain differential target type

### 2.55 SchedulerMode

version 1 [ASDM.SBSummary] Scheduler operation mode

DYNAMIC : Dynamic scheduling

INTERACTIVE : Interactive scheduling

MANUAL : Manual scheduling

QUEUED : Queued scheduling

### 2.56 SidebandProcessingMode

version 1 [ASDM.SpectralWindow] Real-time processing to derive sideband data

NONE : No processing

PHASE\_SWITCH\_SEPARATION : Side band separation using 90-degree phase switching

FREQUENCY\_OFFSET\_SEPARATION : Side band separation using offsets of first and second oscillators

PHASE\_SWITCH\_REJECTION : Side band rejection 90-degree phase switching

FREQUENCY\_OFFSET\_REJECTION : Side band rejection using offsets of first and second oscillators



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 150

### 2.57 SourceModel

version 1 [CalDM.CalFlux] Source Model

GAUSSIAN : Gaussian source

POINT : Point Source

DISK : Uniform Disk

### 2.58 SpectralResolutionType

version 1 [ASDM.SpectralWindow] The types of spectral resolutions for spectral windows.

CHANNEL\_AVERAGE :

BASEBAND\_WIDE :

FULL\_RESOLUTION :

### 2.59 StationType

version 1 [ASDM.Station] Type of antenna station

ANTENNA\_PAD : Astronomical Antenna station

MAINTENANCE\_PAD : Maintenance antenna station

WEATHER\_STATION : Weather station

### 2.60 StokesParameter

version 1 Stokes parameters (CASA definition)

I :

Q :

U :

V :

RR :

RL :

LR :

LL :

XX : Linear correlation product

XY :

YX :

YY :

RX : Mixed correlation product

RY : Mixed correlation product



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 151

LX : Mixed LX product

LY : Mixed LY correlation product

XR : Mixed XR correlation product

XL : Mixed XL correlation product

YR : Mixed YR correlation product

YL : Mixel YL correlation product

PP :

PQ :

QP :

QQ :

RCIRCULAR :

LCIRCULAR :

LINEAR : single dish polarization type

PTOTAL : Polarized intensity  $((Q^2 + U^2 + V^2)^{1/2})$  : *LinearlyPolarizedintensity* $((Q^2 + U^2)^{1/2})$

~~PLINEAR~~ PLINEAR : Polarization Fraction (Ptotal/I)

PFLINEAR : Linear Polarization Fraction (Plinear/I)

PANGLE : Linear Polarization Angle  $(0.5 \arctan(U/Q))$  (in radians)

### 2.61 SubscanIntent

version 1 [ASDM.Subscan] Precise the intent for a subscan

ON\_SOURCE : on-source measurement

OFF\_SOURCE : off-source measurement

MIXED : Pointing measurement, some antennas are on -ource, some off-source

REFERENCE : reference measurement (used for boresight in holography).

SCANNING : antennas are scanning.

HOT : hot load measurement.

AMBIENT : ambient load measurement.

SIGNAL : Signal sideband measurement.

IMAGE : Image sideband measurement.

TEST : reserved for development.

UNSPECIFIED : Unspecified



## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 152

### 2.62 SwitchingMode

version 1 Switching modes: there are two categories of switching modes, those at high rate (chopper wheel, nutator and frequency switch) which involve the BIN axis and those at low rate (frequency, position, load and phase switching) unrelated to the bin axis. Note that in case of frequency switching mode it is the context which tells in which of these two categories it is used.

NO\_SWITCHING : No switching

LOAD\_SWITCHING : Receiver beam is switched between sky and load

POSITION\_SWITCHING : Antenna (main reflector) pointing direction is switched

PHASE\_SWITCHING : 90 degrees phase switching (switching mode used for sideband separation or rejection with DSB receivers)

FREQUENCY\_SWITCHING : LO frequency is switched (definition context sensitive: fast if cycle shorter than the integration duration, slow if e.g. step one step per subscan)

NUTATOR\_SWITCHING : Switching between different directions by nutating the sub-reflector

CHOPPER\_WHEEL : Switching using a chopper wheel

### 2.63 SynthProf

version 1

NOSYNTH

ACACORR

ACA\_CDP

### 2.64 SyscalMethod

version 1 [CalDM.CalAtmosphere] Atmosphere calibration methods

TEMPERATURE\_SCALE : Use single direction data to compute  $\tau_a^*$  scale

SKYDIP : Use a skydip (observing the sky at various elevations) to get atmospheric opacity

SIDEBAND\_RATIO : Measure the sideband gain ratio.

### 2.65 TimeSampling

version 1 Time granularity for data

SUBINTEGRATION : Part of an integration

INTEGRATION : Part of a subscan. An integration may be composed of several sub-integrations.

### 2.66 TimeScale

version 1 Time standards.

UTC : Coordinated Universal Time.

TAI : International Atomic Time.





## SDM Tables Short Description

Doc#: COMP-70.75.00.00-00?-A-DSN  
Date: March 19, 2018  
Status: Draft  
Page 153

### 2.67 WVRMethod

version 1 [CalDM.CalWVR] Methods for WVR Data processing in TelCal

ATM\_MODEL : WVR data reduction uses ATM model

EMPIRICAL : WVR data reduction optimized using actual phase data

### 2.68 WeightType

version 1

K

JY

COUNT\_WEIGHT

### 2.69 WindowFunction

version 1 [APDM; ASDM.ALmaCorrelatorMode] Windowing functions for spectral data apodization

UNIFORM : No windowing

HANNING : Raised cosine:  $0.5 * (1 - \cos(x))$  where  $x = 2 * \pi * i / (N - 1)$

HAMMING : The classic Hamming window is  $W_M(x) = 0.54 - 0.46 * \cos(x)$ . This is generalized to  $W_M(x) = \beta - (1 - \beta) * \cos(x)$  where  $\beta$  can take any value in the range  $[0, 1]$ .  $\beta = 0.5$  corresponds to the Hanning window.

BARTLETT : The Bartlett (triangular) window is  $1 - |x/\pi|$ , where  $x = 2 * \pi * i / (N - 1)$ .

BLACKMANN : The window function is  $W_B(x) = (0.5 - \beta) - 0.5 * \cos(x_j) + \beta * \cos(2x_j)$ , where  $x_j = 2 * \pi * j / (N - 1)$ . The classic Blackman window is given by  $\beta = 0.08$ .

BLACKMANN\_HARRIS : The BLACKMANN\_HARRIS window is  $1.36109 * \cos(x) + 0.39381 * \cos(2 * x) - 0.032557 * \cos(3 * x)$ , where  $x = 2 * \pi * i / (N - 1)$ .

WELCH : The Welch window (parabolic) is  $1 - (2 * i / N)^2$ .